Tieasy USCF-702

Tieasy USCF-702 Range Hood Replacement Charcoal Filter Instruction Manual

Comprehensive guide for installation and maintenance of your Tieasy USCF-702 charcoal filter.

1. Product Overview

The Tieasy USCF-702 charcoal filter is designed to effectively assist in ventilating and purifying the air in your kitchen by absorbing cooking odors and grease. This replacement filter is specifically compatible with the Tieasy Under Cabinet Range Hood model USUC702B.



Image: Two Tieasy USCF-702 charcoal filters, essential for maintaining air quality in your range hood.

2. Product Specifications

- **Brand:** Tieasy
- **Model:** USCF-702
- **Compatible Device:** Tieasy Under Cabinet Range Hood USUC702B
- **Material:** Carbon
- **Item Weight:** 12.6 ounces
- **Product Dimensions:** 7.24 x 7.13 x 2.32 inches

3. Installation Instructions

The Tieasy USCF-702 charcoal filter is designed for easy installation without the need for additional tools. Follow these general steps to replace your filter:

1. **Power Off:** Ensure the range hood is completely powered off and unplugged from the electrical outlet before beginning any installation or maintenance.
2. **Locate Filters:** Identify the existing filters within your range hood. These are typically located on the underside of the hood, above the cooking surface.
3. **Remove Old Filters:** Depending on your specific range hood model, the old filters may be held in place by clips, latches, or a simple push-and-release mechanism. Carefully disengage these fasteners and remove the used charcoal filters.
4. **Insert New Filters:** Align the new Tieasy USCF-702 charcoal filters with the designated slots or areas in the range hood. Ensure they fit snugly and are oriented correctly according to your range hood's design.
5. **Secure Filters:** Re-engage any clips, latches, or mechanisms to firmly secure the new filters in place. Confirm that the filters are stable and will not fall during operation.
6. **Restore Power:** Once the new filters are securely installed, plug the range hood back into the electrical outlet and restore power.

Your browser does not support the video tag.

Video: This video demonstrates the general installation process for a range hood, including the placement of filters. While it may show mesh filters, the principle of securing filters within the hood is similar for charcoal filters.

4. Maintenance and Replacement

Charcoal filters are crucial for removing odors and grease from your kitchen air. Unlike baffle or mesh filters, charcoal filters are not typically cleaned but rather replaced.

- **Replacement Frequency:** The lifespan of a charcoal filter depends on your cooking habits and kitchen conditions. It is generally recommended to replace the Tieasy USCF-702 charcoal filter every 3 to 6 months for optimal performance. Heavy cooking or frequent frying may necessitate more frequent replacement.
- **Signs of Replacement:** If you notice a decrease in odor absorption, increased cooking odors lingering in the kitchen, or visible signs of saturation on the filter, it is time for a replacement.

5. Important Notes

- Always ensure the range hood is disconnected from power before handling filters.
- Use only genuine Tieasy USCF-702 replacement filters to ensure proper fit and performance.
- Dispose of used filters responsibly according to local regulations.

© 2024 Tieasy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question