**PHILCO PTV42M9GR2CMB**

# Smart TV 42-inch Philco PTV42M9GR2CMB LED Roku TV User Manual

Model: PTV42M9GR2CMB | Brand: PHILCO

## Introduction

Welcome to the user manual for your new Philco PTV42M9GR2CMB 42-inch Smart LED Roku TV. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your television. Your TV features Dolby Audio for immersive sound, a Quad-Core processor for smooth performance, and the intuitive Roku OS for easy access to a wide range of streaming content.

## Important Safety Instructions

Please read all safety and operating instructions carefully before using your television. Keep these instructions for future reference.

- **Placement:** Ensure the TV is placed on a stable, level surface. Do not block ventilation openings. Maintain adequate space around the TV for proper airflow.
- **Power:** Use only the specified power supply. Ensure the power cord is not pinched or walked on. Unplug the TV during lightning storms or when unused for long periods.
- **Cleaning:** Always unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Ventilation:** Slots and openings in the cabinet are provided for ventilation. Do not block these openings.

## Initial Setup

### Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for future transport or service needs.




Figure 1: Front view of the Philco PTV42M9GR2CMB Smart TV.

## Attaching the Stand

To attach the base stand to your TV, align the stand with the designated slots on the bottom of the TV. Secure the stand using the provided screws. Ensure the stand is firmly attached before placing the TV on a surface.




Figure 2: Side view showing stand attachment area.

## Connecting Peripherals

Your Philco Smart TV offers multiple connectivity options. Connect your devices to the appropriate ports:

- **HDMI Ports:** Connect Blu-ray players, game consoles, or set-top boxes using HDMI cables. The TV supports HDMI and HDMI ARC for enhanced audio return.
- **USB Ports:** Insert USB drives for media playback (videos, images, music) or to record digital files.

- **Ethernet Port:** For a stable wired internet connection, connect an Ethernet cable from your router to the TV's Ethernet port.



Figure 3: Rear view with connectivity ports.

### Powering On

After connecting all necessary cables, plug the AC power cable into the TV and then into a power outlet. Press the power button on the remote control or on the TV itself to turn it on. Follow the on-screen instructions for initial setup, including language selection and network configuration.

## Operating Your Smart TV

### Remote Control

The included remote control uses infrared technology to operate your TV. Point the remote directly at the TV's infrared sensor. Familiarize yourself with the buttons for navigation, volume, channel selection, and direct access to streaming services.

### Roku OS Interface

Your Philco Smart TV runs on the Roku OS, providing a user-friendly interface. The home screen displays your installed streaming channels, input selections, and settings. Use the directional pad on your remote to navigate through menus and select options.





Figure 4: Roku OS Home Screen.

## Audio and Video Settings

Access the TV's settings menu to adjust picture and sound preferences. Your TV features Dolby Audio for a rich 5.1 channel surround sound experience. You can customize picture modes (e.g., Standard, Movie, Sport) and audio settings to suit your viewing environment.



Figure 5: Displaying vibrant colors on screen.

### Network Connection

To access streaming content and smart features, connect your TV to the internet. You can connect via Wi-Fi or a wired Ethernet connection. Navigate to the 'Settings' menu, then 'Network' to configure your connection.

### Using the Mobile App

Download the official Roku mobile app on your smartphone to use it as an alternative remote control. The app provides convenient features like voice search, private listening, and easy text entry.

## Care and Maintenance

Proper care ensures the longevity of your Philco Smart TV.

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution (never spray directly onto the screen).
- **Cabinet Cleaning:** Use a soft, dry cloth to clean the TV cabinet. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not obstructed by dust or objects.
- **Power Cord:** Regularly check the power cord for any damage.

## Troubleshooting

This section addresses common issues you might encounter and provides simple solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| No Power | Power cord disconnected; Power outlet issue. | Ensure power cord is securely plugged into TV and outlet. Test outlet with another device. |
| No Picture, but Sound is Present | Incorrect input source; Loose video cable. | Press the 'Input' or 'Source' button on the remote to select the correct input. Check video cable connections. |
| No Sound, but Picture is Present | Volume muted or too low; Incorrect audio output setting. | Increase volume. Check TV's audio settings to ensure correct output (e.g., TV speakers, external audio system). |
| Cannot Connect to Wi-Fi | Incorrect password; Router issues; TV too far from router. | Verify Wi-Fi password. Restart router. Move TV closer to router or use a wired Ethernet connection. |
| Remote Control Not Responding | Dead batteries; Obstruction between remote and TV. | Replace batteries. Remove any objects blocking the remote's line of sight to the TV's IR sensor. |

## Technical Specifications

| Feature | Detail |
|---|---|
| Brand | PHILCO |
| Model Name | PTV42M9GR2CMB |
| Screen Size | 42 Inches (107 cm diagonal) |

| Feature | Detail |
|---|---|
| Display Technology | LED |
| Resolution | 1080p (1920 x 1080) |
| Refresh Rate | 60 Hz |
| Aspect Ratio | 16:9 |
| Operating System | Roku OS |
| Audio Output Mode | Surround (Dolby Audio, 5.1 Channels) |
| Connectivity Technology | Wi-Fi, USB, Ethernet, HDMI |
| HDMI Ports | Multiple (including HDMI ARC) |
| USB Ports | 2 |
| Bluetooth | No |
| Special Features | Sleep timer, Multiple voice assistance |
| Voltage | 110 Volts, 220 Volts (Bivolt) |
| Product Dimensions (WxHxD) | 94.5 x 57.2 x 18.5 cm (with stand) |
| Product Weight | 7.41 Kilograms |

## Warranty and Support

### Manufacturer's Warranty

This Philco Smart TV PTV42M9GR2CMB comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Philco customer support. Refer to the contact information provided in your product packaging or visit the official Philco website for the most up-to-date support details.

© 2024 PHILCO. All rights reserved.

**Ask a question about this manual**

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**