Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beyution AWOL-RC

AWOL-RC Replacement Remote Control User Manual

Brand: Beyution

Introduction

This manual provides instructions for the AWOL-RC Replacement Remote Control, designed for use with AWOL TV/Audio/Projector systems. This remote is a direct replacement and does not require complex setup or programming.

Figure 1: Front view of the AWOL-RC Replacement Remote Control, showing all buttons and the sleek silver design.

Setup

Battery Installation

The AWOL-RC remote control operates using standard batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert the required batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.

Figure 2: Back view of the AWOL-RC remote control, illustrating the open battery compartment and the battery cover.

Note:

- This is a replacement infrared remote control that does not require setup and programming.
- Ensure fresh batteries are used for optimal performance.

Operating Instructions

The AWOL-RC remote control is designed for intuitive use with your AWOL TV/Audio/Projector. Its ergonomic design ensures comfortable handling, and buttons respond with good elasticity.

Button Functions

Button	Function
Power ( )	Turns the connected device On or Off.
Sound	Accesses sound settings or audio modes.
Source	Cycles through input sources (HDMI, AV, etc.).
File	Opens file browser or media playback options.
Setting	Accesses system settings menu.
Navigation Pad (Center Circle)	Used for menu navigation (Up, Down, Left, Right) and selection (OK/Enter).
Back (↶)	Returns to the previous screen or menu.
Home (⌂)	Returns to the main home screen.
Menu (≡)	Opens context-sensitive menus.
Mute ( )	Mutes or unmutes the audio.
Brightness (☀)	Adjusts screen brightness (if supported by device).
Volume Down (-)	Decreases the audio volume.
Volume Up (+)	Increases the audio volume.

The remote control has a maximum effective distance of 10 meters, providing stable performance and fast response.

Maintenance

To ensure the longevity and optimal performance of your AWOL-RC remote control, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. Avoid using liquid cleaners, aerosols, or abrasive cleaning agents, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's responsiveness decreases or it stops functioning. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high

humidity.

- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, which can damage internal circuitry.

Troubleshooting

If you encounter issues with your AWOL-RC remote control, please refer to the following common problems and solutions:

Problem	Possible Solution
Remote is not responding.	◦ Check if the batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new ones. ◦ Ensure there are no obstructions between the remote control and the device's infrared receiver. ◦ Make sure you are within the effective operating distance (up to 10 meters).
Buttons are sticky or unresponsive.	◦ Clean the remote control surface and around the buttons with a soft, dry cloth. ◦ Ensure no foreign objects are lodged under the buttons.
Remote works intermittently.	◦ This often indicates low battery power; replace the batteries. ◦ Ensure a clear line of sight to the device.

If the remote control you receive is damaged or does not work after following these steps, please contact customer support for assistance.

Specifications

- **Remote Control Model:** AWOLRC 2A2S9-AWOL-RC 2A2S9AWOLRC
- **Maximum Distance:** 10 Meters
- **Material:** ABS Plastic
- **Connectivity Technology:** Infrared
- **Color:** White (As shown in main image)
- **Programming/Setup Required:** No
- **Product Dimensions:** 7 x 1.5 x 0.5 inches
- **Item Weight:** 1.9 ounces
- **Compatible Devices:** Television (specifically AWOL TV/Audio/Projector)
- **Special Feature:** Ergonomic, No Programming Required

Compatibility

This replacement remote control is compatible with the following AWOL models:

- AWOLRC 2A2S9-AWOL-RC
- 2A2S9AWOLRC

This list is not exhaustive. If your device model is not listed, please contact the seller to verify compatibility before purchasing.

Warranty and Support

This product is a replacement remote control. For any issues, including receiving a damaged or non-functional remote, please contact the seller directly. They will provide a satisfactory solution.
For further assistance or inquiries, please refer to the contact information provided by your retailer or on the product packaging.

© 2024 Beyution. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB1V1NKX

More documents and user manuals: **https://manuals.plus/**