Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MME-LE2483SM-NP

ALLIMITY Remote Control User Manual

Model: MME-LE2483SM-NP

Introduction

This manual provides comprehensive instructions for the ALLIMITY Remote Control, compatible with various ENGEL, RCA, ANTTEQ, Ioplee, and Nordmende TV models. This remote is designed to offer full functionality without the need for programming or complex setup. Please ensure the remote matches your device's model number or image for proper compatibility.
Compatible models include: IOP43QVDA, iRV42H3, iRV50U3, ND40S404M, iRV24H3, iRV32H3, LE2483SM, LE3283SM, LE4283SM, AV32H3, AV24H3, AV32D1, AV42F3-D1, RS65U2-EU.

Product Overview





Front view of the ALLIMITY remote control, showing all buttons including power, number pad, navigation, volume, channel, and dedicated app buttons.





Side and front view of the ALLIMITY remote control, illustrating its ergonomic design and compact dimensions (18 cm length, 4.5 cm width).



Angled view of the ALLIMITY remote control, highlighting its button layout and sleek black finish.

Setup

1. **Battery Installation:**

   Locate the battery compartment on the back of the remote control. Slide open the battery cover. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside. Close the battery cover securely.

2. **Initial Use:**

   No programming or pairing is required for this remote control. Once batteries are installed, point the remote directly at your compatible TV or device and begin using it immediately.

Operating Instructions

The ALLIMITY remote control is designed to replicate the full functionality of your original remote. Below is a general

guide to its key buttons and their functions:

- **Power Button ( ):** Turns the TV or device on/off.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Number Pad (0-9):** Directly enters channel numbers or other numerical inputs.
- **Guide Button:** Displays the electronic program guide (EPG).
- **CH.LIST Button:** Shows the channel list.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections. The **OK** button confirms choices.
- **Back/Return Button (↶):** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Volume Buttons (VOL + / -):** Increases or decreases the volume level.
- **Mute Button ( ):** Mutes or unmutes the audio.
- **Channel Buttons (CH ▲ / ▼):** Changes the TV channel up or down.
- **Text Button:** Accesses Teletext services.
- **Subtitle Button:** Toggles subtitles on/off.
- **Info Button:** Displays information about the current program or content.
- **Dedicated App Buttons (Netflix, Prime Video, YouTube, Plex, Browser, Disney):** Provides direct access to popular streaming applications and the web browser.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If not used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** While ergonomically designed for a good grip, avoid dropping the remote as this can damage internal components.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote has short range or intermittent response.	Weak batteries; Obstruction between remote and device; Infrared sensor on device is blocked.	Replace batteries. Ensure a clear line of sight to the device's IR sensor. Remove any obstructions.
Certain buttons do not work.	Button malfunction; Remote not fully compatible with all functions of your specific device model.	Check if the button is physically stuck. Verify your device model is listed as compatible. While designed for full functionality, minor variations may occur with some specific device models.

Problem	Possible Cause	Solution
Device does not turn on/off.	Remote not compatible; Device is unplugged or has no power.	Confirm the remote's compatibility with your device model. Ensure the device is properly connected to power.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	MME-LE2483SM-NP
Product Dimensions	17 x 5 x 1 cm
Item Weight	59 grams
Compatible Devices	IOP43QVDA, iRV42H3, iRV50U3, ND40S404M, iRV24H3, iRV32H3, LE2483SM, LE3283SM, LE4283SM, AV32H3, AV24H3, AV32D1, AV42F3-D1, RS65U2-EU
Special Feature	Ergonomic design
Connectivity Technology	Infrared (IR)
Maximum Range	10 Meters
Batteries Required	No (Batteries not included)

Warranty and Support

For any questions or support regarding your ALLIMITY remote control, please refer to the retailer or point of purchase. While specific warranty details are not provided in this manual, standard consumer rights and return policies apply. Ensure you have your product model number (MME-LE2483SM-NP) and purchase details ready when contacting support.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB5FBQK2

More documents and user manuals: **https://manuals.plus/**