Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vanshly FP-13DPA

Instruction Manual

Vanshly FP-13DPA 13-Cup Food Processor Pusher Assembly

Model: FP-13DPA

Introduction

This instruction manual provides essential information for the proper use, installation, and maintenance of your Vanshly 13-Cup Food Processor Pusher Assembly. This assembly is designed as a replacement part for specific Cuisinart food processor models, ensuring continued functionality and performance.



Image: The Vanshly 13-Cup Food Processor Pusher Assembly, showcasing its transparent design and components.

Compatibility

It is crucial to verify your food processor model before purchasing and using this pusher assembly. This part is specifically designed to fit the following Cuisinart models:

- FP-13DGM
- FP-13DSV
- CFP-26SVPC
- SFP-13
- FP-13DPA (as a direct replacement)

Note:

Even if your current push rod assembly appears similar, it may not be suitable unless it matches one of the specified compatible models. Always check your food processor's model number to ensure proper fit and function.



Image: Visual representation of the pusher assembly and its compatibility with various food processor models, demonstrating its use in processing ingredients.



Image: A close-up of the pusher assembly's base and a reminder to verify model compatibility before purchase, showing the pusher in use with a food processor.

Product Components

The Vanshly 13-Cup Food Processor Pusher Assembly includes three distinct sizes of push rods, designed to be assembled as needed for various food processing tasks:

- **Small Pusher (FP-13SP):** For smaller ingredients or when precise feeding is required.
- **Medium Pusher (FP-13MP):** A versatile size for general use.
- **Large Pusher (FP-13LP):** The main outer pusher, accommodating larger food items.



Image: The three individual components of the pusher assembly: small, medium, and large push rods, laid out to show their distinct sizes.

Installation and Assembly

The pusher assembly is designed for easy integration with your compatible food processor. Follow these steps for proper installation:

1. Ensure your food processor is unplugged and the work bowl and lid are securely in place.
2. Identify the appropriate pusher size for your task. The large pusher (FP-13LP) is the primary component that fits into the feed tube of the food processor lid.
3. If using, insert the medium pusher (FP-13MP) into the large pusher.
4. If using, insert the small pusher (FP-13SP) into the medium pusher.
5. Carefully insert the assembled pusher into the feed tube of your food processor lid. It should slide in smoothly and fit snugly.



Image: A visual guide demonstrating the step-by-step assembly of the small, medium, and large pushers, and how the complete assembly is inserted into the food processor's feed tube.

Operation

Once installed, the pusher assembly facilitates the safe and efficient feeding of ingredients into the food processor's blades. Always use the pusher when adding food through the feed tube to protect your hands and ensure even processing.

- Place ingredients into the feed tube.
- Use the appropriate size pusher to gently guide the food down towards the spinning blades.
- Apply steady, even pressure. Do not force food into the feed tube.
- For continuous processing, you may remove the smaller pushers to add more ingredients through the larger opening, then reinsert them as needed.

Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your pusher assembly and ensure hygienic food preparation.

- **Cleaning:** Hand wash recommended for all parts of the pusher assembly. Use warm, soapy water and a soft cloth or sponge. The smooth surface and specially designed plastic spots on the bottom assist in easy cleaning.
- **Drying:** Ensure all parts are thoroughly dry before storing to prevent water spots or potential bacterial growth.
- **Storage:** Store the pusher assembly in a clean, dry place, preferably with your food processor accessories.
- **Material:** Made from high-quality, safe, and healthy materials for long service life.

Troubleshooting

Most issues related to the pusher assembly can be resolved by ensuring proper compatibility and usage.

Problem	Possible Cause	Solution
Pusher does not fit into the feed tube.	Incompatible food processor model.	Verify your food processor model against the compatible models list (FP-13DGM, FP-13DSV, CFP-26SVPC, SFP-13, FP-13DPA). This pusher assembly is designed for specific models only.
Food is not processing evenly.	Incorrect pusher size used or uneven pressure.	Ensure you are using the appropriate pusher size for the ingredient. Apply gentle, consistent pressure to guide food evenly.
Pusher feels loose or wobbly.	Not fully inserted or incorrect assembly of nested pushers.	Ensure the pusher is fully seated in the feed tube. If using nested pushers, confirm they are correctly assembled and locked into each other.

Specifications

Attribute	Detail
Brand	Vanshly
Model Name	13-Cup Food Processor Pusher Assembly
Item Model Number	13-Cup Food Processor Pusher Assembly (FP-13DPA)
Color	Transparent
Blade Material	Plastic (for pusher, not actual blades)
Included Components	13-Cup Food Processor Pusher Assembly (Small, Medium, Large)
Item Weight	14 ounces
Package Dimensions	6.46 x 4.8 x 4.8 inches
Country of Origin	China



Image: Detailed measurements of the small, medium, and large pusher components, indicating their height and width for reference.

Warranty and Support

Vanshly is committed to providing high-quality products. While specific warranty details are not provided in this manual, if you encounter any problems during use, please contact the seller or manufacturer immediately for assistance. They are dedicated to providing quality service and support for their products.
For further inquiries or support, please refer to the contact information provided with your purchase or visit the official Vanshly brand page on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB8KMSVX

More documents and user manuals: **https://manuals.plus/**