Tineco A20 & iFLOOR 3 Breeze Complete

Tineco A20 Cordless Stick Vacuum Cleaner & iFLOOR 3 Breeze Complete Wet Dry Vacuum User Manual

Model: A20 & iFLOOR 3 Breeze Complete
Brand: Tineco

Introduction

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your Tineco A20 Cordless Stick Vacuum Cleaner and Tineco iFLOOR 3 Breeze Complete Wet Dry Vacuum. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Tineco A20 Cordless Stick Vacuum Cleaner (left) and the Tineco iFLOOR 3 Breeze Complete Wet Dry Vacuum (right), along with cleaning solutions and roller brushes.

Product Features

- **Versatile Cleaning Modes:** The Tineco A20 offers 3 modes (Normal, Mid, Max) to adjust suction power for various cleaning tasks, from light dust to heavy messes.



Image: Illustration of the Tineco A20's three cleaning modes (Eco, Med, Max) demonstrating their effectiveness on light dust, moderate debris, and heavy stains respectively.

- **Extended Runtime:** Enjoy up to 40 minutes of cordless operation, allowing for comprehensive whole-house cleaning on a single charge.



Image: A person using the Tineco A20 vacuum cleaner to clean a sofa, with an overlay indicating "40 minutes" runtime, highlighting its cordless convenience for extended cleaning sessions.

- **Large Capacity Dustbin:** The Tineco A20 features a 1L dustbin, 150% larger than the Tineco A10, reducing the frequency of emptying during cleaning.



Image: A comparison showing the larger 1L dustbin of the Tineco A20 compared to the Tineco A10, indicating a 150% increase in capacity.

- **Integrated Wet & Dry Cleaning:** The Tineco iFLOOR 3 Breeze Complete simultaneously vacuums and mops hard floors, streamlining your cleaning routine.



Image: A person operating the Tineco iFLOOR 3 Breeze Complete, demonstrating its function as a cordless vacuum and mop on a hard floor.

- **Efficient Drying:** The iFLOOR 3 Breeze Complete ensures floors are left completely dry and streak-free within minutes, with over 90% water recovery.



Image: A close-up of the Tineco iFLOOR 3 Breeze Complete cleaning a wet floor, illustrating its ability to provide fast, streak-free drying.

- **Ergonomic Design:** The dual-handle design of the A20 provides comfortable handling for both floor cleaning and elevated surfaces.



Image: Two images demonstrating the Tineco A20's ergonomic dual-handle design, showing its use for both floor cleaning and reaching high areas like curtains.

- **Multi-Surface Cleaning:** The iFLOOR 3 Breeze Complete is designed to clean multiple sealed hard floor types effectively.



Image: A top-down view of the Tineco iFLOOR 3 Breeze Complete cleaning head, surrounded by various types of sealed hard floors (wood, tile, marble) with different spills, illustrating its versatility.

Setup Instructions

Tineco A20 Cordless Stick Vacuum:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list are present.
2. **Assemble Main Body:** Connect the extension wand to the main motor body until it clicks into place.
3. **Attach Brush Head:** Attach the desired brush head (e.g., multi-tasker power brush) to the end of the extension wand, ensuring it locks securely.
4. **Charge Battery:** Before first use, fully charge the battery. Connect the charger to the charging dock and plug it into a power outlet. Place the vacuum on the charging dock. The indicator lights will show charging status.
5. **Install Dustbin:** Ensure the 1L dustbin is properly installed and secured on the main motor body.

Tineco iFLOOR 3 Breeze Complete Wet Dry Vacuum:

1. **Handle Assembly:** Insert the handle into the main body of the vacuum until it clicks securely.
2. **Fill Clean Water Tank:** Remove the clean water tank from the back of the unit. Fill it with clean water and, if desired, a small amount of Tineco cleaning solution (do not exceed the MAX line). Reattach the tank.
3. **Charge Battery:** Place the unit on its charging base and connect the power adapter. Ensure the unit is fully charged before initial use.
4. **Check Dirty Water Tank:** Ensure the dirty water tank is empty and properly installed before operation.

Operating Instructions

Tineco A20 Cordless Stick Vacuum:

1. **Power On/Off:** Press the power button to turn the vacuum on or off.
2. **Select Mode:** Use the mode selection button to cycle through Normal, Mid, and Max suction modes based on your cleaning needs.
3. **Start Cleaning:** Begin vacuuming. The LED headlights on the brush head will illuminate the cleaning path.
4. **Empty Dustbin:** When the dustbin is full, press the release button to detach it and empty contents into a trash receptacle.

Tineco iFLOOR 3 Breeze Complete Wet Dry Vacuum:

1. **Power On/Off:** Press the power button to start the wet/dry vacuum.
2. **Self-Propelled Movement:** The unit is designed to be self-propelled, making it easy to maneuver across floors.
3. **Cleaning Process:** Push the vacuum forward to dispense water and scrub, then pull it back to suction up the dirty water and dry the floor.
4. **Self-Cleaning Cycle:** After use, place the unit on the charging base and press the self-clean button to initiate the automatic cleaning cycle for the brush roll and internal tubing.
5. **Empty Dirty Water Tank:** After each use, or when full, remove and empty the dirty water tank. Rinse thoroughly.

Maintenance

Tineco A20 Cordless Stick Vacuum:

- **Dustbin Cleaning:** Empty the dustbin after each use. Wipe the interior with a damp cloth if necessary.
- **Filter Cleaning:** The HEPA filter should be cleaned regularly. Tap off loose debris, then rinse under cold running water. Allow to air dry completely for at least 24 hours before reinserting. Replace filter every 3-6 months depending on usage.
- **Brush Roll Maintenance:** Periodically remove the brush roll from the head and clear any tangled hair or debris using scissors or the cleaning tool provided.

Tineco iFLOOR 3 Breeze Complete Wet Dry Vacuum:

- **Dirty Water Tank:** Empty and rinse the dirty water tank after every use to prevent odors and bacterial growth.
- **Clean Water Tank:** Empty any remaining clean water if the unit will not be used for an extended period.
- **Brush Roll & Filter:** After the self-cleaning cycle, remove the brush roll and filter from the unit. Rinse them thoroughly under running water. Allow them to air dry completely before reassembling.
- **Charging Base:** Wipe down the charging base regularly to keep it clean.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged; Power button not pressed correctly.	Ensure battery is fully charged. Press the power button firmly.
Low suction power (A20).	Dustbin full; Filter clogged; Brush roll tangled.	Empty dustbin. Clean or replace filter. Clear brush roll of debris.
Water not dispensing (iFLOOR 3).	Clean water tank empty; Tank not installed correctly.	Fill clean water tank. Reinstall tank securely.
Streaks on floor (iFLOOR 3).	Dirty water tank full; Brush roll dirty; Too much cleaning solution.	Empty and rinse dirty water tank. Clean brush roll. Use recommended amount of cleaning solution.
Unusual noise.	Obstruction in brush roll or air path; Component not assembled correctly.	Check for and remove any obstructions. Reassemble components securely.

If the problem persists after attempting these solutions, please contact Tineco Customer Support.

Specifications

- **Brand:** Tineco
- **Model:** A20 & iFLOOR 3 Breeze Complete
- **Special Feature:** Bagless (A20)
- **Filter Type:** Cartridge
- **Included Components:** Charging Dock, Crevice Tool, Dusting Brush, Mop
- **Cordless:** Yes
- **Dustbin Capacity (A20):** 1 Liters
- **Runtime:** Up to 40 minutes
- **Form Factor:** Stick
- **Controller Type:** Push Button
- **Control Method:** App (for some models/features, general Tineco app)
- **Number of Speeds/Power Levels:** 3
- **Portable:** Yes
- **Indoor/Outdoor Usage:** Indoor
- **ASIN:** B0DBHQW334

Warranty and Support

Tineco products are designed for durability and performance. For warranty information, please refer to the warranty card included with your product or visit the official Tineco website. Keep your purchase receipt as proof of purchase for warranty claims.
For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Tineco Customer Service:

- **Website:** www.tineco.com
- **Email:** Refer to your product's specific support contact information.
- **Phone:** Refer to your product's specific support contact information.

When contacting support, please have your product model number (A20 / iFLOOR 3 Breeze Complete) and ASIN (B0DBHQW334) ready.

© 2023 Tineco. All rights reserved.
Tineco is a registered trademark.