Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TechBrix GS-X2Plus

TechBrix X2 Plus 4K HD Retro Game Stick User Manual

Model: GS-X2Plus

Introduction

The TechBrix X2 Plus 4K HD Retro Game Stick is a compact and powerful home video game console designed to bring back nostalgic gaming memories. Featuring HDMI output for connection to TVs, monitors, or projectors, this plug-and-play device comes with over 30,000 built-in retro games. It supports 50+ emulators, allowing access to a vast library of classic titles. The console system includes convenient functions such as game search, game collection, instant archive read, and pause capabilities. It is equipped with two 2.4G wireless controllers for an immersive gaming experience.

Package Contents

Please verify that all items listed below are included in your package:

- 1 x Game Stick
- 1 x USB Wireless Receiver
- 1 x Extension HDMI Cable
- 1 x USB Power Cable
- 1 x TF Card (pre-installed with games)
- 1 x User Manual (this document)
- 2 x 2.4G Wireless Controllers

Image: All components included in the TechBrix X2 Plus 4K HD Retro Game Stick package.

Setup Guide

1. **Connect the Game Stick:** Insert the Game Stick directly into an available HDMI port on your TV, monitor, or projector. If space is limited, use the included Extension HDMI Cable.
2. **Power the Game Stick:** Connect the USB Power Cable to the Game Stick's power input port and then to a USB power source (e.g., a TV USB port, a USB wall adapter, or a power bank). The Game Stick will power on automatically.
3. **Insert TF Card:** Ensure the TF card (pre-installed with games) is securely inserted into the TF card slot on the Game Stick.

4. **Connect Wireless Receiver:** Plug the USB Wireless Receiver into the USB port on the Game Stick.
5. **Prepare Controllers:** Insert two AAA batteries (not included) into each 2.4G Wireless Controller. Turn on the controllers. They should automatically pair with the Game Stick via the USB Wireless Receiver.
6. **Select HDMI Input:** Switch your TV or display's input source to the corresponding HDMI port where the Game Stick is connected. The system interface should appear on your screen.




Image: The Game Stick plugged into a television's HDMI port, ready for use with the wireless controllers.




Image: An overview of the Game Stick and controllers, highlighting its 4K Ultra HD capability when connected to a compatible display.

Operating Instructions

Navigating the System

Once powered on, the Game Stick will boot into its main interface. Use the D-pad and action buttons on your wireless controller to navigate through menus and select options.

- **Select/Start:** Typically used for confirming selections or starting games.
- **D-pad:** Used for directional navigation within menus and games.
- **Analog Sticks:** Used for movement in compatible games.

Playing Games

1. From the main menu, browse through the available game categories or use the search function to find a specific game.
2. Select the desired game and press the appropriate button (usually 'A' or 'X') to launch it.
3. During gameplay, you can typically access the system menu by pressing a combination of buttons (e.g., SELECT + START simultaneously). This menu allows you to save game progress, load states, pause the game, or exit back to the main menu.




Image: Demonstrates the use of the wireless controllers and the HDMI output capability of the Game Stick for an immersive gaming experience.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the Game Stick and controllers. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **TF Card Handling:** Always ensure the Game Stick is powered off before inserting or removing the TF card to prevent data corruption.
- **Battery Replacement:** Replace controller batteries when performance degrades. Dispose of used batteries responsibly.

Troubleshooting

Problem	Possible Solution
No signal on TV/monitor	Ensure the Game Stick is securely plugged into the HDMI port. Verify the TV input source is set to the correct HDMI port. Check if the USB Power Cable is properly connected and receiving power. Try a different HDMI port or cable.
Controllers not responding	Ensure fresh AAA batteries are installed correctly in both controllers. Verify the USB Wireless Receiver is firmly plugged into the Game Stick's USB port. Turn the controllers off and on again to re-establish connection.
Game freezes or crashes	Restart the Game Stick by unplugging and re-plugging the power cable. Ensure the TF card is properly inserted and not corrupted. Some older games or emulators may have compatibility issues.
Cannot save game progress	Ensure there is sufficient space on the TF card. Follow the in-game or system menu instructions for saving.

Specifications

Feature	Detail
CPU	GB6
Output	HDMI (4K HD compatible)
Operating System	Emuelec4.3
External TF Card Support	Expandable up to 256GB
Controller Frequency	2.4G Wireless
Controller Power	2 x AAA batteries per controller (not included)
Dimensions (Game Stick)	Approx. 8 x 6 x 6 inches (Product Dimensions)
Weight	Approx. 1.1 pounds
Material	Plastic
Model Number	GS-X2Plus

Image: The compact size of the Game Stick, highlighting its internal AI Game Chip and support for various game types.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Manufacturer warranty details are typically available on the official TechBrix website or through the seller from whom the product was acquired.

© 2024 TechBrix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBL5ZPM2

More documents and user manuals: **https://manuals.plus/**