ECONTROLLY RM-C1221

ECONTROLLY RM-C1221 Replacement Remote Control User Manual

For JVC TV DVD Combo Models: LT-19DE62, LT-19D610, LT-24DE73, LT-32DM21, LT-32D340, LT-22DM21, X-076R0SE01A, LT-32DM22, LT-19DE61, LT-19DM21, LT-22DE72, LT-32D210, J54A0721A, LT-32DE73, J54K0421A, LT-19D210

1. Introduction

This manual provides instructions for the ECONTROLLY RM-C1221 replacement remote control. This remote is designed to be compatible with various JVC TV DVD Combo models, offering a straightforward solution for controlling your device without the need for complex programming.

The RM-C1221 is an infrared remote control, pre-programmed for immediate use with the specified JVC models. Simply insert batteries, and it is ready to operate your compatible JVC TV DVD Combo unit.

Compatible JVC TV DVD Combo Models:

- LT-19DE62
- LT-19D610
- LT-24DE73
- LT-32DM21
- LT-32D340
- LT-22DM21
- X-076R0SE01A
- LT-32DM22
- LT-19DE61
- LT-19DM21
- LT-22DE72
- LT-32D210
- J54A0721A
- LT-32DE73
- J54K0421A
- LT-19D210




POWER
1
2
3
4
5
6
7
8
9
DISPLAY
SLEEP
0
TV/DVD
MUTING
AUDIO
ANGLE
CCD/ JUMP
SCREEN SIZE
INPUT SELECT
VOL
REPEAT A-B
RECALL/ZOOM
RETURN
MARKER
SUBTITLE
ENTER
SETUP/ TV MENU
EXIT/ CANCEL
SKIP
SKIP
SEARCH
SEARCH
PAUSE/STILL
PLAY
STOP
PLAY MODE
SLOW
SLOW
DVD MENU
TOP MENU
CH
VOL



Image: Front view of the ECONTROLLY RM-C1221 replacement remote control, showing all buttons and their labels.

2. Setup

Battery Installation

The remote control requires AAA ALKALINE batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA ALKALINE batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Do not use rechargeable batteries. Only use AAA ALKALINE batteries for optimal performance and to prevent potential damage.

3. Operating Instructions

The ECONTROLLY RM-C1221 remote control is designed for intuitive use. Point the remote directly at your JVC TV DVD Combo unit for best signal transmission.

Key Functions:

- **POWER:** Turns the TV DVD Combo unit on or off.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **TV/DVD:** Switches between TV and DVD modes.
- **Muting:** Mutes or unmutes the audio.
- **AUDIO:** Selects audio tracks or modes.
- **ANGLE:** Changes the viewing angle during DVD playback (if supported by the disc).
- **VOL +/-:** Adjusts the volume level.
- **INPUT SELECT:** Cycles through available input sources (e.g., HDMI, AV).
- **Navigation Pad (Up, Down, Left, Right, ENTER):** Navigates menus and confirms selections.
- **SETUP/TV MENU:** Accesses the system setup or TV menu.
- **EXIT/CANCEL:** Exits menus or cancels current operations.
- **PLAY, PAUSE/STILL, STOP, SKIP, SEARCH:** Standard DVD playback controls.
- **CH +/-:** Changes channels.
- **DVD MENU:** Accesses the main menu of a DVD.
- **TOP MENU:** Accesses the top menu of a DVD.
- **SUBTITLE:** Toggles or selects subtitle options.
- **DISPLAY:** Shows on-screen information.



Image: Angled view of the ECONTROLLY RM-C1221 remote control, highlighting the ergonomic design and button layout.

4. Maintenance

Cleaning and Care

- To clean the remote control, gently wipe it with a soft, dry cloth.
- Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the surface or internal components.
- Avoid exposing the remote control to extreme temperatures, direct sunlight, or high humidity.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

5. Troubleshooting

Common Issues and Solutions:

- **Remote control is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA ALKALINE batteries.
  - Check for any obstructions between the remote control and the JVC TV DVD Combo unit's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the device.
- **Specific buttons are not working:**
  - This remote is pre-programmed for JVC TV DVD Combo units. Ensure your device is one of the compatible models listed in the introduction.
  - Some functions may be specific to certain JVC models or DVD content.

6. Specifications

Model:	RM-C1221
Brand:	ECONTROLLY
Product Dimensions:	3.94 x 1.57 x 0.59 inches (10 x 4 x 1.5 cm)
Item Weight:	1.76 ounces (50 grams)
Color:	Black
Special Feature:	Pre-Programmed (Infrared)
Max Number of Supported Devices:	1
Compatible Devices:	JVC TV DVD Combo units (specific models listed in Introduction)
Power Source:	2 x AAA ALKALINE batteries (not included)





Image: Front view of the ECONTROLLY RM-C1221 remote control, illustrating its physical dimensions.

7. Warranty and Support

Specific warranty information for the ECONTROLLY RM-C1221 replacement remote control is not provided in the product details. For any warranty-related inquiries or technical support, please contact the seller or manufacturer directly through your purchase platform.

When contacting support, please have your purchase details and the product model number (RM-C1221) readily

available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question