Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PRETTYCARELIFE W400

PRETTYCARELIFE W400 Cordless Vacuum Cleaner Instruction Manual

Model: W400

1. Product Overview

The PRETTYCARELIFE Cordless Vacuum Cleaner (Model W400) is a versatile 6-in-1 cleaning device designed for efficient home maintenance. It features a lightweight, self-standing design, powerful suction, and a 180° bendable wand for enhanced maneuverability. This rechargeable stick vacuum is suitable for various floor types, including hardwood and carpet, providing a convenient and effective cleaning solution.



Figure 1: PRETTYCARELIFE W400 Cordless Vacuum Cleaner showcasing its 6-in-1 versatility and various attachments.

2. What's Included

Verify that all components are present in the packaging:

- LED Roller Brush
- Cordless Vacuum (Main Unit)
- 2-in-1 Dust Brush
- Wall Mount
- Adapter
- Long Crevice Tool
- Filter * 2 (one pre-installed, one spare)

- Foldable Metal Tube



Figure 2: All components included with the PRETTYCARELIFE W400 Cordless Vacuum Cleaner.

3. Setup

3.1 Assembly

1. Attach the **Foldable Metal Tube** to the main **Cordless Vacuum Unit** by aligning the connectors and pushing until it clicks securely into place.
2. Connect the **LED Roller Brush** to the other end of the **Foldable Metal Tube**, ensuring it clicks firmly.
3. For handheld use, attach desired accessories (e.g., **2-in-1 Dust Brush** or **Long Crevice Tool**) directly to the main **Cordless Vacuum Unit** or the **Foldable Metal Tube**.

3.2 Charging

Before first use, fully charge the vacuum cleaner.

1. Connect the **Adapter** to the charging port on the main **Cordless Vacuum Unit**.
2. Plug the **Adapter** into a standard wall outlet.
3. The battery indicator lights on the main unit will illuminate to show charging status. A full charge is indicated when all lights are solid green.

3.3 Wall Mount Installation (Optional)

To save space and keep your vacuum accessible, you can install the provided wall mount.

1. Choose a suitable location on a wall, ensuring it's near a power outlet if you plan to charge while mounted.
2. Use the provided screws and wall anchors to securely fasten the **Wall Mount** to the wall.
3. Hang the main **Cordless Vacuum Unit** onto the wall mount.

---

4. Operating Instructions

4.1 Power On/Off and Suction Modes

1. Press the **Power Button** on the main unit to turn the vacuum cleaner on.
2. The vacuum will start in the default (minimum) suction mode.
3. Press the **Max/Min Button** to toggle between minimum and maximum suction power as needed for different cleaning tasks.
4. Press the **Power Button** again to turn the vacuum cleaner off.

4.2 Using the Bendable Wand and LED Headlights

The 180° bendable wand allows for easy cleaning under low-lying furniture without excessive bending.

- To activate the bendable feature, press the release button on the foldable metal tube and adjust the angle.
- The **LED Headlights** on the roller brush automatically illuminate the cleaning path, making dust and debris visible in dimly lit areas.



Figure 3: The 180° bendable wand facilitates cleaning under furniture.



Figure 4: Flexible adjustment and LED headlights for improved visibility.

4.3 Using Attachments

- The **2-in-1 Dust Brush** is ideal for cleaning upholstery, curtains, and delicate surfaces.
- The **Long Crevice Tool** is designed to reach narrow gaps, corners, and tight spaces in your home or car.

4.4 Self-Standing Design

The vacuum features a self-standing design, allowing it to remain upright on its own when not in use or during temporary pauses in cleaning, eliminating the need for a wall mount or leaning against furniture.



Figure 5: The self-standing design offers convenient storage and temporary placement.

5. Maintenance

5.1 Emptying the Dustbin

1. Ensure the vacuum is turned off.
2. Locate the dustbin release button on the main unit.
3. Press the button to open the bottom flap of the dustbin and empty its contents into a trash receptacle.

5.2 Cleaning Filters

Regularly clean the filters to maintain optimal suction performance.

1. Twist and remove the dustbin from the main unit.
2. Carefully remove the **HEPA Filter** and **Stainless Steel Filter** from the dustbin.

3. Rinse both filters under running water until clean. Do not use detergent.
4. Allow the filters to air dry completely for at least 24 hours before reinserting them into the dustbin. Ensure they are completely dry to prevent damage to the motor.
5. Reassemble the filters and dustbin, then attach the dustbin back to the main unit.



Figure 6: Components of the 6-Stage & Double Cyclone Filtration System.

5.3 Cleaning the Roller Brush

To prevent tangles and maintain effective cleaning, periodically clean the roller brush.

1. Ensure the vacuum is turned off.
2. Locate the release mechanism on the side of the**LED Roller Brush** head.
3. Unlock and remove the roller brush.
4. Use scissors or the provided cleaning tool to cut and remove any tangled hair or debris from the brush.
5. Reinsert the clean roller brush and lock it into place.

6. Troubleshooting

- **No Power:** Check if the battery is charged. Ensure the adapter is properly connected during charging.
- **Reduced Suction:** Empty the dustbin if full. Clean the HEPA and stainless steel filters. Check the foldable metal tube and roller brush for any blockages.
- **Roller Brush Not Spinning:** Turn off the vacuum and check for tangled hair or debris obstructing the roller. Ensure the roller brush is correctly inserted and locked.

7. Specifications

Brand	PRETTYCARELIFE
Model Number	W400
Special Feature	Cordless, Foldable, HEPA, Lightweight
Filter Type	HEPA Filter
Maximum Suction	187.5 Inches (25Kpa)
Form Factor	Stick
Product Dimensions	40.6"L x 8.2"W x 9.9"H
Battery Type	Lithium-Ion (1 included)
Controller Type	Push Button
Motor Horsepower	2.01 horsepower
Number of Speeds	2
Item Weight	3 pounds

8. Warranty and Support

For warranty information, technical support, or any product-related inquiries, please refer to the contact information provided in your product packaging or visit the official PRETTYCARELIFE website. Some customers have reported up to 2 years of technical support availability.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBM1BYLY

More documents and user manuals: **https://manuals.plus/**