Tnfeeon B0DBM2392Y

Tnfeeon 8-in-1 Sandwich Maker Panini Press Instruction Manual

1. Product Overview

The Tnfeeon 8-in-1 Sandwich Maker Panini Press is a versatile kitchen appliance designed for preparing a variety of breakfast and snack items. It features a rapid heating system and double-sided cooking for efficient food preparation. The appliance includes 14 removable, interchangeable cooking plates, allowing for the creation of sandwiches, waffles, donuts, nuts, cookies, steaks, hot dogs, and madeleine cakes. Its non-stick surfaces and removable plates ensure easy cleaning and maintenance.



Image: Tnfeeon 8-in-1 Sandwich Maker with grill plates.

2. Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance body in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use the appliance for other than intended use.

3. Product Components and Dimensions

The appliance consists of the main unit and 14 interchangeable cooking plates. The main unit features a non-slip handle, stable chassis, and LED indicator lights for power and readiness.



Image: Product dimensions and a single cooking plate.

Interchangeable Cooking Plates:

The set includes 14 plates, offering a variety of cooking options:

- Sandwich Plates
- Waffle Plates
- Donut Plates
- Nut Plates
- Cookie Plates
- Baking Tray (for steaks and other items)
- Hot Dog Plates
- Madeleine Cake Plates




Image: Examples of Sandwich, Waffle, Donut, and Hot Dog plates and their culinary results.



Image: Examples of Cookie, Baking Tray (Steak), Walnut, and Madeleine Cake plates and their culinary results.

4. Setup

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.

2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash all removable cooking plates with warm, soapy water, rinse thoroughly, and dry completely. Do not immerse the main unit in water.
3. **Insert Plates:** Select the desired cooking plates. Align the plates with the slots on the top and bottom heating elements and press down until they click securely into place. Ensure both plates are firmly seated.
4. **Position:** Place the appliance on a stable, heat-resistant, and dry surface, away from walls or other heat-sensitive objects.
5. **Connect Power:** The appliance is designed for plug-and-play operation. Ensure the voltage matches your power supply (US Plug 110V).

5. Operating Instructions

The appliance features a rapid heating system and dual-sided cooking for efficient results.



Image: Quick heating system illustration.

1. **Preheat:** Close the lid and plug the appliance into a 110V power outlet. The red indicator light will illuminate, indicating power is on. The appliance will begin to preheat.
2. **Ready Indicator:** Once the appliance reaches the optimal cooking temperature, the green indicator light will illuminate, signaling that it is ready for use. This typically takes a few minutes.
3. **Prepare Food:** Open the lid. Lightly grease the cooking plates with a small amount of cooking oil or butter, if desired, especially for the first use or for recipes that tend to stick.
4. **Add Ingredients:** Place your ingredients onto the bottom cooking plate. Do not overfill, as this may cause overflow and uneven cooking.
5. **Cook:** Carefully close the lid. The appliance will cook the food from both sides simultaneously. The green indicator light may cycle on and off during cooking to maintain temperature.
6. **Monitor Cooking:** Cooking times will vary depending on the type of food and desired doneness. Refer to specific recipes for guidance.

7. **Remove Food:** Once cooked, open the lid and carefully remove the food using a heat-resistant plastic or wooden utensil. Do not use metal utensils, as they can damage the non-stick coating.
8. **Unplug:** After use, unplug the appliance from the power outlet and allow it to cool completely before cleaning.




Image: Three-step cooking process.



Image: LED indicators and other features.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Remove Plates:** Press the plate release buttons (if applicable) and carefully lift the cooking plates from the heating elements.
3. **Clean Plates:** Wash the removable cooking plates in warm, soapy water. For stubborn residue, soak the plates for a few minutes before cleaning. Use a soft sponge or cloth. Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating. Rinse thoroughly and dry completely. The plates are not dishwasher safe.
4. **Clean Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners. Never immerse the main unit in water or any other liquid.
5. **Storage:** Once clean and dry, store the appliance with the plates installed or separately in a dry, safe place.



Image: Demonstrating easy cleaning of the non-stick plates.

7. Troubleshooting

If you encounter issues with your appliance, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in; power outlet malfunction; internal fault.	Ensure the appliance is securely plugged into a working 110V outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food sticks to the plates.	Plates not properly greased; residue buildup; damaged non-stick coating.	Lightly grease plates before each use. Ensure plates are thoroughly cleaned after each use. Avoid using metal utensils.
Green 'Ready' light does not illuminate.	Appliance not fully preheated; sensor malfunction.	Allow sufficient time for preheating (typically a few minutes). If the light never illuminates after an extended period, contact customer support.

Problem	Possible Cause	Solution
Uneven cooking.	Uneven distribution of ingredients; plates not properly seated.	Distribute ingredients evenly across the cooking surface. Ensure both top and bottom plates are securely clicked into place.

8. Specifications

Feature	Detail
Brand	Tnfeeon
Model	B0DBM2392Y
Special Feature	Dual Zone Cooking
Style	Modern
Material Type Free	Lead Free
Appliance Size (Approx.)	24 cm x 24 cm (9.4 in x 9.4 in)
Voltage	110V (US Plug)
Removable Plates	14 (for 8 different food types)