Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RC5118

Azwok RC5118 Replacement Remote Control User Manual

Model: RC5118

Introduction

This manual provides comprehensive instructions for the Azwok RC5118 replacement remote control. It is designed to function as a direct replacement for the original RC5118 remote, compatible with a wide range of Hitachi, Bush, Teac, Haier, and Finlux Smart TV models. No programming is required; simply insert batteries for immediate use.

Product Overview

The Azwok RC5118 remote control features a standard layout with dedicated buttons for common TV functions and popular streaming services.





Image Description: A full view of the Azwok RC5118 replacement remote control. The remote is black with white and colored buttons. Key features visible include a power button, source input, number pad, navigation cluster with OK button, volume and channel controls, and dedicated buttons for Netflix and YouTube. The model number "RC5118" is printed at the bottom.

Setup

1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

2. Initial Use

The Azwok RC5118 remote control is pre-programmed and does not require any setup or code entry. Once batteries are installed, it is ready for immediate use with compatible televisions.

Operating Instructions

This section details the functions of the buttons on your RC5118 remote control.

Top Section Buttons

- **Power (Red Circle with Line)**: Turns the television on or off.
- **SOURCE**: Selects the input source (e.g., HDMI 1, AV, TV).
- **YouTube**: Direct access to the YouTube application.
- **NETFLIX**: Direct access to the Netflix application.
- **Mute (Speaker with Cross)**: Mutes or unmutes the television audio.
- **Media Controls (Play, Pause, Stop, Fast Forward, Rewind)**: Controls media playback.
- **LANG.**: Changes audio language or subtitle options.

Number Pad and Color Buttons

- **0-9 (Number Buttons)**: Enters channel numbers or numerical input.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functions vary depending on the TV menu or application.

Navigation and Menu Controls

- **TV**: Switches to TV mode.
- **MENU**: Opens the main menu of the television.
- **Q.MENU (Quick Menu)**: Accesses quick settings or frequently used options.
- **Navigation Arrows (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections or enters sub-menus.
- **P+ / P- (Channel Up / Down)**: Changes television channels.
- **V+ / V- (Volume Up / Down)**: Adjusts the television volume.
- **BACK**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or application.

Additional Function Buttons

- **Information (i)**: Displays program information.
- **Text (Square with lines)**: Accesses teletext or digital text services.
- **Subtitle (Square with dots)**: Toggles subtitles.
- **Star/Circle, Star/Q, List, TV Screen**: These buttons may have specific functions depending on the TV model, often related to smart features, favorites, or input selection. Refer to your TV's manual for exact functionality.

Compatibility

The Azwok RC5118 remote control is compatible with various Smart TV models from Hitachi, Bush, Teac, Haier, and Finlux. A partial list of known compatible models includes:

- **Hitachi:** LC-32HG5141K, LC-32HG5341K, LC-40UG7252K, LC-40UI7352E, LC-43CFG6002E, LC-43FG5242E, LC-50UI7422E, LC-40FG5342E, LC-40UG7242K, LC-40UI7552K, LC-43CFG6001K, LC-49CFG6001E, LC-49CFG6001K, LC-40FG5242E, LC-40UG7252E, 32-FFA-5615, 32-FFA-5650, 32-FHA-5511, 32HPD274BT, 32HPD274B-T, 40-FFA-5511, 40FLSMR277BC, 40FPD274BT, 40FP.D274BD27-T, 43-FFA-5615, 43FUA-8050, 43FUA-8060, 43UT3E310BT, 43UT3E310B-T, 43UXE310B-P, 48-FFA-5500, 48UXE304B-P, 49UT3E310BT, 49UT3E399UT10B-T, 50FLHMR249BCM, 50FPD274BT, 50FPD274B-T, 55-FFA-5515, 55-FUA-8020, 55UT3E310BT, 55UT3E310B-T, 55UT3EC320ST, 55UT3EC320S-T, 55UX3EC55UX320ST, 55UX3EC320S-T, 65FLHYR249BHC, 65FME249B-T, 65FME249ST, 65FME249S-T, 65UT3E249BT, 65UT3E249B-T
- **Finlux:** FIN32BASEHD, FIN48BASEBK, FIN5SMART4K, FIN55SM.ARTBK
- **Other Brands (Generic Models):** DLED44448265FHDCNTD, LED32127HDCNTD, DLED32265HDCNTD,

DLED50273FHDCNTD, ELED32240HDCNTD3D, ELED42240FHDCNTD3D, LED40127FHDCNTD, ELED50240FHDCNTD3D, ELED22134F.HDDVDCDCNTD, LED24265DVDCNTD, CELED32S0716B3-2, CELED3D65ML3, CELED55K0416B3, CELED55B3, CELED55CURV3D3, CELED32S0716B3, CELED483DMLA3, CELED32S0716B, CELED403DMLEDLEDLEDLA3, 650116B29, CEDLED50SX3, CELED32S0716B3-2, LDF50V500S, U65H7100, Edenwood ED4300FHD, ED3202HD, LCD32880HDF

If your specific TV model is not listed, or if your original remote differs significantly, please contact customer support for compatibility verification.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote, gently wipe the surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.

Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the TV's infrared sensor. Obstructions can block the signal.
- **Distance:** Operate the remote within the effective range of your television.
- **TV Sensor:** Verify that the TV's remote sensor is not blocked or dirty.

Specific Buttons Not Working

- If only certain buttons are unresponsive, try replacing the batteries first. If the issue persists, the remote may be faulty.

Still Not Working?

If troubleshooting steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

Specifications

Feature	Detail
Model Number	RC5118 (RM-RC5118-HT004)
Product Dimensions	9.84 x 1.97 x 0.79 inches (25 x 5 x 2 cm)
Item Weight	4.1 ounces (116 grams)
Connectivity Technology	Infrared (IR)

Max Number of Supported Devices	1 (Television)
Special Feature	No Programming Required

Warranty and Support

Warranty Information

This Azwok RC5118 replacement remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, compatibility inquiries, or warranty claims, please contact Azwok customer support through the retailer where the product was purchased. Provide your product model number (RC5118) and a detailed description of the issue.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBR527BJ

More documents and user manuals: **https://manuals.plus/**