ELECTCOM PRO RC-URC

ELECTCOM PRO DVD Player Remote Control User Manual

Model: RC-URC

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your ELECTCOM PRO DVD Player Remote Control. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.



Figure 1: ELECTCOM PRO DVD Player Remote Control. This image displays the black remote control, showcasing its full array of buttons including the numeric keypad, navigation controls, playback functions, and volume adjustments.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.

3. Operating Instructions

This section details the functions of each button on your ELECTCOM PRO DVD Player Remote Control.

3.1 Power and Numeric Buttons

- **Power Button (Red)**: Turns the DVD player on or off.
- **Numeric Buttons (0-9)**: Used to directly select track numbers, chapters, or input numerical values.
- **0/10+ Button**: For entering numbers greater than 9 or selecting track 0.
- **GOTO Button**: Allows direct navigation to a specific time, chapter, or track.

3.2 Navigation and Menu Controls

- **Directional Arrows (Up, Down, Left, Right)**: Navigate through menus and options.
- **ENTER Button**: Confirms selections or enters a menu item.
- **MENU Button**: Accesses the main menu of the DVD.
- **TITLE Button**: Returns to the disc's title menu.
- **SETUP Button**: Enters the system setup menu of the DVD player.
- **OSD (On-Screen Display) Button**: Toggles on-screen display information.

3.3 Playback Controls

- **Play/Pause Button (►▮▮)**: Toggles between play and pause modes.
- **STOP Button (■)**: Stops playback.
- **PREV (Previous) Button (◄◄)**: Skips to the beginning of the previous track/chapter.
- **NEXT Button (►►)**: Skips to the beginning of the next track/chapter.
- **REWIND Button (◄◄◄)**: Rewinds playback.
- **FORWARD Button (►►►)**: Fast forwards playback.
- **SLOW Button**: Activates slow-motion playback.
- **REPEAT Button**: Repeats the current track, chapter, or entire disc.

3.4 Audio and Video Controls

- **VOL+ Button**: Increases volume.
- **VOL- Button**: Decreases volume.

- **MUTE Button**: Mutes or unmutes the audio output.
- **SUBTITLE Button**: Cycles through available subtitle languages.
- **ANGLE Button**: Changes the camera angle on compatible DVDs.
- **LANGUAGE Button**: Cycles through available audio languages.
- **ZOOM Button**: Zooms in or out on the video display.
- **HD Button**: Likely related to High Definition output settings (specific function may vary by DVD player model).
- **L/R Button**: Adjusts left/right audio channels or stereo/mono output.
- **A-B Button**: Repeats a specific segment between point A and point B.
- **N/P Button**: Toggles between NTSC and PAL video output formats.
- **PROG Button**: Accesses program playback mode.
- **CD RIPPING Button**: Initiates CD ripping function (if supported by the DVD player).
- **DISC/USB Button**: Switches input source between disc and USB (if supported by the DVD player).

4. Maintenance

4.1 Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

4.2 Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the DVD player's infrared sensor.
  - Make sure you are within the effective operating range (typically up to 20 feet or 6 meters) and pointing the remote directly at the DVD player.
- **Buttons Not Working:**
  - Clean the remote control surface, especially around the buttons, to remove any dirt or debris that might be preventing proper contact.
  - If only specific buttons are not working, it might indicate internal damage.

If the problem persists after trying these steps, please contact customer support.

6. Specifications

Feature	Detail
Brand	ELECTCOM PRO
Model Number	RC-URC
Compatible Devices	ELECTCOM PRO DVD Player
Max Number of Supported Devices	1
Color	Black
Item Weight	2.12 ounces
Package Dimensions	7.64 x 2.17 x 1.14 inches
Manufacturer	ELECTCOM PRO
Country of Origin	China
ASIN	B0DBTWYL5J
Date First Available	May 1, 2023

7. Warranty and Support

This remote control is designed for reliable performance. For specific warranty information, please refer to the documentation provided with your ELECTCOM PRO DVD Player or contact the manufacturer directly.

Customer Support

If you have any questions, require technical assistance, or encounter issues not covered in this manual, please contact ELECTCOM PRO customer support. Refer to the contact information provided with your original product purchase or visit the official ELECTCOM PRO website for support details.
When contacting support, please have your product model number (RC-URC) and ASIN (B0DBTWYL5J) ready.

© 2023 ELECTCOM PRO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question