TP-Link Archer NX200

TP-Link Archer NX200 5G Wi-Fi 6 AX1800 Router User Manual

Model: Archer NX200

Introduction

Welcome to the user manual for your TP-Link Archer NX200 5G Wi-Fi 6 AX1800 Router. This guide provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and a seamless internet experience.

The Archer NX200 is designed to provide high-speed 5G connectivity and advanced Wi-Fi 6 technology, offering robust and reliable internet access for your home or office. Its dual-band capabilities and EasyMesh support ensure wide coverage and stable connections across multiple devices.

Product Overview



Figure 1: TP-Link Archer NX200 Router and Packaging

The TP-Link Archer NX200 is a versatile 5G Wi-Fi 6 router, offering a range of features for modern connectivity needs:

- **5G Connectivity Support:** Connect your home using advanced 5G connectivity with download speeds up to 4.6 Gbps, sharing the network with multiple Wi-Fi devices.
- **Wi-Fi 6 AX1800:** Delivers speeds up to 1201Mbps on the 5GHz band and 574Mbps on the 2.4GHz band for efficient data transfer.
- **Plug & Play:** Simply insert a SIM card to get connected instantly.
- **EasyMesh Support:** Expand your Wi-Fi by adding an EasyMesh-compatible extender for seamless whole-home coverage.
- **Gigabit WAN/LAN Port:** The gigabit WAN/LAN port allows the NX200 to function as a traditional wireless router, compatible with cable, fiber, and DSL modems.



Figure 2: Archer NX200 highlighting 5G, Wi-Fi 6, and EasyMesh capabilities.

Setup Guide

1. Package Contents

Before you begin, ensure all items are present in the box:

- 5G AX1800 Wireless Dual-Band Gigabit Router Archer NX200
- 1.5m Power Adapter
- RJ45 Ethernet Cable
- Quick Installation Guide

2. Hardware Installation

1. **Insert SIM Card:** Locate the SIM card slot on the bottom of the Archer NX200. Gently insert your Nano SIM card until it clicks into place. Ensure the SIM card is correctly oriented as indicated by the diagram near the slot.



Figure 3: SIM Card Insertion

2. **Connect Power:** Connect the provided power adapter to the router's power port and plug the other end into a power outlet. The router will automatically power on.
3. **Optional - Ethernet Connection:** If you wish to connect a device directly via Ethernet, use the RJ45 Ethernet cable to connect your device (e.g., PC, game console) to one of the LAN ports on the back of the router.



Figure 4: Rear Panel with Ports

4. **Optional - WAN Connection:** If using the router with a traditional modem (cable, fiber, DSL), connect the modem's Ethernet cable to the WAN/LAN port on the Archer NX200.



Figure 5: WAN Connection Diagram

3. Initial Configuration (via TP-Link Tether App)

The easiest way to set up your Archer NX200 is using the TP-Link Tether app:

1. **Download Tether App:** Search for "TP-Link Tether" in the Apple App Store or Google Play Store and install the app on your smartphone.
2. **Connect to Router's Wi-Fi:** On your smartphone, connect to the default Wi-Fi network broadcast by the Archer NX200. The default Wi-Fi name (SSID) and password are printed on the label at the bottom of the router.
3. **Launch Tether App:** Open the Tether app. It should automatically detect your Archer NX200. Follow the on-screen instructions to create a TP-Link ID (if you don't have one) and configure your router's settings, including Wi-Fi name, password, and internet connection type.
4. **Complete Setup:** The app will guide you through the remaining steps, including setting up administrator password and checking for firmware updates.



Figure 6: TP-Link Tether App for Easy Setup

Operating Instructions

Wi-Fi Connectivity

The Archer NX200 broadcasts two Wi-Fi bands: 2.4GHz and 5GHz. You can connect your devices to either band based on your needs. The 5GHz band offers faster speeds over shorter distances, while the 2.4GHz band provides better coverage over longer distances and through obstacles.

- **Connecting Devices:** On your device (smartphone, laptop, tablet), search for available Wi-Fi networks. Select your router's Wi-Fi name (SSID) and enter the password you set during the initial configuration.
- **Guest Network:** For enhanced security, you can enable a separate guest network via the Tether app or web interface. This allows guests to access the internet without accessing your main network resources.

EasyMesh Functionality

The Archer NX200 supports EasyMesh, allowing you to create a unified whole-home mesh Wi-Fi system by adding compatible TP-Link EasyMesh extenders. This eliminates Wi-Fi dead zones and provides seamless roaming throughout your home.

1. **Adding an EasyMesh Extender:** Refer to the Quick Installation Guide of your EasyMesh extender for specific pairing instructions. Generally, you will power on the extender near the router and press the WPS button on both devices to establish a connection.
2. **Seamless Roaming:** Once connected, your devices will automatically switch to the strongest Wi-Fi signal as you move around your home, ensuring an uninterrupted connection.



Figure 7: EasyMesh Whole-Home Wi-Fi

5G/4G LTE Internet Access

The router automatically detects the inserted SIM card and connects to the 5G/4G LTE network. The LED indicators on the front panel will show the connection status.

- **Signal Strength:** The signal strength indicator on the router and in the Tether app will show the quality of your 5G/4G LTE connection. For best performance, place the router in an area with strong cellular signal.
- **Data Usage Monitoring:** Use the Tether app to monitor your data usage, which is particularly useful if your SIM plan has data limits.

Maintenance

- **Firmware Updates:** Regularly check for and install firmware updates via the Tether app or the router's web management interface. Updates often include performance improvements, security patches, and new features.
- **Placement:** Place the router in a central location, away from obstructions and sources of interference (e.g., microwaves, cordless phones). Ensure adequate ventilation to prevent overheating.
- **Cleaning:** Keep the router clean and free of dust. Use a soft, dry cloth for cleaning. Do not use liquid cleaners or aerosols.
- **Rebooting:** If you experience connectivity issues, try rebooting the router by unplugging the power adapter for 10 seconds and then plugging it back in.

Troubleshooting

Problem	Possible Solution
No Internet connection after SIM insertion.	• Ensure the SIM card is correctly inserted and activated with your mobile operator. • Check the router's LED indicators for cellular signal status. • Verify APN settings in the router's web interface or Tether app (usually auto-detected, but manual entry may be needed for some operators). • Reboot the router.

Problem	Possible Solution
Slow Wi-Fi speeds.	• Ensure your device is connected to the 5GHz band if possible. • Reduce distance between device and router, and remove obstructions. • Check for Wi-Fi interference from other devices. • Update router firmware.
Router frequently disconnects or freezes.	• Ensure adequate ventilation to prevent overheating. • Check for the latest firmware updates. • Try a factory reset (refer to the Quick Installation Guide for button location and procedure).
Cannot access router's web management page.	• Ensure your device is connected to the router's Wi-Fi or via Ethernet. • Verify the correct IP address (default is usually 192.168.1.1 or tplinkwifi.net). • Clear your browser's cache or try a different browser.

Specifications

Feature	Detail
Brand	TP-Link
Model Name	Archer NX200
Wireless Type	802.11ax (Wi-Fi 6)
Frequency Band Class	Dual Band (2.4 GHz & 5 GHz)
5G Connectivity Speed	Up to 4.6 Gbps (theoretical)
Wi-Fi Speed (5GHz)	1201 Mbps
Wi-Fi Speed (2.4GHz)	574 Mbps
Ethernet Ports	3 (including 1 WAN/LAN Gigabit port)
Dimensions	9.9 x 19 x 9.9 cm
Weight	610 grams
Operating System	TP-Link OS
Special Features	Internet Security, Remote Access, EasyMesh
Compatible Devices	PC, Smartphone

Warranty and Support

TP-Link products come with a limited warranty. Please refer to the warranty card included in your product packaging or

visit the official TP-Link website for detailed warranty terms and conditions specific to your region.
For technical support, product registration, and additional resources, please visit the TP-Link support website:

TP-Link Official Support

You can also utilize the TP-Link Tether app for quick access to support resources and frequently asked questions.

© 2024 TP-Link. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question