Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

H.Koenig FRY900

H.Koenig FRY900 XXL Dual Basket Air Fryer Instruction Manual

Model: FRY900

1. Important Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the appliance on a stable, heat-resistant surface, away from walls and other appliances.
- Do not immerse the cord, plug, or the appliance housing in water or other liquids to prevent electric shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the appliance manufacturer, as this may cause injuries.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for anything other than its intended use.
- Ensure the baskets are properly inserted before operation.
- Hot air is released through the air outlet vents. Keep your hands and face at a safe distance from the vents.
- Do not cover the air inlet or outlet vents while the appliance is operating.

2. Product Overview

The H.Koenig FRY900 is an XXL dual basket air fryer designed for healthy, oil-free cooking. It features two independent 4.5L baskets, allowing you to cook different foods simultaneously with separate settings or synchronized finishes.

2.1 Key Features

- **Dual Basket Design:** Two 4.5L baskets for a total capacity of 9L.
- **Wide Temperature Range:** Adjustable from 80°C to 200°C.

- **Digital Touch Screen:** Intuitive control panel for easy operation.
- **8 Pre-set Programs:** Optimized settings for various dishes.
- **60-Minute Timer:** With automatic shut-off and audible alert.
- **SYNC & MATCH Functions:** Synchronize cooking times or settings across both baskets.
- **Easy Cleaning:** Removable, dishwasher-safe grids.
- **Powerful Performance:** 2400W for fast and even cooking.

2.2 Appliance Components



Figure 1: Top-down view of the H.Koenig FRY900 Air Fryer, showing the two cooking baskets and the digital control panel on top.



Figure 2: Front view of the H.Koenig FRY900 Air Fryer, highlighting the touch screen control panel and the handles of the two cooking baskets.

Control Panel Layout:

- **Power Button:** Turns the appliance on/off.
- **Time Controls (+/-):** Adjust cooking time.
- **Temperature Controls (+/-):** Adjust cooking temperature.
- **Basket Select (1/2):** Selects which basket to control.
- **SYNC Button:** Synchronizes the finish time of both baskets.
- **MATCH Button:** Copies settings from one basket to the other.
- **MENU Button:** Cycles through pre-set cooking programs.
- **SHAKE Reminder:** Icon indicating when to shake contents for even cooking.
- **Start/Pause Button:** Initiates or pauses the cooking cycle.
- **Pre-set Program Icons:** Visual indicators for different food types (e.g., fish, chicken, fries, pizza, steak, vegetables, baking, dehydrate).

3. Setup and First Use

3.1 Unpacking

1. Carefully remove the air fryer and all packaging materials from the box.

2. Remove any stickers or labels from the appliance.
3. Keep packaging materials out of reach of children.

3.2 Initial Cleaning

1. Wash the cooking baskets and removable grids with hot, soapy water. Rinse thoroughly and dry completely.
2. Wipe the interior and exterior of the appliance with a damp cloth. Do not use abrasive cleaners.
3. Ensure all parts are completely dry before plugging in the appliance.

3.3 Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 10-15 cm of clear space around the back and sides of the appliance for proper air circulation.
- Do not place the appliance near flammable materials or heat sources.
- Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

4.1 Basic Operation

1. Plug in the air fryer. The power button will illuminate.
2. Press the Power button to turn on the display.
3. Place food into the desired basket(s). Ensure the removable grid is in place.
4. Select Basket 1 or 2 by pressing the corresponding number button.
5. Adjust the temperature using the TEMP +/- buttons (80°C - 200°C).
6. Adjust the cooking time using the TIME +/- buttons (1 - 60 minutes).
7. Press the Start/Pause button to begin cooking.
8. To pause cooking, press the Start/Pause button again. Press it once more to resume.
9. When cooking is complete, the timer will beep, and the appliance will automatically shut off.

4.2 Using Pre-set Programs

1. After turning on the display, select Basket 1 or 2.
2. Press the MENU button repeatedly to cycle through the 8 pre-set programs (e.g., Fish, Chicken, Fries, Pizza, Steak, Vegetables, Baking, Dehydrate).
3. Once a program is selected, the default time and temperature will be displayed. You can adjust these settings manually if needed.
4. Press the Start/Pause button to begin cooking.

4.3 Dual Basket Functions (SYNC & MATCH)

The FRY900 allows for flexible cooking with its dual baskets:

- **Independent Cooking:** Set different times and temperatures for each basket (Basket 1 and Basket 2) and start them independently.
- **MATCH Function:** To cook the same food in both baskets with identical settings:
    a. Set the desired time and temperature for Basket 1.
    b. Press the MATCH button. The settings from Basket 1 will be copied to Basket 2.
    c. Press Start/Pause to begin cooking in both baskets simultaneously.

- **SYNC Function:** To ensure both baskets finish cooking at the same time, even if they have different cooking durations:
    a. Set the desired time and temperature for Basket 1.
    b. Set the desired time and temperature for Basket 2.
    c. Press the SYNC button. The air fryer will automatically adjust the start time of the basket with the shorter cooking duration so both finish together.
    d. Press Start/Pause to begin the synchronized cooking.

4.4 SHAKE Reminder

For certain foods, the air fryer may display a "SHAKE" reminder icon during the cooking cycle. This indicates that the food in the basket should be shaken or tossed to ensure even cooking and crispiness. Simply pull out the basket, shake the contents, and reinsert the basket to resume cooking.

5. Maintenance and Cleaning

Regular cleaning will help maintain the performance and longevity of your H.Koenig FRY900 Air Fryer.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Cleaning Baskets and Grids:**
    - Remove the cooking baskets and grids.
    - Wash them in hot, soapy water using a non-abrasive sponge.
    - The removable grids are also dishwasher safe for convenience.
    - For stubborn food residue, soak the baskets and grids in warm, soapy water for about 10 minutes before cleaning.
3. **Cleaning the Interior:**
    - Wipe the interior of the appliance with a damp cloth.
    - Do not use abrasive cleaners or metal scouring pads, as they can damage the non-stick coating.
4. **Cleaning the Exterior:**
    - Wipe the exterior of the air fryer with a soft, damp cloth.
    - Ensure no water enters the control panel area.
5. **Storage:** Ensure the appliance is clean and dry before storing. Store it in a cool, dry place.

6. Troubleshooting

If you encounter any issues with your H.Koenig FRY900 Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Power outlet malfunction; Appliance fault.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Overfilling baskets; Food not shaken; Incorrect temperature/time.	Do not overfill baskets; ensure food is in a single layer. Shake or toss food halfway through cooking. Adjust temperature and time as needed.
Food is not crispy.	Too much moisture; Not enough oil (for some recipes); Temperature too low.	Pat food dry before cooking. A small amount of oil (1-2 teaspoons) can help with crispiness. Increase temperature slightly.
White smoke coming from the appliance.	Grease residue from previous use; High-fat food cooking.	Clean the baskets and interior thoroughly after each use. For high-fat foods, drain excess fat during cooking. This is usually harmless.
Appliance smells during first use.	New appliance odor.	This is normal for new appliances and will dissipate after a few uses. Ensure good ventilation.

7. Technical Specifications

Brand	H.Koenig
Model Number	FRY900
Capacity	9 Liters (2 x 4.5L baskets)
Power	2400 Watts
Voltage	230 Volts
Temperature Range	80°C - 200°C
Timer	Up to 60 minutes
Material	Stainless Steel
Dimensions (L x W x H)	44 x 39 x 34.5 cm
Weight	7.6 Kilograms
Special Features	5 Cooking Modes, 8 Pre-set Programs, Touch Screen, Dual Basket SYNC/MATCH functions

8. Warranty and Customer Support

The H.Koenig FRY900 Air Fryer comes with an extended **2-year warranty**. This warranty covers manufacturing defects and ensures peace of mind for prolonged and reliable use.

For any questions, technical assistance, or warranty claims, please contact H.Koenig customer support. An after-sales service (SAV) workshop is available in France to provide dedicated support.

Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCBYH3N7

More documents and user manuals: **https://manuals.plus/**