Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Homepointe 204641

HomePointe 204641 Kitchen Faucet User Manual

Model: **204641** | Brand: **HomePointe**

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your HomePointe 204641 Kitchen Faucet. This single-handle pull-out kitchen faucet features a PVD Brushed Nickel finish, a ceramic disc cartridge, and temperature memory functionality. It is designed for either 1-hole or 3-hole installations and includes a brass waterway and a braided black nylon hose. This product meets California AB1953 No Lead Standard.

Product Overview



Figure 1: HomePointe 204641 Kitchen Faucet. This image displays the faucet in a brushed nickel finish, featuring a single lever handle and a pull-out spray head. The faucet is mounted on a deck plate, suitable for multi-hole installations.

The HomePointe 204641 faucet is designed for ease of use and durability. Its pull-out spray head offers versatility for various kitchen tasks, while the single-loop handle allows for precise control over water temperature and flow. The brushed nickel finish provides a modern aesthetic and is resistant to tarnishing and corrosion.

Installation Instructions

Before You Begin

- Ensure all necessary tools are available.
- Turn off the main water supply to your kitchen.

- Clear the area under the sink for easy access.

Mounting Options

This faucet supports both 1-hole and 3-hole installations. For 3-hole installations, utilize the included deck plate to cover the additional holes. For 1-hole installations, the deck plate is optional.

Step-by-Step Installation

1. **Prepare the Sink:** If replacing an existing faucet, remove it and clean the mounting surface thoroughly.
2. **Install Deck Plate (if applicable):** Place the rubber gasket on the underside of the deck plate, then position the deck plate over the sink holes.
3. **Mount the Faucet:** Insert the faucet body through the center hole (and deck plate, if used). From underneath the sink, secure the faucet with the provided mounting hardware (washer and mounting nut). Tighten securely.
4. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet body. Ensure connections are hand-tight, then use a wrench for a quarter turn. Do not overtighten.
5. **Connect Pull-Out Hose:** Connect the pull-out spray hose to the designated connection point under the faucet. Ensure a secure, leak-free connection.
6. **Install Weight (if applicable):** Attach the hose weight to the pull-out hose at the marked location to ensure proper retraction of the spray head.
7. **Install Soap Dispenser (Optional):** If using the integrated soap dispenser, insert it into the designated hole and secure it from underneath the sink. Fill with liquid soap.
8. **Test for Leaks:** Turn on the main water supply slowly and check all connections for leaks. Operate the faucet to ensure proper function of both stream and spray modes.

Operating Instructions

Water Flow and Temperature Control

- **Turn On/Off:** Lift the single-loop handle to turn on the water. Push down to turn off.
- **Adjust Temperature:** Move the handle left for hot water and right for cold water. The ceramic disc cartridge and temperature memory feature maintain your preferred temperature setting when the faucet is turned off and on again.
- **Adjust Flow:** The further the handle is lifted, the greater the water flow.

Pull-Out Spray Function

- **Extend Spray Head:** Grasp the spray head and pull it out from the faucet body. The braided black nylon hose allows for extended reach.
- **Switch Spray Modes:** The spray head features a button to switch between a solid stream and a spray pattern. Press the button to toggle between modes.
- **Retract Spray Head:** Once finished, guide the spray head back into the faucet body. The hose weight will assist in smooth retraction.

Maintenance

- **Cleaning the Finish:** Clean the PVD Brushed Nickel finish with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Aerator Maintenance:** Periodically unscrew the aerator from the spray head and clean any mineral deposits or debris to maintain optimal water flow.
- **Ceramic Disc Cartridge:** The faucet is equipped with a durable ceramic disc cartridge. If a leak occurs from the

handle, the cartridge may need replacement. Refer to a qualified plumber for cartridge replacement (Replacement part TV# 133808).

- **Hose Inspection:** Regularly inspect the braided black nylon hose for any signs of wear or damage.

Troubleshooting

- **Low Water Flow:** Check if the aerator is clogged with debris or mineral deposits. Clean or replace as necessary. Ensure water supply valves are fully open.
- **Leaking from Handle:** This often indicates a worn or damaged ceramic disc cartridge. Replacement may be required.
- **Spray Head Not Retracting:** Check if the hose weight is properly positioned and not obstructed under the sink. Ensure the hose is not kinked or tangled.
- **Water Temperature Issues:** Verify that both hot and cold water supply lines are connected correctly and that the water heater is functioning.

Specifications

Feature	Detail
Brand	Homepointe
Model Number	204641
Finish Type	PVD Brushed Nickel
Material	Stainless Steel (faucet body), Nylon, Brass, Ceramic (handle material)
Mounting Type	Deck Mount (1 or 3 Hole Installation)
Number of Handles	1 (Single Loop Handle)
Flow Rate	1.8 GPM (Gallons Per Minute)
Special Features	Pull-Out Spray, Temperature Memory, Ceramic Disc Cartridge
Hose Type	Braided Black Nylon Hose
Compliance	Meets California AB1953 No Lead Standard
Product Dimensions	20.86 x 13.18 x 9.6 inches
Item Weight	13.95 pounds

Warranty and Support

Specific warranty information for the HomePointe 204641 Kitchen Faucet is not provided in the product details. Please refer to the manufacturer's official website or contact HomePointe customer service for detailed warranty terms and support options. For replacement parts, such as the single handle ceramic cartridge, use TV# 133808.

© 2023 HomePointe. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCGQGFBY

More documents and user manuals: **https://manuals.plus/**