Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAZHOME kitchen island

GAZHOME Rolling Kitchen Island with Trash Can Storage - Instruction Manual

Model: kitchen island

Introduction

Thank you for choosing the GAZHOME Rolling Kitchen Island. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen island. Please read these instructions carefully before use and retain them for future reference.



Image: The GAZHOME Rolling Kitchen Island, a versatile storage and prep solution.

Safety Information

Important Safety Instructions:

- Ensure all parts are properly secured before use.
- Do not allow children to play on, with, or around the cart.
- Use caution when moving on uneven surfaces to prevent tipping.
- Be careful around sharp edges during assembly and use.
- Do not overload shelves or drawers.
- Keep electrical components (power outlet) away from water.

Parts List

A detailed parts list is included with the separate assembly instructions. Please verify all components are present before beginning assembly.

Setup and Assembly

Assembly of the GAZHOME Rolling Kitchen Island is required. Detailed assembly instructions are provided separately within the product packaging. Please follow these instructions carefully to ensure proper and safe construction.
General Assembly Tips:

- Lay out all parts on a clean, soft surface to prevent scratches.
- Identify all hardware before starting.
- Do not overtighten screws during initial assembly; tighten fully once the unit is stable.
- Two people are recommended for assembly.

Operating Instructions

1. Mobility and Placement

The kitchen island is equipped with four hidden casters for easy movement. To move the island, gently push it to the desired location. To secure the island in place, engage the locks on the casters. Ensure the island is on a flat, stable surface before locking the wheels.



Image: Hidden universal wheels provide easy movement for the kitchen island.

2. Tilt-Out Trash Can Cabinet

The island features a tilt-out cabinet designed to house a 13-gallon trash can (not included). To access, pull the front panel outwards. This design helps contain odors and keeps your kitchen tidy.



Image: The tilt-out cabinet provides discreet storage for a trash can.

3. Power Outlet and USB Ports

A charging station is integrated into the top panel, featuring two standard AC outlets and two USB ports. This allows for convenient powering of small kitchen appliances or charging of electronic devices. Ensure the island is connected to a grounded power source.

4. Adjustable Shelves

The cabinet shelf and the lower open shelves on both sides are adjustable to three different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf. This allows for customizable storage to accommodate various items.



Image: Dimensional view highlighting the adjustable shelves and other storage features.

Maintenance

To maintain the appearance and longevity of your kitchen island, follow these care instructions:

- For general cleaning, wipe surfaces with a damp cloth.
- Immediately follow with a dry cloth to prevent moisture damage, especially on the bamboo countertop.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Regularly check and tighten any loose hardware.



Image: The bamboo countertop requires regular wiping with a dry cloth after cleaning.

Troubleshooting

This section addresses common issues you might encounter. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Island does not move smoothly.	Casters are locked or obstructed.	Unlock casters. Check for debris around wheels and clear if necessary.
Power outlets not working.	Island not plugged in; circuit breaker tripped.	Ensure the island's power cord is securely plugged into a functional wall outlet. Check your home's circuit breaker.
Drawers or doors stick.	Misalignment during assembly; obstruction.	Verify assembly instructions were followed correctly. Check for items obstructing movement.

Specifications

Feature	Detail
Product Dimensions	53.1"W x 22"D x 38"H
Item Weight	80 pounds
Color	White
Frame Material	Wood
Countertop Material	Bamboo
Shelf Type	Pull-Out Shelf (Adjustable)
Number of Shelves	3 (Adjustable)
Power Outlets	2 Standard AC Outlets
USB Ports	2 USB Ports
Trash Can Capacity	Accommodates 13-gallon trash can (not included)
Assembly Required	Yes

Warranty and Support

GAZHOME is committed to providing quality products. We offer risk-free shopping and guarantee to provide the best quality product. If you encounter any issues with your kitchen island, our customer service team is available to assist you.
Customer Support:

- For assistance, please refer to the contact information provided in your product packaging or visit the official GAZHOME website.
- Our customer service aims to resolve your problems within 24 hours.

© 2025 GAZHOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCJTJH1G

More documents and user manuals: **https://manuals.plus/**