MASTRAD F21413

MASTRAD Vegetable Chopper with Container

Model: F21413

User Instruction Manual

Introduction

Thank you for choosing the MASTRAD Vegetable Chopper, Model F21413. This multi-functional kitchen tool is designed to simplify your food preparation by efficiently dicing, julienning, and slicing various vegetables and fruits. Please read this manual carefully before first use to ensure safe and optimal operation, and retain it for future reference.

Safety Instructions

- **Sharp Blades:** The cutting grids contain extremely sharp blades. Always handle with extreme care. Keep fingers away from the blades during assembly, use, and cleaning.
- **Child Safety:** Keep the appliance and its components out of reach of children.
- **Stable Surface:** Always use the chopper on a stable, flat, and dry surface to prevent slipping.
- **Intended Use:** Use this appliance only for its intended purpose of chopping vegetables and fruits. Do not attempt to chop hard items like bones, frozen foods, or nuts, as this may damage the blades and unit.
- **Cleaning:** Always disassemble the unit before cleaning. Use the provided cleaning comb to remove food residue from the blades.
- **Inspection:** Before each use, inspect the blades and components for any damage. Do not use if any part is damaged.

Product Components

The MASTRAD Vegetable Chopper comes with the following components:

1. Main Chopper Unit (Lid with integrated cutting plate)
2. Collection Container
3. Dicing Grid (Large squares)
4. Julienning Grid (Small sticks)
5. Slicing Blade (Flat blade)

6. Food Pusher / Safety Holder
7. Cleaning Comb



Image 1: All components of the MASTRAD Vegetable Chopper. This includes the main chopping lid, the transparent collection container, three interchangeable cutting grids (dicing, julienning, slicing), a food pusher for safety, and a small cleaning comb.

Setup and Assembly

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash:** Before first use, wash all parts (except the main chopper unit with blades) in warm soapy water, rinse thoroughly, and dry. The main chopper unit with blades can be wiped clean with a damp cloth, taking extreme care around the blades.
3. **Select Grid:** Choose the desired cutting grid (dicing, julienning, or slicing) for your preparation.
4. **Insert Grid:** Place the selected grid securely into the designated slot on the collection container. Ensure it sits flush and is stable.

5. **Attach Lid:** Align the main chopper unit (lid) with the collection container and press down firmly until it clicks into place.
6. **Prepare Food:** Wash and peel your vegetables or fruits as needed. Cut larger items into pieces that fit onto the cutting grid.

Operating Instructions

Follow these steps for safe and effective chopping:

1. **Place Food:** Position the vegetable or fruit onto the center of the chosen cutting grid. For optimal results, ensure the food item is stable.
2. **Use Food Pusher:** Place the food pusher (safety holder) over the vegetable/fruit. This protects your hands and ensures even pressure.
3. **Chop:** With a swift and firm motion, press down the main chopper unit lid. The blades will cut the food, and the chopped pieces will fall into the collection container below.
4. **Repeat:** Lift the lid, remove any remaining food, and repeat the process for additional pieces.
5. **Collection Container:** The transparent container allows you to monitor the amount of chopped food. Once full, detach the lid and grid to empty the contents. The container can also be used for temporary storage with its lid.



Image 2: The MASTRAD Vegetable Chopper actively dicing a potato. The potato is placed on the grid, and the lid is pressed down, allowing the chopped pieces to fall into the clear collection container.



Image 3: The MASTRAD Vegetable Chopper in a kitchen setting, demonstrating its use for dicing potatoes. Fresh vegetables such as zucchini and tomatoes are visible, highlighting the chopper's versatility for various ingredients.

Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your MASTRAD Vegetable Chopper.

- **Disassembly:** After each use, carefully disassemble the chopper by detaching the lid from the container and removing the cutting grid.
- **Rinse:** Rinse all parts under running water to remove loose food particles.
- **Cleaning Comb:** Use the provided cleaning comb to safely remove any stubborn food residue from between the blades of the cutting grids. *Do not use your fingers to clean the blades.*
- **Wash:** Wash all components with warm soapy water. The collection container, grids, and food pusher are dishwasher safe. The main chopper unit (lid with blades) should be hand-washed with care.
- **Dry:** Thoroughly dry all parts before reassembling or storing to prevent rust and bacterial growth.
- **Storage:** Store the chopper in a clean, dry place. Its compact design allows for easy storage.

Troubleshooting

Problem	Possible Cause	Solution
Food not chopping cleanly.	Insufficient pressure; dull blades; food too large/hard.	Apply firm, swift pressure. Ensure food fits the grid. Do not chop excessively hard items. Blades are not user-replaceable.
Food stuck in blades.	Food residue accumulation.	Use the cleaning comb to carefully dislodge food. Rinse immediately after use.

Problem	Possible Cause	Solution
Lid not closing properly.	Grid not seated correctly; food obstructing closure.	Ensure the cutting grid is fully inserted and flush with the container. Check for any food pieces blocking the mechanism.

Specifications

Model Number: F21413

Brand: MASTRAD

Dimensions (L x W x H): 12.2 x 10.5 x 22 cm (approximately 4.8 x 4.1 x 8.7 inches)

Weight: 750 grams (approximately 1.65 lbs)

Material: Polypropylene Acrylonitrile Butadiene Styrene (ABS), Stainless Steel blades

Color: Blue

Operation Mode: Manual

Special Feature: Compact design, integrated collection container, anti-slip base

Country of Origin: China

Warranty and Support

For any questions, concerns, or support regarding your MASTRAD Vegetable Chopper, please contact MASTRAD customer service. Refer to your purchase documentation for specific warranty details and contact information.

© 2024 MASTRAD. All rights reserved. | www.mastrad.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question