Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross AC Adapter (Compatible with MKB-C-01012, MKB-C-01214, MKB-C-20330)

saschedross AC Adapter Instruction Manual

Compatible with Arcade1Up MKB-C-01012, MKB-C-01214, MKB-C-20330 Mortal Kombat II Countercade Arcade Machines

1. Introduction

This manual provides essential instructions for the safe and effective use of your saschedross AC Adapter. This adapter is designed as a replacement power supply for specific Arcade1Up Countercade arcade machines, ensuring your device receives the correct power for operation.

Please read this manual thoroughly before installation and retain it for future reference.

2. Safety Information

- **Voltage Compatibility:** Ensure the input voltage of the adapter (110V AC) matches your wall outlet's voltage.
- **Indoor Use Only:** This adapter is designed for indoor use in dry environments. Do not expose it to water, rain, or excessive moisture.
- **Proper Ventilation:** Do not cover the adapter or place it in an enclosed space where heat cannot dissipate.
- **Avoid Damage:** Do not use the adapter if the cord or plug is damaged. Avoid bending, twisting, or pulling the cord excessively.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods or during electrical storms.
- **Children and Pets:** Keep the adapter out of reach of children and pets.
- **Professional Service:** Do not attempt to open or repair the adapter yourself. Refer all servicing to qualified personnel.

3. Package Contents

- 1 x saschedross AC Adapter

4. Setup Instructions

1. **Verify Compatibility:** Before connecting, confirm that your Arcade1Up Countercade machine requires a 5V power supply. This adapter is **NOT** for 12V versions. Check the specifications label on your arcade machine for its required input voltage.
2. **Connect to Arcade Machine:** Locate the power input port on your Arcade1Up Countercade machine. Carefully insert the DC output plug of the saschedross AC Adapter into this port. Ensure a firm and secure connection.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 110V AC wall outlet. Ensure the outlet is easily accessible and not overloaded.



Figure 4.1: Connecting the AC adapter to a device.

5. Operating Instructions

Once the saschedross AC Adapter is correctly connected to both your Arcade1Up Countercade machine and a functional wall outlet, the arcade machine should power on automatically or be ready to be powered on via its power button.

Ensure the adapter remains securely plugged in during operation to prevent interruptions.

6. Maintenance

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid sharp bends or kinks in the power cord. Do not place heavy objects on the cord.

7. Troubleshooting

- **Arcade Machine Not Powering On:**
  - Check that the AC adapter is firmly plugged into both the wall outlet and the arcade machine.
  - Verify that the wall outlet is functional by plugging in another device.
  - Confirm that the adapter is compatible with your specific Arcade1Up Countercade model (5V input required).
- **Adapter Feels Hot:**
  - A slight warmth during operation is normal. However, if the adapter becomes excessively hot, immediately unplug it from the wall and the arcade machine.
  - Ensure the adapter has adequate ventilation and is not covered.
  - If overheating persists, discontinue use and contact support.

8. Specifications

Brand	saschedross
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	110 Volts (AC)
Connector Type	2-Pin
Color	Black
Compatible Devices	Arcade1up MKB-C-01012, MKB-C-01214, MKB-C-20330 Mortal Kombat II 2 Player Countercade Counter-cade 3 Game in 1 Arcade Cabinet Machine
Feature	High Quality construction



Figure 8.1: AC Adapter dimensions.



Figure 8.2: AC Adapter cable length (6.5 ft).

9. Warranty and Support

For warranty information, technical assistance, or customer support, please refer to the retailer where the product was purchased or visit the official saschedross website. Keep your purchase receipt as proof of purchase.

© 2024 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCNHL2JD

More documents and user manuals: **https://manuals.plus/**