Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bulelink Max 5

Bulelink Max 5 Cordless Stick Vacuum Cleaner User Manual

Model: Max 5

Introduction

This manual provides comprehensive instructions for the safe and efficient operation and maintenance of your Bulelink Max 5 Cordless Stick Vacuum Cleaner. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Prevent unintentional starting. Ensure the switch is in the OFF position before connecting to battery pack, picking up or carrying the appliance.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, or storing appliance.

- Recharge only with the charger specified by the manufacturer.
- Do not modify or attempt to repair the appliance or the battery pack.

Package Contents

Please check the box for the following items:

- Main Motor Unit
- Battery Pack
- Floor Brush
- Telescopic Tube
- Filter (Pre-installed)
- HEPA Filters (2 units)
- Dust Bin
- Power Adapter
- 2-in-1 Brush Tool
- Flat Nozzle Tool
- Gooseneck Cleaning Brush
- Aromatherapy Tablet
- Wall Mount Bracket
- Material Bag
- Quick Guide
- Instruction Manual (this document)



Image: All components included in the Bulelink Max 5 Cordless Stick Vacuum Cleaner package, showing the main unit, various attachments, and filters.

Product Overview

The Bulelink Max 5 is a versatile cordless stick vacuum cleaner designed for efficient cleaning across various surfaces.

Key Features:

- **Powerful Suction:** Equipped with a 550W brushless motor, providing up to 45kPa suction power.
- **Extended Runtime:** Features an 8-cell removable battery, offering up to 70 minutes of operation in Min mode.
- **Intelligent OLED Display:** Real-time monitoring of battery level, dustbin status, brush entanglement, and suction mode.
- **Advanced Brush Roll:** V-shaped brush roll with a combination of soft and hard bristles for deep cleaning and anti-tangle performance on floors and carpets.
- **8-Stage HEPA Filtration:** High-density filtration system captures up to 99.99% of fine dust and particles, releasing clean air.

- **Aromatherapy Function:** Integrated aromatherapy tablets to freshen the air during cleaning.
- **Wall-Mounted Charging:** Convenient storage and charging solution.
- **Large Dust Bin:** 1.5L capacity dustbin with one-click emptying.



Image: The intelligent OLED display on the vacuum cleaner, showing battery percentage and current operating mode.



Image: Diagram illustrating the 8-stage filtration system, including HEPA filters and the aromatherapy tablet compartment.



Image: Close-up view of the V-shaped brush roll with soft and hard bristles, designed for effective cleaning and anti-tangle performance on various floor types.

Setup and Assembly

1. Assembling the Vacuum Cleaner:

1. Insert the telescopic tube into the main motor unit until it clicks into place.
2. Attach the floor brush to the other end of the telescopic tube, ensuring it locks securely.
3. For handheld use, attach desired accessories (2-in-1 brush, flat nozzle) directly to the main motor unit.

2. Charging the Battery:

- The battery pack can be charged while attached to the main unit or separately.
- Connect the power adapter to the charging port on the battery or the wall mount.
- Plug the adapter into a power outlet. The OLED display will indicate charging status.
- A full charge takes approximately 4 hours.



Image: Illustration of the removable 8-cell battery pack and its charging mechanism, highlighting the 70-minute runtime capability.

3. Installing the Wall Mount:

- Choose a suitable location near a power outlet.
- Secure the wall mount bracket to the wall using the provided hardware.
- The vacuum cleaner can be stored and charged on the wall mount.

Operating Instructions

1. Powering On/Off:

Press the power button on the main motor unit to turn the vacuum cleaner on or off.

2. Selecting Suction Mode:

The vacuum offers 3 suction modes: Min, Mid, and Max. Press the mode selection button to cycle through these options. The current mode will be displayed on the OLED screen.

- **Min Mode:** For light cleaning and extended runtime (up to 70 minutes).
- **Mid Mode:** For general cleaning tasks.
- **Max Mode:** For deep cleaning and stubborn dirt (up to 20 minutes runtime).

3. Using Attachments:

- **Floor Brush:** Ideal for hard floors, carpets, and pet hair. The integrated LED light illuminates dark areas.
- **2-in-1 Brush Tool:** Use the brush for dusting delicate surfaces or the nozzle for crevices.
- **Flat Nozzle Tool:** Suitable for narrow gaps and corners.
- **Gooseneck Cleaning Brush:** For reaching awkward angles and surfaces.



Image: The Bulelink Max 5 cordless vacuum cleaner actively cleaning a hard floor, demonstrating its suction capability.



Image: The main motor unit used in handheld mode with an anti-mite attachment, demonstrating its versatility for cleaning upholstery and mattresses.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. Emptying the Dust Bin:

- When the dust bin is full (indicated on the OLED display), press the release button to detach it from the main unit.

- Position the dust bin over a trash receptacle and press the bottom release button to empty its contents.
- Reattach the dust bin securely.

2. Cleaning Filters:

- The vacuum cleaner includes a pre-filter and two HEPA filters.
- Remove the filters from the dust bin assembly.
- Tap off loose dirt. Filters can be rinsed under cold running water. Ensure they are completely dry before reinstallation (allow 24-48 hours).
- Replace HEPA filters every 3-6 months, depending on usage.

3. Cleaning the Brush Roll:

- Periodically check the V-shaped brush roll for tangled hair or debris.
- To remove the brush roll, locate the release tab on the side of the floor brush and unlock it.
- Carefully remove any tangled hair or fibers using scissors or the gooseneck cleaning brush.
- Reinsert the brush roll and secure the release tab.



Image: Detailed view of the improved brush roll, highlighting its soft and hard bristles designed to prevent hair entanglement and enhance cleaning performance on carpets.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely clicked into place.

Problem	Possible Cause	Solution
Low suction power.	Dust bin is full, filters are clogged, or brush roll is obstructed.	Empty dust bin. Clean or replace filters. Remove any obstructions from the brush roll.
Brush roll stops rotating.	Hair or debris tangled in the brush roll.	Turn off the vacuum, remove the brush roll, and clear any obstructions.
Vacuum stops during operation.	Battery is depleted or motor is overheating.	Recharge the battery. Allow the vacuum to cool down if it has been used continuously for a long period.
OLED display shows an error.	Specific error code or indicator.	Refer to the quick guide for specific error code meanings or contact customer support.

Specifications

Brand: Bulelink

Model Number: Max 5

Motor Power: 550W

Suction Power: Up to 45kPa

Battery: 8-cell, removable

Runtime: Up to 70 minutes (Min mode), 20 minutes (Max mode)

Charging Time: Approximately 4 hours

Dust Bin Capacity: 1.5 Liters

Filtration System: 8-stage HEPA filtration

Number of Speeds: 3

Product Dimensions (L x W x H):25.5 x 29.8 x 126 cm

Item Weight: 4.06 kg

Recommended Surface: Tiled floors, wooden floors, marble floors, short-pile carpets, pet hair

Warranty and Customer Support

Bulelink provides a 2-year warranty for this product, covering return and exchange support. Lifetime customer service is also available.
If you encounter any issues or have questions regarding your Bulelink Max 5 Cordless Stick Vacuum Cleaner, please contact our customer support team for assistance.
Contact information can typically be found on the product packaging or the official Bulelink website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCNJ1ZT5

More documents and user manuals: **https://manuals.plus/**