XOSS XL-3000

XOSS XL-3000 USB Rechargeable Bike Light Instruction Manual

Model: XL-3000

Product Overview

The XOSS XL-3000 is a high-performance, USB rechargeable bicycle headlight designed for night riding. It features a robust aluminum alloy shell, IPX7 waterproofing, and offers 10 distinct lighting modes with a maximum output of 3000 lumens. This manual provides essential information for the safe and effective use of your XL-3000 bike light.



Image: Front view of the XOSS XL-3000 bike light, showcasing its compact design and LED array.

Safety Information

- Always ensure the light is securely mounted before riding.
- Do not look directly into the light beam, as it can cause temporary vision impairment.
- Keep the light away from children.
- Use appropriate lighting modes for your riding conditions to avoid dazzling oncoming traffic or pedestrians.
- Ensure the USB-C port cover is properly sealed to maintain IPX7 waterproof rating.

Package Contents

Please check the package for the following items:

- XOSS XL-3000 Bike Headlight
- Handlebar Mounting Bracket

- USB-C Charging Cable
- Line Control Cable
- User Manual (this document)

Setup

1. Charging the Battery

Before first use, fully charge the XL-3000 bike light. The integrated 9000mAH lithium battery takes approximately 3 hours to fully charge.

1. Locate the USB-C charging port on the light.
2. Open the protective rubber cover of the USB-C port.
3. Connect the supplied USB-C cable to the light and the other end to a USB power source (e.g., computer, wall adapter).
4. The indicator light will show charging status (e.g., red for charging, green for fully charged).
5. Once fully charged, disconnect the cable and securely close the rubber cover to maintain waterproofing.



Image: Illustrative image showing the USB-C charging port on the XOSS XL-3000 light, with a charging cable connected. (Note: This image is illustrative; actual charging port location may vary slightly.)

2. Mounting the Light

The XL-3000 uses a frame mount system for secure attachment to your bicycle handlebars.

1. Attach the handlebar mounting bracket to your bicycle handlebars. Ensure it is positioned centrally and securely tightened.
2. Slide the XL-3000 bike light onto the mounting bracket until it clicks into place.
3. Adjust the angle of the light to ensure optimal illumination of the path ahead without blinding oncoming traffic.



Image: Illustrative image of the XOSS XL-3000 bike light securely mounted on a bicycle handlebar. (Note: This image is illustrative; actual mounting process may vary slightly.)

3. Connecting the Line Control

The XL-3000 is equipped with a line control for convenient operation.

1. Locate the dedicated port for the line control cable on the light.

2. Connect the line control cable to this port.
3. Route the line control cable along your handlebars to a comfortable and accessible position.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the power button (or the line control button) for approximately 2 seconds.
- **To Power Off:** Press and hold the power button (or the line control button) for approximately 2 seconds.

Changing Lighting Modes

The XL-3000 offers 10 distinct lighting modes. Briefly press the power button (or the line control button) to cycle through the modes.

Available Lighting Modes

Mode	Brightness (Lumens)	Description
Normal Light Mode 1	350LM - 1000LM	Adaptive brightness for general riding.
Normal Light Mode 2	400LM - 1100LM	Adaptive brightness for varied conditions.
Normal Light Mode 3	500LM - 1600LM	Adaptive brightness for darker environments.
Normal Light Mode 4	800LM - 1700LM	Adaptive brightness for challenging visibility.
Normal Light Mode 5	1150LM - 2000LM	Adaptive brightness for maximum visibility.
Quick Flash Light Mode	1700LM	High-visibility flashing for daytime or busy areas.
Slow Flash Light Mode	1700LM	Steady flashing for general visibility.
SOS Mode 1	1000LM	Emergency signal mode.
SOS Mode 2	1700LM	Higher intensity emergency signal mode.
High Light	3000LM	Maximum brightness for darkest conditions.



Image: Illustrative image showing the XOSS XL-3000 light emitting light, representing its various modes. (Note: This image is illustrative; actual light patterns may vary.)

Maintenance

Cleaning

- Wipe the light's aluminum alloy shell with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish or internal components.
- Ensure the lens is clean for optimal light output.

Waterproofing

The XL-3000 is IPX7 waterproof, meaning it can withstand immersion in water up to 1 meter for 30 minutes. To maintain this rating:

- Always ensure the USB-C charging port's rubber cover is fully and securely closed when not charging.
- Avoid prolonged submersion or high-pressure water jets.

Battery Care

- Recharge the battery regularly, even if the light is not used frequently, to prolong its lifespan.
- Avoid completely draining the battery before recharging.
- Store the light in a cool, dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the light fully using the supplied USB-C cable.
Light turns off unexpectedly.	Low battery level.	Recharge the battery.
Light output is dim.	Low battery level or dirty lens.	Charge the battery or clean the lens with a soft cloth.
Line control not responding.	Cable not properly connected.	Ensure the line control cable is securely plugged into the light.
Mount feels loose.	Mounting bracket not tightened or light not fully engaged.	Re-tighten the mounting bracket or ensure the light is clicked into place.

Specifications

Feature	Detail
Model	XL-3000
Brand	XOSS
Material	Aluminum Alloy
Power Source	Battery Powered (USB-C Rechargeable)
Battery Capacity	9000mAH Lithium Battery
Charging Time	Approx. 3 hours
Run Time	Up to 8 hours (depending on mode)
Brightness	Max 3000 Lumens
Lighting Modes	10 Modes (5 Normal, 2 Flash, 2 SOS, 1 High Light)
Water Resistance	IPX7
Mounting Type	Frame Mount (Handlebar)
Item Weight	558 g
Dimensions (Parcel)	20.9 x 10.21 x 6.71 cm

© 2024 XOSS. All rights reserved.

For further assistance, please refer to the official XOSS website or contact customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question