Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PRETTYCARELIFE P4

PRETTYCARELIFE P4 Cordless Vacuum Cleaner Instruction Manual

Model: P4 | Brand: PRETTYCARELIFE

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and/or filters in place.
- Turn off the appliance before making any adjustments, changing accessories, or storing the vacuum cleaner.
- Use only manufacturer's recommended attachments.
- If the charging cable is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Store the vacuum cleaner indoors in a cool, dry place.

2. Product Overview

The PRETTYCARELIFE P4 Cordless Vacuum Cleaner is designed for efficient cleaning across various floor types. It features a powerful brushless motor, smart LED display, and a lightweight, self-standing design for user convenience.

Key Features:

- **40KPa Powerful Suction:** Equipped with an upgraded 100,000 RPM brushless motor, providing strong suction for deep cleaning on carpets and hard floors.
- **Long-Lasting Runtime:** Built-in 2200 mAh battery offers up to 40 minutes of runtime in standard mode.
- **Smart LED Display:** Allows monitoring of remaining power and operational status.
- **Self-Standing Design:** Conveniently stands upright for easy storage and breaks during cleaning.
- **Ultra Lightweight & Multi-functional:** Weighing only 3.3 pounds, it easily converts into a handheld vacuum with various attachments for versatile cleaning.
- **Flexible Brush with Headlights:** Maneuverable head with 180° side-to-side and 90° up-and-down rotation, plus LED lights to illuminate dark areas.

- **Low Noise Operation:** Brushless motor generates less noise (63dB) for a quieter cleaning experience.



Figure 2.1: The PRETTYCARELIFE P4 Cordless Vacuum Cleaner featuring its self-standing design, allowing it to be placed upright anywhere during use or for storage. An inset shows the locking mechanism for the self-standing feature.



Figure 2.2: Demonstrates the powerful 40KPa suction of the P4 vacuum, effectively cleaning debris from both carpeted and hard floor surfaces, powered by its brushless motor.



Figure 2.3: Detailed view of the vacuum's features, including the LED power display, the anti-tangling brush roller, and an indication of its 40-minute maximum running time.



Figure 2.4: The vacuum's maneuverable head with integrated LED lights, demonstrating its ability to easily reach and clean under low furniture like beds.



Figure 2.5: Illustrates the lightweight nature (only 3.3 lbs) and multi-functional capabilities of the P4 vacuum, showing its use as a stick vacuum and a handheld unit with various attachments for comprehensive cleaning.

3. Package Contents

Please check the package contents upon unboxing to ensure all components are present:

- Main Motor Unit
- Extension Tube
- Motorized Floor Brush
- Dusting Brush
- Long Crevice Tool
- Wall Mount Bracket
- Power Adapter/Charger
- HEPA Filter (Pre-installed)
- User Manual

4. Assembly

Follow these steps to assemble your PRETTYCARELIFE P4 Cordless Vacuum Cleaner:

1. **Attach the Extension Tube:** Insert the extension tube into the main motor unit until it clicks securely into place.
2. **Connect the Floor Brush:** Attach the motorized floor brush to the other end of the extension tube, ensuring it locks firmly.
3. **Install Wall Mount (Optional):** Choose a suitable location for the wall mount. Secure it to the wall using the provided screws. The vacuum can then be hung on the mount for storage and charging.

5. Charging the Battery

Before first use, fully charge the vacuum cleaner for approximately 4-5 hours.

1. Connect the power adapter to the charging port on the main motor unit.
2. Plug the adapter into a wall outlet.
3. The LED display will show the charging status. A full charge is indicated by 100% on the display.
4. Once fully charged, disconnect the adapter.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the charging process of the PRETTYCARELIFE P4 Cordless Vacuum Cleaner, showing how to connect it to the wall mount for charging and how the LED display indicates battery status.

6. Operating Instructions

6.1 Power On/Off and Suction Modes

1. **Power On:** Press the power button on the main unit to start the vacuum cleaner. It will typically start in standard suction mode.
2. **Change Suction Mode:** Press the mode button (if available, or press power button again) to switch between standard and MAX suction modes. The LED display will indicate the current mode or power level.
3. **Power Off:** Press the power button again to turn off the vacuum cleaner.

6.2 Using Attachments

The P4 vacuum comes with various attachments for different cleaning tasks:

- **Motorized Floor Brush:** Ideal for cleaning large areas of hard floors and carpets. The LED headlights illuminate dust in dark corners.
- **Dusting Brush:** Use for cleaning delicate surfaces, curtains, upholstery, and keyboards. Attach directly to the main unit or the extension tube.
- **Long Crevice Tool:** Perfect for reaching tight spaces, corners, and between sofa cushions. Attach directly to the main unit or the extension tube.

Your browser does not support the video tag.

Video 6.1: This video demonstrates the versatility of the PRETTYCARELIFE P4 Cordless Vacuum Cleaner, showing how to attach and use the dusting brush and crevice tool for cleaning various surfaces like curtains, tables, and sofa crevices.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1 Emptying the Dust Cup

1. Ensure the vacuum is turned off.
2. Locate the dust cup release button on the main unit.

3. Press the button to open the bottom flap of the dust cup and empty contents into a trash bin.
4. Close the flap securely until it clicks.

7.2 Cleaning Filters

The P4 features a multi-stage filtration system including a HEPA filter, mesh filter, and carbon filter. Clean filters regularly to maintain suction power.

1. Twist and pull to remove the dust cup from the main unit.
2. Separate the filter components (HEPA filter, mesh filter, cyclone system).
3. Rinse the mesh filter and HEPA filter under running water. Ensure they are completely dry before reassembling. Do not wash the carbon filter unless specified by the manufacturer.
4. Reassemble the filters and dust cup, then reattach to the main unit.

7.3 Cleaning the Brush Roll

1. Ensure the vacuum is off and disconnected from the charger.
2. Detach the motorized floor brush from the extension tube.
3. Locate the brush roll release mechanism (usually a latch or screw) on the side of the floor brush.
4. Remove the brush roll and clear any tangled hair or debris using scissors or a cleaning tool.
5. Reinsert the brush roll and secure the release mechanism.

Your browser does not support the video tag.

Video 7.1: This video illustrates the maintenance procedures for the PRETTYCARELIFE P4 Cordless Vacuum Cleaner, including how to easily release dust from the dustbin with one click and how to clean the filter system under running water.

8. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged.	Charge the battery fully.
	Power button not pressed correctly.	Ensure the power button is pressed firmly.
Low suction power.	Dust cup is full.	Empty the dust cup.
	Filters are clogged.	Clean or replace the filters.
	Brush roll is tangled.	Remove and clean the brush roll.
	Hose or nozzle is blocked.	Check for and remove any blockages.
Brush roll not spinning.	Brush roll is jammed or tangled.	Clean the brush roll and check for obstructions.
	Floor brush not properly attached.	Ensure the floor brush is securely connected to the extension tube.
Short battery runtime.	Battery not fully charged.	Ensure the battery is fully charged before use.
	Using MAX suction mode continuously.	MAX mode consumes more power. Use standard mode for longer runtime.

9. Specifications

Model Name	P4
Brand	PRETTYCARELIFE
Special Feature	Cordless, Self-Standing, LED Display
Filter Type	HEPA Filter
Power Source	Battery Powered (1 Lithium Ion battery included)
Capacity	1.2 Liters
Wattage	210 watts
Maximum Suction	40KPa (15.75 Inches)
Noise Level	63 Decibels
Battery Life	Up to 40 minutes
Product Dimensions	9.9"L x 7.9"W x 42.5"H
Item Weight	3.3 pounds
Number of Power Levels	2
Surface Recommendation	All floors

10. Warranty and Support

The PRETTYCARELIFE P4 Cordless Vacuum Cleaner comes with a standard manufacturer's warranty. For detailed warranty information, including terms and conditions, please refer to the warranty card included in your package or contact PRETTYCARELIFE customer support.
For technical support, troubleshooting assistance, or to order replacement parts, please contact PRETTYCARELIFE customer service through their official website or the contact information provided in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCZF58YZ

More documents and user manuals: **https://manuals.plus/**