Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Reizen EL Button Talking Alarm Clock

Reizen EL Button Talking Alarm Clock - Spanish Red Instruction Manual

Introduction

The Reizen EL Button Talking Alarm Clock in Spanish Red is designed for ease of use, particularly for individuals with low vision or blindness. With a simple press of its large button, the clock clearly announces the current time and date in a high-quality Spanish-speaking voice. Its compact and portable design makes it suitable for various environments, from bedrooms and kitchens to offices and travel.



Image: The Reizen EL Button Talking Alarm Clock, featuring a large red button on a black base, designed for easy access and

visibility.

Features

- **Voice Announcement:** Announces time and date with a clear, distinctive Spanish-speaking voice.
- **Large Button:** Features a big Red button (2.75-inch diameter) for easy activation.
- **Stable Design:** Housed in a compact black base with four low-profile, non-slip feet for stability.
- **Portability:** Ultra-portable design (3.50 in. diameter x 1.25 in. high) ideal for travel.
- **Battery Operated:** Operates on 2 AAA batteries (not included).

Setup

Battery Installation

1. Locate the battery compartment on the bottom of the clock unit.
2. Open the battery compartment cover.
3. Insert 2 AAA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Power On/Off

On the bottom of the unit, locate the ON/OFF switch. Slide the switch to the 'ON' position to power on the clock. To conserve battery life, slide the switch to 'OFF' when not in use for extended periods.

Operating Instructions

Announcing Time and Date

To hear the current time and date announced, simply press the large Red button on the top of the clock.

Setting Time, Date, and Alarm

The clock features a black, Red-encircled Mode Button on the bottom. This button allows you to access the voice-announced Settings Menu. Follow the voice prompts to set the desired parameters:

1. Press the Mode Button repeatedly to cycle through the settings:
    - Set Hour (all hours - AM/PM)
    - Set Minute (0-59)
    - Set Year (2024-2045)
    - Set Month (January - December)
    - Set Date (1st-31st)
    - Set Alarm Hour (all hours - AM/PM)
    - Set Alarm Minute (0-59)
    - Adjust the alarm ON or OFF
2. When a setting is announced, use the UP/DOWN arrow buttons (located near the Mode Button) to adjust the value.
3. After adjusting a value, press the Mode Button again to confirm and move to the next setting.
4. Within 8 seconds of completing the setup, you will hear a short "dada" sound, indicating that the setup is

complete.

Your browser does not support the video tag.

Video: This video demonstrates the features and setup of a talking clock, including how to set the time, date, and alarm, and how to activate the voice announcement.

Maintenance

To clean your Reizen EL Button Talking Alarm Clock, use a soft paper towel. Avoid using any corrosive cleaners or chemical solutions, as these may damage the unit.

Troubleshooting

- **No Sound/Low Volume:** Ensure the ON/OFF switch is in the 'ON' position and that the batteries are correctly installed and not depleted. Replace batteries if necessary.
- **Incorrect Time/Date:** Follow the "Setting Time, Date, and Alarm" instructions carefully to reset the clock.
- **Alarm Not Activating:** Verify that the alarm hour and minute are set correctly and that the alarm is activated (ON) in the settings menu.

Specifications

- **Brand:** Reizen
- **Color:** Red
- **Display Type:** Button
- **Product Dimensions:** 3.5"W x 1.25"H (88.90 mm Diameter x 31.75 mm High)
- **Power Source:** Battery Powered (2 AAA batteries, not included)
- **Indoor/Outdoor Usage:** Indoor
- **Frame Material:** Plastic

Warranty & Support

This Reizen EL Button Talking Alarm Clock comes with a Limited 1-Year Warranty. For support or warranty claims, please refer to the contact information provided with your purchase or visit the official Reizen website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DCZTWYSN

More documents and user manuals: **https://manuals.plus/**