INFINMIND L910

INFINMIND Wireless Bluetooth Side Scroll Mouse - L910 Instruction Manual

Model: L910 | Brand: INFINMIND

Product Overview

The INFINMIND Wireless Bluetooth Side Scroll Mouse (Model L910) is an ergonomic computer mouse designed for seamless multi-device connectivity. It features a smart flying scroll wheel for rapid navigation, a side scroll wheel for horizontal movement, quiet click buttons, and adjustable DPI settings. This mouse is built to reduce hand fatigue during extended use and offers versatile compatibility across various operating systems.



Figure 1: Overview of the INFINMIND Wireless Bluetooth Side Scroll Mouse.

Setup

1. Battery Installation

The mouse requires two AA batteries (included). You can choose to install one or two batteries based on your preference for mouse weight. One battery can provide power for up to 20 months, while two batteries can extend usage up to 40 months.

- Remove the battery compartment cover located on the underside of the mouse.
- Insert one or two AA batteries, ensuring correct polarity (+/-).
- Replace the battery compartment cover securely.

2. Connecting to Devices (Multi-Device Connectivity)

The L910 mouse supports connection to up to three devices simultaneously: one via 2.4G USB receiver and two via Bluetooth.

- **2.4G USB Connection:**
  - Locate the USB receiver stored inside the mouse's battery compartment.
  - Plug the USB receiver into an available USB port on your computer or laptop.
  - Slide the switch on the underside of the mouse to the USB (white light) position. The mouse will automatically connect.
- **Bluetooth Connection (BT1 & BT2):**

- Slide the switch on the underside of the mouse to either the BT1 (blue light) or BT2 (green light) position.
- On your device (e.g., laptop, tablet, smartphone), go to Bluetooth settings and search for new devices.
- Select "INFINMIND L910" (or similar name) from the list to pair.
- Once paired, the corresponding indicator light on the mouse will remain solid.



Figure 2: The mouse supports multi-device connectivity across various operating systems.

Operating Instructions

1. Power On/Off

To conserve battery life, turn off the mouse when not in use. The power switch is located on the underside of the mouse.

- Slide the switch to the "ON" position to power on the mouse.
- Slide the switch to the "OFF" position to power off the mouse.

2. DPI Adjustment

The mouse features 4 adjustable DPI levels (1000/1600/2400/3000) to suit different tasks and user preferences. DPI (Dots Per Inch) controls the sensitivity of the mouse cursor.

- Press the "DPI" button located on the top of the mouse, below the main scroll wheel, to cycle through the DPI settings.
- Each press will change the sensitivity, indicated by the corresponding LED lights.



Figure 3: Adjusting DPI settings for optimal cursor sensitivity.

3. Scrolling Functions

The mouse is equipped with both a smart flying scroll wheel and a side scroll wheel for enhanced navigation.

- **Smart Flying Scroll (Vertical):** The main metal roller allows for rapid vertical scrolling with remarkable speed and near silence.
- **Side Scroll (Horizontal):** The side scroll wheel enables horizontal page scrolling, useful for wide documents or spreadsheets.



Figure 4: Utilizing both vertical and horizontal scrolling features.

4. Quiet Click Buttons

The mouse features quiet click buttons, making it suitable for use in various environments without disturbing others.



Figure 5: The quiet click design is ideal for shared workspaces.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your INFINMIND mouse.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the mouse's performance degrades or the indicator light signals low power. Always use new AA alkaline batteries.
- **Storage:** When not in use for extended periods, turn off the mouse and store it in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Mouse not responding	Low battery; Incorrect connection mode; USB receiver not detected; Bluetooth not paired.	Replace batteries; Ensure switch is in correct mode (USB/BT1/BT2); Re-insert USB receiver; Re-pair Bluetooth connection.
Cursor movement is erratic or slow	Low DPI setting; Dirty optical sensor; Unsuitable surface.	Increase DPI setting; Clean the optical sensor on the underside of the mouse; Use on a clean, non-reflective surface or mouse pad.
Cannot connect via Bluetooth	Mouse not in pairing mode; Device's Bluetooth is off; Interference.	Ensure mouse is in BT1/BT2 mode and indicator is blinking; Turn on Bluetooth on your device; Move closer to the device or away from other wireless devices.

Specifications

- **Brand:** INFINMIND
- **Model Number:** L910
- **Connectivity Technology:** Bluetooth, USB (2.4G Wireless)
- **Movement Detection Technology:** Optical

- **DPI Settings:** 1000/1600/2400/3000 DPI
- **Special Features:** Ergonomic Design, Multi-Device Mouse, Thumb Scroll (Side Scroll)
- **Power Source:** 2 AA batteries (included)
- **Battery Life:** Up to 20 months (1 battery), up to 40 months (2 batteries)
- **Product Dimensions:** 4.41 x 2.99 x 0.04 inches
- **Item Weight:** 5.3 ounces
- **Color:** Grey
- **Compatibility:** Windows, Mac OS, Linux, iOS, Android, Chrome OS

Warranty and Support

INFINMIND is committed to product quality and customer satisfaction. For any issues or inquiries regarding your L910 Wireless Bluetooth Side Scroll Mouse, please contact INFINMIND customer support through the retailer's platform or the official INFINMIND website. Please retain your proof of purchase for warranty claims.
For more information about INFINMIND products, visit the INFINMIND Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question