Ninja FN101GY

Ninja Crispi 4-in-1 Portable Glass Air Fryer Cooking System User Manual

Brand: Ninja | Model: FN101GY

Introduction

Welcome to the world of convenient and healthy cooking with your new Ninja Crispi Portable Cooking System. This innovative appliance combines the power of a full-sized air fryer with the versatility of portable glass containers, allowing you to prepare delicious meals anywhere you can plug it in. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new cooking system.



The Ninja Crispi 4-in-1 Portable Glass Air Fryer Cooking System.

What's Included

Your Ninja Crispi Portable Cooking System comes with the following components:

- **Ninja Crispi PowerPod:** The main heating unit.
- **4-Quart TempWare Glass Container:** For larger batches and meals.
- **6-Cup TempWare Glass Container:** Ideal for single-serve meals and smaller portions.
- **2 Crisper Plates:** Designed to elevate food for optimal air circulation.
- **2 Storage Lids:** Leak-proof lids for convenient storage of cooked food.
- **Crispi Container Adapter:** Allows the PowerPod to be used with the larger 4-quart container.



All components of the Ninja Crispi Portable Cooking System.

Setup

Before first use, wash all glass containers, crisper plates, and storage lids in warm, soapy water or in the dishwasher. Rinse thoroughly and dry. Ensure the PowerPod is clean and dry before use.

Assembling for Use:

1. Place the desired TempWare glass container (4-quart or 6-cup) on a stable, heat-resistant surface.
2. Insert the appropriate crisper plate into the glass container.
3. If using the 4-quart container, place the Crispi Container Adapter securely on top of the container before attaching the PowerPod.

4. Carefully place the Ninja Crispi PowerPod onto the glass container (or adapter). Ensure it sits securely.
5. Plug the PowerPod into a standard 120V electrical outlet.



Securely attach the PowerPod to the glass container.

Operating Instructions

The Ninja Crispi offers 4-in-1 functionality: Max Crisp, Bake, Air Fry, and Recrisp. The control panel allows for easy selection of cooking modes and time adjustments.



The intuitive control panel for selecting cooking modes.

Cooking Modes:

Max Crisp (425-450°F): Best for frozen favorites, providing an extra-crispy crunch with rapid high heat.

Place frozen food on the crisper plate. Select MAX CRISP mode and adjust time. Press START.

Bake (375-400°F): Gentle heat for all your baked treats, desserts, and breads.

Place ingredients in the glass container. Select BAKE mode and adjust time. Press START.

Air Fry (400-425°F): Give your food crispiness and crunch with little to no oil.

Place food on the crisper plate. Select AIR FRY mode and adjust time. Press START. Flip food halfway through cooking for even results.

Recrisp (380-400°F): Revive your leftovers with an even, crispy texture.

Place leftovers on the crisper plate. Select RECRISP mode and adjust time. Press START.

General Operation Tips:

- Always preheat the unit for 3-5 minutes for best results, especially for air frying and max crisp modes.

- Shake or toss food halfway through cooking for even browning and crisping.
- The PowerPod features fixed heat-safe feet, allowing you to safely place it on various countertop surfaces.



Fixed heat protection allows safe placement on countertops.

For more detailed recipes and cooking charts, refer to the Quick Start Guide included with your product or visit the official Ninja website.

Maintenance

Proper cleaning and maintenance will extend the life of your Ninja Crispi and ensure optimal performance.

Cleaning:

- **Glass Containers, Crisper Plates, Adapter, and Lids:** All these components are dishwasher safe for quick and easy

cleanup. They can also be hand-washed with warm, soapy water.

- **PowerPod:** The PowerPod unit should never be submerged in water. Wipe the exterior with a damp cloth. For stubborn residue on the heating element, use a non-abrasive sponge or brush. Ensure the PowerPod is completely dry before storing.



Easy to clean: Glassware and accessories are dishwasher safe.

Storage:

The Ninja Crispi PowerPod and TempWare glassware are designed to nest together, allowing for easy, mess-free storage in your cabinets or on your countertop.



Nesting design for compact storage.

Troubleshooting

If you encounter any issues with your Ninja Crispi, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; PowerPod not properly seated.	Ensure unit is securely plugged into a working outlet. Re-seat the PowerPod firmly onto the container.
Food is not crispy.	Overcrowding; Insufficient cooking time/temperature.	Cook in smaller batches. Increase cooking time or temperature. Ensure food is not wet before cooking.

Problem	Possible Cause	Solution
Smoke coming from unit.	Excess fat/oil; Food residue on heating element.	Reduce oil. Clean heating element thoroughly after each use. Ensure crisper plate is used to elevate food.
Food not cooking evenly.	Food not shaken/flipped.	Shake or flip food halfway through cooking cycle.

Specifications

Feature	Detail
Model Name	Ninja FN101GY
Product Dimensions	13.38"D x 11.96"W x 13.58"H
Capacity	4 Quarts (large container)
Output Wattage	1500 Watts
Voltage	120 Volts
Control Method	Touch
Inner Material	Glass (TempWare)
Outer Material	Metal
Min Temperature Setting	22 Degrees Fahrenheit
Max Temperature Setting	450 Degrees Fahrenheit
Dishwasher Safe Components	Containers, crisper plates, adapter, and lids
Item Weight	14.72 pounds
Country of Origin	China

Warranty & Support

Your Ninja Crispi Portable Cooking System comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.
For product support, replacement parts, or additional information, please visit the official Ninja website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.
Online Support: www.ninjakitchen.com

© 2024 Ninja. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I bought a Ninja Crispi 4-in-1 Portable Glass Air Fryer (4 qt) and it did not come with an instruction manual. Could you mail me a paper booklet?

Manuals+ is an independent digital archive and does not provide physical paper booklets by mail. However, you can access the full digital version of the Ninja Crispi 4-in-1 Portable Glass Air Fryer (Model FN101GY)...

Read full answer