Jaobeem B0DDKB1DZF

Jaobeem 65x50 Inch Baby Playpen Instruction Manual

Model: B0DDKB1DZF

Introduction Safety Information Package Contents Setup Operating Instructions Maintenance Troubleshooting Specifications Support

1. Introduction

Thank you for choosing the Jaobeem 65x50 Inch Baby Playpen. This playpen is designed to provide a safe and spacious environment for your baby or toddler to play, explore, and learn to stand and walk. Its sturdy construction and breathable mesh design ensure both safety and visibility. This manual provides detailed instructions for assembly, operation, maintenance, and important safety information to ensure proper use of your playpen.

2. Important Safety Information

Please read and understand all instructions and warnings before assembling and using this playpen. Failure to follow these instructions could result in serious injury or death.

- **Adult Supervision Required:** Never leave a child unattended in the playpen. Always keep your child in view.
- **Proper Assembly:** Ensure all parts are correctly assembled and securely fastened before placing a child in the playpen. Regularly check for loose parts.
- **Hazard Prevention:** Keep the playpen away from stairs, windows, heating appliances, and other potential hazards. Do not place toys with long strings or cords inside the playpen to prevent strangulation hazards.
- **Weight and Age Limits:** This playpen is intended for infants and toddlers who are not yet able to climb out. Discontinue use when a child is able to climb out or reaches 35 inches (89 cm) in height, or 30 lbs (14 kg) in weight.
- **No Additional Padding:** Do not add extra padding, pillows, or mattresses inside the playpen, as this can create a suffocation hazard. The floor of the playpen is designed for safety.
- **Inspect Regularly:** Periodically check the playpen for any signs of damage, wear, or missing parts. Do not use if any part is damaged or missing.
- **Outdoor Use:** When used outdoors, ensure the playpen is placed on a flat, stable surface and protected from direct sunlight and harsh weather conditions.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Rust-proof alloy pipes (various lengths for frame)
- ABS plastic joints (connectors)
- Breathable mesh fabric enclosure (sides and bottom)
- Zippered door panel
- Instruction Manual



Image: All components of the Jaobeem Baby Playpen laid out before assembly.

4. Setup and Assembly

Assembly is designed to be straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.

Refer to the parts list to ensure everything is present.

2. **Assemble Base Frame:** Connect the longest pipes using the appropriate ABS plastic joints to form the rectangular base of the playpen. Ensure all connections are firm.
3. **Attach Side Panels:** Slide the mesh fabric side panels onto the vertical pipes. Pay attention to the orientation of the zippered door panel.
4. **Construct Vertical Supports:** Insert the vertical pipes into the base frame joints and connect them to the upper frame pipes using more ABS joints.
5. **Secure Top Frame:** Complete the top rectangular frame by connecting the remaining pipes and joints. Ensure the mesh fabric is taut and evenly distributed.
6. **Install Bottom Fabric:** Secure the bottom fabric to the frame according to the instructions, ensuring it is flat and secure.
7. **Final Check:** Once assembled, gently shake the playpen to ensure all connections are secure and stable. Check for any sharp edges or exposed parts.



Image: Illustrates the process of connecting frame pipes and joints during assembly.



Image: The assembled playpen, highlighting its spacious 65x50 inch interior dimensions.

5. Operating Instructions

Using your Jaobeem Baby Playpen is simple and provides a secure area for your child.

- **Placement:** Position the playpen on a flat, stable surface, away from any potential hazards like stairs, heaters, or open flames.
- **Child Placement:** Gently place your child inside the playpen. Ensure they have enough space to move and play comfortably.
- **Zippered Door:** The playpen features an external zippered door for easy access. Always ensure the zipper is fully closed when your child is inside to prevent them from exiting unsupervised.
- **Supervision:** Always maintain direct visual supervision of your child while they are in the playpen. The 360° transparent mesh design allows for full visibility.
- **Toys:** You may place appropriate, safe toys inside the playpen for your child's entertainment. Avoid toys with small parts that could be a choking hazard or long cords.



Image: A baby happily playing within the secure confines of the playpen.



Image: Demonstrates the external zippered door, allowing easy entry and exit for parents.



Image: A toddler standing and holding onto the top rail, illustrating the playpen's safe height.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your playpen and ensure a hygienic environment for your child.

- **Cleaning Fabric:** The breathable and quick-drying fabric can be cleaned by simply wiping it down with a wet cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow all fabric components to air dry completely before folding or storing the playpen to prevent mold or mildew growth.
- **Frame Cleaning:** Wipe down the alloy pipes and plastic joints with a damp cloth as needed.
- **Storage:** When not in use, disassemble the playpen (if desired) and store it in a clean, dry place, away from extreme temperatures and direct sunlight.

7. Troubleshooting

If you encounter any issues with your Jaobeem Baby Playpen, please refer to the following common solutions:

Problem	Possible Cause	Solution
Playpen is unstable or wobbly.	Loose connections or uneven surface.	Ensure all pipes are fully inserted into the ABS joints. Place the playpen on a flat, level surface.
Parts are missing or damaged upon arrival.	Manufacturing or shipping error.	Do not assemble. Contact Jaobeem customer support immediately for assistance.
Fabric appears stained or has mold/mildew.	Improper cleaning or storage in a damp environment.	Clean with a wet cloth and mild soap. Ensure thorough drying. Store in a dry, well-ventilated area. If mold persists, contact support.
Zipper is stuck or difficult to operate.	Debris in zipper teeth or misalignment.	Check for any fabric caught in the zipper. Gently try to realign the zipper pull. Do not force it.

8. Product Specifications

- **Brand:** Jaobeem
- **Model:** B0DDKB1DZF
- **Dimensions:** 65 x 50 x 27 inches (Length x Width x Height)
- **Floor Area:** Approximately 3150 Square Inches
- **Color:** Grey
- **Material Type:** Plastic, Stainless Steel (for pipes), Breathable Mesh Fabric
- **Age Range Description:** Infant / Toddler (up to 35 inches height or 30 lbs weight)

9. Warranty and Customer Support

Jaobeem is committed to providing high-quality products. If you experience any quality issues with your baby playpen, please do not hesitate to contact our customer support team.

- **Warranty:** Specific warranty details are not provided in this manual. Please refer to your purchase documentation or contact customer support for warranty information.
- **Customer Service:** For any questions, concerns, or assistance with your product, please contact us. We aim to help resolve any issues within 24 hours.
- **Contact Information:** Please refer to the contact details provided on the product packaging or the retailer's website where you purchased the item.

© 2026 Jaobeem. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question