MZK ET2307

MZK 20V 12" Cordless String Trimmer User Manual

Model: ET2307 | Brand: MZK

1. Introduction

Thank you for choosing the MZK 20V 12" Cordless String Trimmer. This manual provides essential information for the safe and efficient operation, assembly, maintenance, and troubleshooting of your new tool. Please read this manual thoroughly before first use and keep it for future reference.



The MZK 20V 12" Cordless String Trimmer, designed for efficient lawn care.

2. Safety Information

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these instructions may result in serious injury.

General Safety Rules

- Wear eye protection, long sleeves, and sturdy shoes during operation.
- Keep pets and children away from the area of operation.
- Ensure the work area is clear of debris, rocks, and other objects that could be thrown by the trimmer.

- Do not operate the trimmer in wet conditions or rain.
- Always remove the battery pack when not in use, before cleaning, or when changing accessories.
- Inspect the trimmer for damage before each use. Do not use if damaged.
- Use only MZK approved replacement parts and accessories.



The trimmer features a dual safety switch for secure operation. Press both buttons for effortless safety start.

3. Package Contents

Verify that all items are present and in good condition upon opening the package. If any items are missing or damaged, please contact customer service.

- Cordless String Trimmer Unit
- 20V Lithium-Ion Battery (1 included)
- Fast Charger
- Replacement Spools (4 included)
- User Manual



Included components: Trimmer, 20V Battery, Charger, and 4 replacement spools.

4. Assembly

Follow these steps to assemble your string trimmer before first use.

4.1 Attaching the Guard

1. Align the guard with the slots on the trimmer head.
2. Push firmly until it clicks into place. Ensure it is securely fastened.

4.2 Installing the Auxiliary Handle

1. Slide the auxiliary handle onto the main shaft.
2. Adjust the handle to a comfortable working position and tighten the locking knob.



The ergonomic handle can be adjusted for optimal comfort and handling.

4.3 Attaching the Battery

1. Ensure the battery is fully charged.
2. Slide the battery pack into the battery slot on the trimmer handle until it clicks into place.

5. Operation

5.1 Charging the Battery

Connect the charger to a power outlet and insert the battery pack into the charger. The indicator light will show charging status. A full charge typically takes [Insert typical charge time if available, otherwise omit or state 'several hours'].

5.2 Starting and Stopping

- To start: Press the safety switch (usually a button or lever) and then squeeze the ON/OFF trigger switch.
- To stop: Release the ON/OFF trigger switch.

5.3 Trimming and Edging (2-in-1 Function)

Your MZK trimmer features a 2-in-1 design, allowing for easy conversion between trimming and edging modes.

- **Trimming:** Hold the trimmer parallel to the ground, allowing the line to cut the grass.
- **Edging:** Rotate the trimmer head 90 degrees to use the wheel for guiding along edges of sidewalks or driveways.



Easily convert between trimming and edging modes with a one-button conversion.

5.4 Automatic Line Feed

The trimmer is equipped with an automatic line feed system, which releases more line as needed during operation, eliminating the need for manual adjustments.



The automatic line feed system ensures continuous cutting without manual intervention.



The telescopic pole adjusts from 36 to 44 inches for comfortable use.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your trimmer.

6.1 Cleaning

- Always remove the battery before cleaning.
- Wipe down the exterior of the trimmer with a damp cloth.
- Remove any grass clippings or debris from the guard and trimmer head.

6.2 Replacing the Spool

When the cutting line runs out, replace the spool with a new one.

1. Ensure the battery is removed.
2. Press the tabs on the spool cover and remove it.
3. Remove the empty spool.
4. Insert a new MZK replacement spool, ensuring the line is fed through the eyelet.
5. Replace the spool cover, ensuring it clicks securely into place.



The automatic line feed system includes an integrated spool holder for easy replacement.

6.3 Storage

Store the trimmer in a dry, secure location, out of reach of children. Remove the battery pack before storing for extended periods.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Trimmer does not start	Battery not charged or improperly inserted; Safety switch not engaged.	Ensure battery is fully charged and properly seated. Engage safety switch before pressing trigger.

Problem	Possible Cause	Solution
Line does not feed automatically	Spool is empty; Line is tangled or jammed; Incorrect line type.	Replace spool. Clear any tangles or debris from the trimmer head. Use only recommended MZK line.
Reduced cutting performance	Line is too short or worn; Motor overloaded.	Allow automatic line feed to extend line or replace spool. Avoid cutting excessively thick or wet vegetation.
Excessive vibration	Damaged cutting line or spool; Loose components.	Inspect and replace damaged line/spool. Check all connections and tighten if necessary.

8. Specifications

Feature	Detail
Brand	MZK
Model Number	ET2307
Power Source	Battery Powered (20V Lithium-Ion)
Cutting Width	12 Inches
Speed	8000 RPM
Item Weight	6.09 pounds
Product Dimensions	39"L x 13"W
Style	Auto Feed



The upgraded motor delivers a high speed of 8000 RPM for efficient cutting.

9. Warranty and Support

MZK is committed to providing you with the best shopping experience possible. If you have any questions or problems with your MZK tool, please feel free to contact our customer service team. We are always here to help you solve any

problems you may encounter.

For support, please visit the official MZK store or contact us through the platform where you purchased the product.

© 2025 MZK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question