Azwok AKB74475490

Azwok AKB74475490 Remote Control Instruction Manual

Replacement Remote Control for LG TV Models

1. Introduction

This manual provides instructions for the Azwok AKB74475490 replacement remote control, designed for use with various LG TV models. This remote control offers the primary functions of the original AKB74475490 remote, ensuring seamless operation of your television.

Compatible LG TV Models:

- 32LH510B, 32LH510U, 32LH513U, 32LH519U, 32LH520U, 32LH530V
- 43LH510V, 43LH513V, 43LH520V, 43LH541V
- 49LH513V, 49LH520V, 49LH541V





Image 1.1: The Azwok AKB74475490 replacement remote control. This image displays the full remote control, showing its black casing and the layout of all buttons, including the power button, number pad, navigation controls, and function buttons.

2. Setup

The Azwok AKB74475490 remote control is designed for immediate use without requiring any programming. Follow these steps to begin operation:

1. **Install Batteries:** Open the battery compartment cover on the back of the remote control. Insert two AAA batteries (not included), ensuring correct polarity (+ and -).
2. **Close Compartment:** Securely close the battery compartment cover.
3. **Ready for Use:** The remote control is now ready to operate your compatible LG TV.

Note: If the remote does not function, verify battery installation and ensure the batteries are new and correctly oriented.

3. Operating Instructions

This section details the functions of the buttons on your Azwok AKB74475490 remote control.





Image 3.1: Top section of the remote control. This view highlights the power button (red circle with power symbol), SUBTITLE, AD, RATIO, and TV/RAD buttons.

- **Power (Red Circle)**: Turns the TV on or off.
- **TV/RAD**: Switches between TV and Radio modes.
- **RATIO**: Adjusts the screen aspect ratio.
- **SUBTITLE**: Activates or deactivates subtitles.
- **AD**: Activates or deactivates Audio Description.





Image 3.2: Middle section of the remote control. This view shows the numeric keypad (0-9), LIST, Q.VIEW, FAV, GUIDE, PAGE, TEXT, T.OPT, Q.MENU, and the central navigation cluster with OK button.

- **Numeric Keypad (0-9)**: Directly selects channels or enters numerical values.
- **LIST**: Displays the channel list.
- **Q.VIEW**: Quickly switches to the previously viewed channel.
- **FAV**: Accesses favorite channels.
- **GUIDE**: Opens the electronic program guide.
- **PAGE (Up/Down Arrows)**: Navigates through pages in menus or guides.
- **TEXT**: Activates or deactivates Teletext.
- **T.OPT**: Accesses Teletext options.
- **Q.MENU**: Opens the Quick Menu for common settings.
- **Navigation Arrows (Up, Down, Left, Right)**: Moves cursor or navigates through menus.
- **OK**: Confirms a selection.
- **Home (House Icon)**: Returns to the TV's home screen or smart menu.
- **Settings (Gear Icon)**: Opens the TV's main settings menu.
- **Mute (Speaker with X)**: Mutes or unmutes the TV audio.


TV/
RAD
RATIO
SUBTITLE
AD
1
2
3
4
5
6
7
8
9
LIST
0
Q.VIEW
FAV
GUIDE
P
PAGE
TEXT
T.OPT
Q.MENU
OK
BACK
EXIT
INFO
REC/*



Image 3.3: Bottom section of the remote control. This view displays the BACK, EXIT, INFO, REC/*, and media playback control buttons (Rewind, Play, Pause, Fast Forward, Stop), along with the four colored function buttons.

- **BACK**: Returns to the previous screen or menu.
- **EXIT**: Exits the current menu or application.
- **INFO**: Displays information about the current program or input.
- **REC/***: Initiates recording (if supported by TV and external device) or other special functions.
- **Media Playback Controls (Rewind, Play, Pause, Fast Forward, Stop)**: Controls media playback for connected devices or TV functions.
- **Colored Buttons (Red, Green, Yellow, Blue)**: These buttons perform specific functions depending on the TV's current mode or application, often indicated on-screen.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type (AAA).
- **Cleaning:** Use a soft, dry cloth to clean the remote control's surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the remote control in a dry place, away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the remote control to water or other liquids.

5. Troubleshooting

If you experience issues with your remote control, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote control does not work.	◦ Batteries are dead or incorrectly installed. ◦ Obstruction between remote and TV. ◦ Remote control sensor on TV is blocked. ◦ Remote control is too far from the TV.	◦ Replace batteries with new ones, ensuring correct polarity. ◦ Remove any objects blocking the line of sight between the remote and the TV. ◦ Ensure the TV's remote sensor is clear. ◦ Move closer to the TV.
Some buttons do not respond.	◦ Specific function not supported by your TV model. ◦ Button is stuck or dirty.	◦ Refer to your TV's original manual for supported functions. ◦ Clean the remote control.

6. Specifications

- **Model Number:** RM-AKB74475490-LG127 (Replacement for AKB74475490)
- **Brand:** Azwok
- **Compatible Devices:** LG Televisions
- **Connectivity Technology:** Infrared
- **Special Feature:** No Programming Required
- **Color:** Black
- **Product Dimensions:** 6.69 x 1.97 x 0.59 inches
- **Power Source:** 2 x AAA Batteries (not included)

7. Warranty and Support

This Azwok remote control comes with a**12-month warranty**.
If you encounter any issues, have questions regarding compatibility, or require assistance, please contact the seller for support. They can help you verify compatibility or assist with any operational concerns.

© 2024 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question