Shark UV730

Shark UV730 Navigator Lift-Away Upright Vacuum User Manual

Model: UV730

Setup Operation Maintenance Troubleshooting Specifications Warranty Support

Introduction

This manual provides instructions for the safe and effective use of your Shark UV730 Navigator Lift-Away Upright Vacuum. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Shark UV730 Navigator Lift-Away Upright Vacuum, shown with its main body, handle, and various cleaning attachments including a dust brush and crevice tool.

Setup and Assembly

Your Shark UV730 vacuum requires minimal assembly. Ensure all components are present before beginning.

Included Components:

- Navigator Lift-Away Upright Vacuum (main unit)
- Dust Brush
- Crevice Tool

Assembly Steps:

1. Insert the wand into the nozzle until it clicks securely.
2. Attach the handle to the top of the wand, ensuring it locks into place.
3. Connect the hose to the back of the vacuum pod.
4. Store the dust brush and crevice tool on the onboard accessory posts if available, or keep them nearby for easy access.



Image: A detailed diagram illustrating the various components of the Shark Lift-Away vacuum, including fingertip controls, Anti-Allergen Complete Seal with HEPA, Lift-Away Technology, Swivel Steering, PowerFins, and Self-Cleaning Brushroll.

Operating Instructions

Power and Mode Selection:

- Plug the power cord into an electrical outlet.
- Press the power button to turn the vacuum on.
- Use the brushroll shutoff feature to switch between deep carpet cleaning (brushroll on) and gentle bare floor cleaning (brushroll off).



Image: A person operating the Shark UV730 vacuum cleaner on a white carpet, demonstrating its use for deep cleaning carpets and hard floors.

Lift-Away Functionality:

The Lift-Away feature allows for versatile cleaning in various areas.

1. **For Under Furniture:** Press the Lift-Away button to detach the pod from the nozzle. This allows you to clean under low-lying furniture with ease.
2. **For Above-Floor Cleaning:** Detach the nozzle or use the wand with attachments to clean upholstery, stairs, and other elevated surfaces.



Image: A person using the Lift-Away feature of the Shark vacuum to clean under a piece of furniture, demonstrating how the detachable pod allows access to low areas.



Image: A person carrying the detached pod of the Shark vacuum to clean stairs, illustrating the portability and convenience of the Lift-Away function for elevated surfaces.



Image: A person using the Shark vacuum with its wand extended for high-reach cleaning, demonstrating the versatility of the Lift-Away feature for cleaning ceilings or high shelves.



Image: A person using the detached pod of the Shark vacuum with an attachment to clean pet hair from a sofa, highlighting its effectiveness for pet hair pickup.

Swivel Steering and LED Headlights:

- **Swivel Steering:** Maneuver the vacuum easily around furniture and into tight spaces by gently twisting the handle.
- **LED Headlights:** The integrated LED headlights illuminate the cleaning path, revealing hidden dust and debris.



Image: A close-up view of the Shark vacuum's LED headlights, showing them illuminating dust and debris on a dark floor, emphasizing their utility in revealing hidden dirt.

Maintenance

Regular maintenance ensures optimal performance of your vacuum cleaner.

Emptying the Dust Cup:

- The 0.8-quart capacity dust cup should be emptied after each use or when debris reaches the MAX fill line.
- To empty, press the dust cup release latch and lift the dust cup from the vacuum pod.
- Hold the dust cup over a trash bin and press the bottom release latch to open the bottom flap.
- For thorough cleaning, the top of the dust cup can also be opened.

Filter Cleaning:

Your vacuum features a HEPA filter and washable pre-motor filters. Clean filters regularly to maintain suction power.

- **Pre-Motor Filters (Foam & Felt):** Rinse with water every 3 months, or as needed. Allow to air dry completely for at least 24 hours before reinstalling.
- **HEPA Post-Motor Filter:** Rinse with water once a year, or as needed. Allow to air dry completely for at least 24 hours before reinstalling. Do not use a brush to clean the HEPA filter.
- The Anti-Allergen Complete Seal Technology, combined with the HEPA filter, traps 99.9% of dust and allergens inside the vacuum.



Image: A diagram illustrating the effectiveness of Shark's Anti-Allergen Complete Seal HEPA system, showing how it captures 99.99% of dust and allergens compared to unsealed HEPA vacuums.

Self-Cleaning Brushroll:

The PowerFins HairPro Self-Cleaning Brushroll is designed to minimize hair wrap. Periodically check the brushroll for any entangled debris and remove it if necessary.

Troubleshooting

If your vacuum is not performing as expected, consult the following guide:

Problem	Possible Cause	Solution
Vacuum not picking up debris or low suction.	• Dust cup is full. • Filters are dirty and need cleaning. • Hose or nozzle is clogged. • Brushroll is obstructed.	• Empty the dust cup. • Clean and air dry all filters. • Check hose and nozzle for blockages and clear them. • Remove any hair or debris from the brushroll.
Brushroll not spinning.	• Brushroll shutoff is engaged (bare floor mode). • Obstruction in the brushroll. • Vacuum is not fully upright.	• Ensure the vacuum is in carpet mode (brushroll on). • Remove any debris from the brushroll. • Recline the vacuum handle to engage the brushroll.
Vacuum turns off automatically.	• Overheating due to clogged filters or hose.	• Turn off and unplug the vacuum. • Empty dust cup and clean all filters. • Check for and clear any blockages in the hose or nozzle. • Allow the vacuum to cool for at least 60 minutes before restarting.

Specifications

- **Brand:** Shark
- **Model Name:** Shark Navigator Lift-Away Upright Vacuum with PowerFins HairPro
- **Model Number:** UV730
- **Special Features:** Bagless, HEPA, Headlight, Lift-Away, Washable Filter
- **Filter Type:** HEPA Filter
- **Included Components:** Navigator Lift-Away Upright Vacuum, Dust Brush & Crevice Tool
- **Cordless:** No
- **Capacity:** 0.8 Quarts (Dust Cup)
- **Wattage:** 800 watts
- **Recommended Uses:** Carpet, Floor, Pet Hair
- **Form Factor:** Upright
- **Color:** Gray
- **Item Weight:** 13.49 pounds
- **Product Dimensions:** 11.99 x 11.95 x 45.33 inches
- **UPC:** 732388804337

Warranty Information

This product comes with a**90 days limited warranty**. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or contact customer support.

Customer Support

For further assistance, replacement parts, or service inquiries, please visit the official Shark website or contact their customer service department. Contact information can typically be found on the manufacturer's website or on the product packaging.

Online Resources: www.sharkclean.com

© 2023 SharkNinja Operating LLC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question