Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AMKE IB-801

AMKE Luxury Electric Baby Swing Rocker IB-801 Instruction Manual

Model: IB-801

1. Product Overview

The AMKE Luxury Electric Baby Swing Rocker is designed to provide a soothing and engaging experience for infants from newborn up to approximately 9 months (or 20 pounds). Featuring multiple rocking motions, adjustable speeds, and recline positions, this swing offers customizable comfort. Its quiet dual motors ensure a peaceful environment, while smart controls via a touchscreen panel or remote provide convenience for parents.



Image 1: The AMKE Electric Baby Swing in use, highlighting its 5 swing modes and 5 adjustable speeds.

2. Safety Information

- **SGS Certified:** Tested to ASTM F2088 & CPSC 16 CFR Part 1223, ASTM F3084-22, and ASTM F963-23 for toy-grade safety.
- **Secure Harness:** Equipped with a 5-point harness to keep your baby safely secured.
- **Stable Design:** Features a stable wide base (28.7*20.2 inches) and a robust aircraft-grade aluminum frame to prevent tipping.
- **Weight Limit:** Suitable for infants up to 20 pounds.

- **Age Range:** Recommended for infants from 0 to 9 months.



Image 2: Close-up of a safety warning label on the baby swing, emphasizing important usage guidelines.

3. Assembly Instructions

The AMKE Electric Baby Swing is designed for straightforward assembly. An Allen wrench is included for tightening screws.

1. **Base and Frame:** Connect the main frame to the base unit. Ensure all connections are secure.
2. **Attach Seat:** Securely attach the seat unit to the frame using the provided screws and Allen wrench.
3. **Install Toy Bar:** Attach the removable toy bar to the designated slot on the frame.
4. **Power Connection:** Plug the power adapter into the swing's base and then into a wall outlet.

Your browser does not support the video tag.

Video 1: A seller-provided video demonstrating the assembly process of the AMKE Electric Baby Swing, including attaching the frame,

seat, and toy bar.

4. Operating Instructions

4.1 Power On/Off

Press the power button on the touchscreen panel or the remote control to turn the swing on or off. The swing will enter standby mode when plugged in.

4.2 Rocking Motions and Speeds

The swing offers 5 distinct rocking motions and 5 adjustable speeds. Use the motion mode buttons on the touchscreen or remote to select your preferred motion. Adjust the speed using the 'S' button.



Image 3: Visual representation of the five distinct rocking motions and adjustable speed levels available on the swing.

4.3 Seat Recline Adjustment

The seat angle can be quickly adjusted from 10° to 40° to support your baby during play, feeding, or rest. Locate the adjustment knob/buttons on the side of the seat frame to change the recline position.



Image 4: The baby swing demonstrating its adjustable recline feature, suitable for various activities like playing or resting.

4.4 Audio Features

The swing includes 5 built-in lullabies. You can select different melodies and adjust the volume using the music notes

buttons and the 'V' button on the control panel or remote. The quiet dual motors operate under 45dB, ensuring a peaceful environment.

Your browser does not support the video tag.

Video 2: A seller-provided video showcasing the quiet motor and various motion settings of the AMKE Electric Baby Swing, along with its built-in music options.

4.5 Timer Function

Set a 30-minute auto-off timer for convenience. This feature can be activated via the control panel or remote.

4.6 Remote Control

A remote control is included for easy adjustment of motions, speeds, music, and volume from a distance.



Image 5: Detailed view of the swing's touchscreen control panel, illustrating the various buttons for operation.

5. Maintenance

The seat cover is machine-washable for easy cleaning. Refer to the care label for specific washing instructions.



Image 6: The baby swing emphasizing its skin-friendly, breathable, and machine-washable seat cover for easy maintenance.

6. Troubleshooting

- **No Power:** Ensure the power adapter is securely plugged into both the swing and a working wall outlet.
- **Motion Not Working:** Check if the swing is powered on and a motion mode is selected. Ensure no obstructions are preventing movement.
- **No Sound:** Verify that the volume is not set to minimum. Try selecting a different melody.
- **Remote Not Responding:** Check the remote's battery. Ensure there are no obstructions between the remote and the swing's sensor.

7. Specifications

Feature	Detail

Brand	AMKE
Model Number	IB-801
Color	Gray
Material	Aluminum
Product Dimensions	28.7"D x 19.7"W x 17.7"H
Item Weight	22 Pounds
Maximum Weight Recommendation	20 Pounds
Manufacturer Minimum Age	0 Months
Manufacturer Maximum Age	9 Months
Required Assembly	Yes



Image 7: The baby swing with key dimensions highlighted, including depth, width, and height.

8. Warranty & Support

For any questions regarding product warranty, technical support, or service, please contact AMKE customer support directly. Refer to the product packaging or the official AMKE website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDPFGHMJ

More documents and user manuals: **https://manuals.plus/**