Gahenwo LJ-8898

Gahenwo 173cm Selfie Stick Tripod for Phone and Action Camera - User Manual

Model: LJ-8898 | Brand: Gahenwo

Introduction Features Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The Gahenwo 173cm Selfie Stick Tripod is a versatile 3-in-1 device designed for mobile phones and action cameras. It combines the functionality of a selfie stick, a desktop tripod, and a floor tripod in one compact and portable design. Made from an aluminum alloy, it offers stability and durability for various shooting scenarios, from selfies and group photos to video recording and live streaming. This manual provides detailed instructions for the proper setup, operation, and maintenance of your device.

2. Features

- **3-in-1 Design:** Easily switch between selfie stick, desktop tripod, and floor tripod modes.
- **Wide Compatibility:** Suitable for smartphones from 4 to 7 inches and action cameras with a 1/4" screw mount.
- **Adjustable Height:** Extendable aluminum alloy pole with 8 sections, adjustable from 30 cm to 172.7 cm.
- **Flexible Angles:** Supports 360° horizontal rotation and 110° vertical rotation for optimal shooting angles.
- **Wireless Remote Control:** Detachable USB-C rechargeable remote control for photos and videos up to 10 meters away.
- **Stable and Portable:** Robust tripod base with a leg length of 8.3 inches and a base side of 13.5 inches. Folded, it is only 30 cm long and weighs 0.31 kg.
- **Cold Shoe Slot:** Integrated cold shoe slot on the phone holder for accessories such as microphones or video lights.

3. Setup

3.1. Unfolding the Tripod

1. Hold the selfie stick firmly.
2. Press the "BUTTON" on the side of the handle to unlock and extend the three tripod legs. Ensure the legs are fully extended for maximum stability.
3. Place the tripod on a flat and stable surface.



Image: Unfolding the tripod legs by pressing the button.

Your browser does not support the video tag.

Video: Demonstration of the tripod legs automatically opening when the base hits the ground.

3.2. Attaching a Phone or Action Camera

1. **For Phones:** Pull apart the phone holder and place your smartphone (4-7 inches) inside. Ensure the phone is securely held and cannot slip. The lower arm of the clip is foldable for storage.
2. **For Action Cameras:** Use the 1/4" screw mount at the top of the selfie stick to directly attach your action camera. Ensure it is tightened securely.



Image: The phone holder and 1/4" screw mount for various devices.

Your browser does not support the video tag.

Video: Demonstration of attaching a phone and camera to the Ulanzi 180cm Selfie Stick Tripod, including rotation.

3.3. Pairing the Bluetooth Remote Control

1. Remove the wireless remote control from its holder on the selfie stick.
2. Turn on the remote control (usually by long-pressing the button). An indicator light will flash.

3. Enable Bluetooth on your smartphone and search for "T-226" or a similar name in the list of available devices.
4. Select the device to pair. The indicator light on the remote control will stop flashing when pairing is successful.

Your browser does not support the video tag.

Video: Demonstration of pairing the Bluetooth remote control with a smartphone.

4. Operation

4.1. Adjusting Height

The selfie stick features an 8-section aluminum alloy telescopic pole. Gently pull out the pole to the desired height. The height can be adjusted from 30 cm (folded) to 172.7 cm (maximum height). Ensure all sections are securely locked when extended.



Image: Various heights and modes of the tripod: folded, desktop, standing, and maximum height.

4.2. Adjusting Angle

The phone holder supports 360° horizontal rotation and 110° vertical rotation. Manually rotate the holder to find the perfect angle for your photos or videos. You can easily switch between portrait and landscape modes.



Image: Demonstration of 360° rotation and 110° angle adjustment of the phone holder.

4.3. Using the Remote Control

After the remote control is paired with your phone, open the camera app on your phone. Press the button on the remote control to take photos or start/stop video recording. The remote control works up to a distance of 10 meters.

Your browser does not support the video tag.

Video: Demonstration of using the magnetic remote control with the 173cm Magnetic Selfie Stick Tripod.

5. Maintenance

- **Cleaning:** Regularly wipe the tripod with a soft, dry cloth to remove dust and dirt. Do not use harsh chemicals or abrasive materials.
- **Storage:** Fully collapse the tripod and store the remote control in its designated slot to prevent loss. Store it in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery:** Charge the remote control with the included USB-C cable when the battery is low.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control does not connect	Low battery, Bluetooth not enabled, not paired.	Charge the remote control. Ensure Bluetooth is enabled on your phone. Repeat the pairing procedure (see section 3.3).
Tripod is unstable	Legs not fully extended, uneven surface, device too heavy.	Ensure the tripod legs are fully extended and locked. Place the tripod on a flat surface. Check if your device's weight is within specifications.
Phone does not fit in the holder	Phone is too large or too small.	The holder is compatible with phones from 4 to 7 inches. Check your phone's dimensions.

7. Specifications

Feature	Value
Model Number	LJ-8898
Material	Acrylonitrile Butadiene Styrene (ABS), Aluminum
Minimum Height	30.5 cm
Maximum Height	172.7 cm (68 inches)
Weight	311 Grams
Number of Leg Sections	8
Compatible Devices	Smartphone (4-7 inches), Action Camera
Remote Control Range	Up to 10 meters
Remote Control Battery	1 Lithium-polymer battery (included)

8. Warranty & Support

For information regarding warranty and product support, including repairs or replacements, please contact Gahenwo customer service using the contact details provided on the product packaging or the official website. Please retain your proof of purchase for warranty purposes.

© 2024 Gahenwo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question