Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit B0DDTGX8RK

ZdalaMit Replacement Voice Remote Control Commander for Hisense Smart Google TV User Manual

Model: B0DDTGX8RK

1. Introduction

This manual provides instructions for the ZdalaMit Replacement Voice Remote Control Commander, designed for use with compatible Hisense Smart Google TV models. Please read this manual thoroughly before using the remote control to ensure proper operation and to familiarize yourself with its features.

2. Product Overview

The ZdalaMit Replacement Voice Remote Control Commander offers a user-friendly interface with dedicated buttons for popular streaming services and voice control capabilities.







Figure 1: Front view of the ZdalaMit Replacement Voice Remote Control Commander. It features a brushed silver finish with black buttons, including a central navigation pad, volume and channel controls, and dedicated buttons for streaming services like Netflix, YouTube, Prime Video, Disney+, Tubi, and Peacock.

Key Features:

- Voice Search functionality for convenient control.
- Dedicated quick-access buttons for popular streaming applications.
- Standard navigation and media playback controls.

3. Setup and Pairing

3.1 Battery Installation

This remote control requires two (2) AAA size alkaline batteries. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

3.2 Pairing Instructions

Pairing is required before using the remote control with your Hisense Smart Google TV.

1. **Initial Setup:** When you power on your TV for the first time, on-screen instructions will guide you through the remote control pairing process. Follow these prompts.
2. **Manual Pairing (If initial pairing fails or for re-pairing):**
    - Ensure the remote control is within 10 feet (approximately 3 meters) of your TV.
    - Simultaneously press and hold the **Back** button and the **Home** button for at least 3 seconds.
    - Continue holding until you observe the light on the remote control pulsing, indicating it is in pairing mode.
    - Release the buttons. The TV should display a confirmation message once pairing is successful.

4. Operating Instructions

4.1 Basic Navigation

- **Directional Pad (Up, Down, Left, Right):** Use to navigate menus and select items on the screen.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the TV's home screen.
- **Volume Up/Down (VOL +/-):** Adjusts the TV volume.
- **Channel Up/Down (CH +/-):** Changes TV channels.
- **Mute Button:** Mutes or unmutes the TV audio.

4.2 Voice Search

The remote control features a Voice Search button (microphone icon). Press and hold this button to activate voice commands and speak into the remote to search for content, control your TV, or ask questions.

4.3 Quick Access Buttons

Dedicated buttons provide direct access to popular streaming services:

- **Netflix**
- **YouTube**
- **Prime Video**
- **Disney+**
- **Tubi**
- **Peacock**

Simply press the desired button to launch the corresponding application.

4.4 Apps Button

Press the **APPS** button to access a menu displaying all installed applications on your Hisense Smart Google TV, allowing for easy navigation and selection of other services.

5. Compatible Hisense TV Models

This remote control is compatible with the following Hisense Smart Google TV models:

- 75U7N
- 85U7N
- 55U6N
- 55U7N
- 75U6N
- 85U6N
- 65U75N
- 65U7N
- 75U75N
- 65U6N



Figure 2: The ZdalaMit remote control positioned in a living room environment, demonstrating its use with a Hisense Smart Google TV setup.

6. Specifications

Feature	Detail
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	2 ounces
Color	Black
Special Feature	Voice Search
Max Number of Supported Devices	1
Compatible Devices	Television
Batteries Required	2 x AAA (not included)





Figure 3: Dimensions of the ZdalaMit Replacement Voice Remote Control Commander, showing its length as 7.65 inches and width as 1.77 inches.

7. Maintenance

7.1 Battery Replacement

Replace batteries when the remote's performance degrades or if the pairing indicator light does not illuminate. Always replace both batteries at the same time with new AAA alkaline batteries.

7.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

8. Troubleshooting

- **Remote Not Responding:**
  - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
  - Ensure there are no obstructions between the remote control and the TV.
  - Re-pair the remote control with the TV using the manual pairing steps described in Section 3.2.
- **Voice Search Not Working:**
  - Ensure the remote is properly paired.
  - Check your TV's settings to confirm voice control is enabled.
  - Speak clearly and hold the remote closer to your mouth when using voice commands.
- **Quick Access Buttons Not Launching Apps:**
  - Verify that the respective applications are installed and updated on your Hisense Smart Google TV.
  - Ensure your TV has an active internet connection.

9. Product Video

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and compatibility of the ZdalaMit Replacement Remote Control for Hisense Smart Google TVs. This video highlights the remote's design and functionality.

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDTGX8RK

More documents and user manuals: **https://manuals.plus/**