ELECTCOM PRO DVD-3621

ELECTCOM PRO DVD Player User Manual

Model: DVD-3621 (ELC-1910)

Introduction

Thank you for purchasing the ELECTCOM PRO DVD Player, Model DVD-3621 (ELC-1910). This player is designed to provide an immersive video and audio experience with its 1080p output and versatile compatibility. It supports various disc formats and offers convenient features for your home entertainment system. Please read this manual thoroughly before operating the device to ensure proper use and longevity.



Image: The ELECTCOM PRO DVD Player, its remote control, and included HDMI and RCA cables.

Package Contents

Upon opening the package, please verify that all the following items are included:

- 1 x ELECTCOM PRO DVD Player (Model DVD-3621)
- 1 x Remote Control (requires 2 AAA batteries, not included)
- 1 x HDMI Cable (3FT)
- 1 x RCA Cable (3FT)
- 1 x User Manual



Image: All items included in the product packaging: the DVD player, remote, HDMI cable, RCA cable, and user manual.

Setup and Connections

Follow these steps to connect your DVD player to your television or audio system.

1. Choose Your Connection Type:

The DVD player offers multiple connection options to suit various display and audio devices.

- **HDMI Connection (Recommended for HD Quality):** Use the included HDMI cable for optimal picture and sound quality. This connection is suitable for Smart TVs, projectors, and monitors.
- **RCA Connection (Standard Definition):** Use the included RCA cable (red, white, yellow) for older TVs, speakers, soundbars, amplifiers, or old-school tuners.



Image: Rear view of the DVD player highlighting HDMI and RCA output jacks for multi-device connectivity.

2. Connect to Your Display/Audio Device:

1. Ensure both the DVD player and your display/audio device are powered off.
2. **For HDMI:** Insert one end of the HDMI cable into the "HD OUT" port on the back of the DVD player and the other end into an available HDMI input on your TV or projector.
3. **For RCA:** Connect the red, white, and yellow plugs of the RCA cable to the corresponding colored ports on the back of the DVD player ("AUDIO OUT L/R" for red/white, "VIDEO OUT" for yellow). Connect the other end to the matching input ports on your TV or audio receiver.



Image: The included HDMI and RCA cables, ready for connection.

3. Power Connection:

Plug the power cord of the DVD player into a standard electrical outlet.

4. Power On:

Press the **POWER** button on the front of the DVD player or on the remote control to turn on the unit. Select the correct input source (e.g., HDMI 1, AV) on your TV.

Operating Instructions

Disc Playback:

1. Press the **OPEN/CLOSE** button on the front panel or remote to open the disc tray.
2. Place a DVD, CD, or VCD disc gently onto the tray with the label side facing up.
3. Press the **OPEN/CLOSE** button again to close the tray. The player will automatically begin reading the disc.

4. Use the **PLAY/PAUSE**, **STOP**, **PREV**, **NEXT**, **REV**, and **FWD** buttons on the remote for playback control.

Note: This is an HDMI DVD player and is not compatible with Blu-ray Discs. The player is designed to be region-free, supporting discs from all regions. If you encounter issues playing discs from specific regions, please refer to the Troubleshooting section or contact customer support.



Image: The DVD player's display showing playback time, emphasizing its quick disc reading and region-free capabilities.

USB Playback:

The DVD player features a USB port for playing digital media files.

- Insert a USB flash drive into the USB port on the front of the player.
- The player supports MP3 audio files and JPG image files.
- **Important:** The USB interface does not support MP4 video playback.
- Use the **DISC/USB** button on the remote to switch between disc and USB playback modes.

Remote Control Functions:

The remote control provides full functionality for operating your DVD player.



Image: Detailed diagram of the remote control, showing buttons and their primary functions (Part 1).



Image: Detailed diagram of the remote control, showing buttons and their secondary functions (Part 2).

1. **POWER ON/OFF:** Press to power on. Press again for Standby mode.
2. **NUMBERS 0-9/10+:** While playing DVD/VCD/CD/MP3 discs, use to select desired track/chapter in menu selection.
3. **TITLE:** When using DVDs, press to return to the title menu.
4. **Direction Arrows:** Select the direction within the menu.
5. **ENTER:** Confirm your selection.
6. **SETUP:** Press to get into Setup menu.

7. OSD: Press for the relative information of the disc to Display.

8. L/R: When playing VCD or CD discs. Press button to select left or right channel, or stereo.

9. OPEN/CLOSE: Press to load and remove discs. Place disc into tray with the title side facing up. Press button again to close the disc tray.

10. GOTO: Press GOTO button to select title time, chapter time and track time. You can use digit keys to input the go to the specific time.

11. MENU: When playing DVD discs press MENU once to return to sub menu. Press MENU again to return to the main menu. When playing VCD discs, press MENU button to turn on PBC, the VCD is played by menu, press MENU again to turn off PBC, then VCD is played in sequence.

12. REPEAT: Press REPEAT button to repeat a title, chapter, track or the whole disc. When playing DVD discs, press REPEAT button continually, the TV screen shows chapter repeat, title repeat, all repeat, repeat cancel in turn. When playing SVCD, VCD, CD discs, the sequence is track repeat, all repeat, repeat cancel. When playing MP3 discs, the sequence is single repeat, directory repeat, repeat cancel.

13. VOLUME+/VOLUME-: Increase/decrease volume.

14. PLAY/PAUSE: Press once to pause, press again to play.

15. STOP: Press to stop media. Press the Play/Pause button to resume.

16. SUBTITLE: When playing the DVD discs with multi-subtitles, press SUBTITLE continually to get to the language you desire.

17. ANGLE: Change angle in DVD mode.

18. PREV (PREVIOUS, |<<): In DVD mode, press to go to previous chapter. With SVCD, VCD, CD, MP3 discs, press to go to previous track.

19. NEXT (NEXT, >>|): In DVD mode, press to go to next chapter. With SVCD, VCD, CD, MP3 discs, press to go to next track.

20. REV: Press this button for quick rewind search.

21. FWD: Press this button for quick forward search.

22. DISC/USB: Press this button to switch the play between DISC and USB.

23. SLOW: Press to select slow speed playing.

24. LANGUAGE: When playing DVD with more than one audio stream, press LANGUAGE to select what you desired.

25. CD RIPPING: Press the button to use the CD ripping function.

26. PROG: If the disc is with 2 or more tracks, chapters or titles, set up the playing order as your reference. Press this button to enter program menu. Press digit key to input the number of the track, title or chapter. If the programmed tracks are over ten press 10+ to go on programming. (Maximum 16 programmable items) use the up / down / left / right key to move the cursor to the PLAY. Press ENTER to start Program play.

27. HD: Press the button to choose the following resolution levels from the HDMI output.

28. A-B: Press to repeat certain sections. Press button on start point (A) and the end point (B) to select section. Cancel by pressing button a third time.

29. ZOOM: Press to Zoom in, press again to zoom out. Use arrow keys to move picture.

30. MUTE: Mute the sound during playing.

31. N/P: Press to switch the TV system between NTSC and PAL.

Maintenance and Care

To ensure the longevity and optimal performance of your DVD player, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the player. Do not use liquid cleaners or aerosol sprays, as they may damage the finish or internal components.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of dust, fingerprints, and scratches. Use a soft,

lint-free cloth to wipe discs from the center outwards.

- **Ventilation:** Ensure the player is placed in a well-ventilated area. Do not block any ventilation openings.
- **Storage:** When not in use for extended periods, disconnect the power cord and store the player in a cool, dry place.

Troubleshooting

If you encounter any issues with your DVD player, please refer to the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
No power	Power cord not connected securely; power outlet not active.	Ensure power cord is firmly plugged into the player and a working electrical outlet. Try a different outlet.
No picture on TV	Incorrect input source selected on TV; loose HDMI/RCA cable connection.	Select the correct HDMI or AV input on your TV. Check that HDMI or RCA cables are securely connected to both the player and the TV.
No sound	TV/audio system volume too low or muted; loose audio cable connection.	Increase volume on TV/audio system and ensure it's not muted. Check audio cable connections (red/white RCA or HDMI).
Disc does not play or "No Disc" error	Disc is dirty, scratched, or inserted incorrectly; unsupported disc format; player region compatibility.	Clean the disc with a soft cloth. Ensure the disc is inserted label-side up. Verify the disc format (DVD/CD/VCD). **Note:** While designed to be region-free, some users have reported issues with specific region discs (e.g., Region 2). If this occurs, ensure the disc is clean and try another disc. If the issue persists, contact customer support for assistance.
USB playback issues	Unsupported file format; USB drive not properly formatted.	Ensure files are MP3 (audio) or JPG (images). MP4 video files are not supported. Ensure USB drive is formatted to FAT32.
Remote control not working	Batteries are dead or inserted incorrectly; obstruction between remote and player.	Replace batteries (2 AAA). Ensure correct polarity. Remove any obstructions between the remote and the player's IR sensor.

Specifications

Feature	Detail
Brand	ELECTCOM PRO
Model Name	DVD3621 (ELC-1910)
Compatible Devices	Television
Media Type Supported	CD, DVD, VCD

Feature	Detail
Supported Audio Formats	Surround, Stereo, MP3
Video Capture Resolution	1080p (1920x1080)
Connector Type	HDMI, RCA, USB
Total USB Ports	1
Power Source Type	Corded Electric
Remote Control Type	IR (Infrared)
Batteries Required for Remote	No (Batteries not included)
Product Dimensions	22.86 x 20.32 x 5.08 cm (9 x 8 x 2 inches)
Item Weight	1 kg (24 oz)



Image: The compact design of the DVD player, illustrating its small footprint and light weight.

Warranty and Support

ELECTCOM PRO stands behind the quality of its products. This DVD player comes with a**3-year warranty**.

- For warranty claims, technical support, or any questions regarding your product, please contact ELECTCOM PRO customer service.
- Refer to the contact information provided on the product packaging or the official ELECTCOM PRO website.
- Please have your model number (DVD-3621 or ELC-1910) and purchase details ready when contacting support.

© 2025 ELECTCOM PRO. All rights reserved.