Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEEDECK LB-DWY-US-0B

BEEDECK Cordless Leaf Blower Instruction Manual

Model: LB-DWY-US-0B



Image: BEEDECK Cordless Leaf Blower, model LB-DWY-US-0B, shown with its product packaging.

Important Notice: Battery and Charger Not Included

This product is sold as a tool only. Compatible DEWALT 20V MAX lithium-ion batteries and chargers must be purchased separately.

1. Safety Information

Please read and understand all safety warnings and instructions before operating this leaf blower. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

General Safety Precautions

- **Read the Manual:** Familiarize yourself with the controls and proper use of the appliance.
- **Wear Eye Protection:** Always wear safety glasses or goggles to protect your eyes from flying debris.
- **Wear Hearing Protection:** Prolonged use may require hearing protection.
- **Secure Grip:** Maintain a firm grip on the handle during operation.
- **Dry Conditions:** Operate the leaf blower only in dry conditions. Do not expose to rain or wet environments.
- **Keep Clear:** Ensure children, bystanders, and pets are kept at a safe distance from the operating area.
- **Inspect Before Use:** Check for loose parts, damage, or obstructions before each use.

Electrical Safety

- **Battery Compatibility:** Use only with compatible DEWALT 20V MAX lithium-ion batteries (DCB200, DCB201, DCB203, DCB204, DCB205, DCB206, DCB207, DCB208, DCB210, DCB230, DCB240).
- **Battery Condition:** Do not use damaged or modified battery packs.
- **Charging:** Refer to the battery manufacturer's instructions for proper charging procedures. This product does not include a charger.

2. Package Contents

Verify that all items are present and in good condition upon unpacking.

- 1 x BEEDECK Cordless Leaf Blower (Tool Only)
- 1 x Blower Tube
- 1 x User Manual (this document)

3. Setup

3.1 Attaching the Blower Tube

1. Align the blower tube with the outlet on the main unit.
2. Push the tube onto the outlet and twist it clockwise until it locks securely into place. Ensure the assembling button or dot aligns for proper fit.



Image: Diagram illustrating the simple assembly of the blower tube onto the main unit of the BEEDECK Cordless Leaf Blower.

3.2 Installing the Battery

1. Ensure the leaf blower is turned off.
2. Slide a charged, compatible DEWALT 20V MAX lithium-ion battery into the battery slot on the blower until it clicks into place.
3. To remove the battery, press the battery release button and slide the battery out.



Image: The BEEDECK Cordless Leaf Blower with an exploded view of the battery compartment, showing various compatible DEWALT 20V Li-ion battery models.

4. Operating Instructions

4.1 Controls Overview



Image: Diagram of the BEEDECK Cordless Leaf Blower highlighting its components: Soft Grip Non-Slip Handle, Insurance Button, ON/OFF Switch, Assembling Button, and Large-diameter Nozzle.

4.2 Powering On and Off

- To turn on the leaf blower, press the ON/OFF switch.
- To turn off the leaf blower, release the ON/OFF switch.

4.3 Adjusting Speed Modes

This leaf blower features 6 adjustable speed modes to suit various tasks.

1. Locate the speed adjustment dial on the side of the blower.
2. Rotate the dial to select the desired speed setting from 1 (lowest) to 6 (highest).



Image: Side view of the BEEDECK Cordless Leaf Blower showing the 6-speed adjustment dial and an arrow pointing to the 'Assemble Dot' for tube alignment.

4.4 General Usage

Hold the leaf blower firmly with one hand using the ergonomic handle. Use a sweeping motion to direct debris away from desired areas. Start with a lower speed for light debris and increase as needed for heavier or wet leaves.



Image: Four panels depicting the BEEDECK Cordless Leaf Blower being used in different environments: a lawn, a backyard patio, inside a car, and on a walkway.

5. Maintenance

5.1 Cleaning

- Always remove the battery before cleaning.
- Wipe the exterior of the blower with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure air vents are clear of debris to prevent overheating. Use a soft brush or compressed air if necessary.

5.2 Storage

- Remove the battery from the leaf blower before storing.
- The blower tube can be detached for more compact storage.
- Store the leaf blower in a dry, secure location, out of reach of children.

6. Troubleshooting

If you encounter issues with your BEEDECK Cordless Leaf Blower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly Battery is discharged ON/OFF switch not engaged	Ensure battery is fully seated and clicked into place Charge the battery Press the ON/OFF switch firmly
Low air output or power	Battery is low Blower tube not securely attached Air intake/outlet obstructed	Charge the battery Re-attach blower tube securely Clear any obstructions from air vents or nozzle
Excessive vibration or noise	Obstruction in fan/impeller Loose components	Remove battery and carefully inspect for and remove any debris Check all connections and ensure they are tight

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Feature	Detail
Brand	BEEDECK
Model	LB-DWY-US-0B
Power Source	Battery Powered
Voltage	20 Volts
Battery Compatibility	DEWALT 20V MAX Lithium-ion Batteries (DCB200, DCB201, DCB203, DCB204, DCB205, DCB206, DCB207, DCB208, DCB210, DCB230, DCB240)
Max Air Volume	520 CFM (Cubic Feet per Minute)
Max Wind Speed	150 MPH (Miles Per Hour)
Speed Modes	6 Adjustable Speeds
Item Weight	2.45 kg (5.39 lbs)
Product Dimensions	30" L x 5" W x 9" H
Special Features	Adjustable Speed, Lightweight, Overload Protection, Ergonomic Handle, Detachable Blower Tube
UPC	810147640881



Image: Cutaway view of the BEEDECK Cordless Leaf Blower illustrating the internal powerful motor and air flow, highlighting features like 'More Power', 'Lower Noise', and 'More Runtime'.



Image: Diagram showing the overall dimensions of the BEEDECK Cordless Leaf Blower, indicating a total length of 30 inches and a blower tube length of 16 inches.

8. Warranty and Customer Support

BEEDECK is committed to providing quality products and customer satisfaction.

Warranty Information

For specific warranty details regarding your BEEDECK Cordless Leaf Blower, please refer to the warranty card included with your purchase or contact customer support.

Customer Support

Our company offers 24-hour customer support to address any questions or concerns you may have promptly. Please reach out to us for assistance with product operation, troubleshooting, or warranty inquiries.

Contact information can typically be found on the product packaging or on the BEEDECK official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DF6KZYBS

More documents and user manuals: **https://manuals.plus/**