Yakry B0DFGNBR6V

Yakry Vehicle Backup Camera User Manual

Model: B0DFGNBR6V (Y02 Compatible)

Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Yakry Vehicle Backup Camera. Designed for compatibility with the Yakry Y02 system, this camera offers a wide view to enhance your vehicle's rear visibility, making parking and reversing safer and more convenient. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

Package Contents

Upon opening the package, please verify that all the following components are included:

- 1 x Yakry Vehicle Backup Camera
- 1 x USB Charging Cable

Setup and Installation

The Yakry Vehicle Backup Camera is designed for straightforward installation, primarily compatible with the Yakry Y02 backup camera system (Model: B0DFCLKKXS). This camera features a strong magnetic base, eliminating the need for complex wiring.

1. **Compatibility Check:** Ensure your existing system is the Yakry Y02 backup camera system (ASIN: B0DFCLKKXS). This camera is only compatible with that specific system.
2. **Mounting Location:** Choose a suitable flat, metallic surface at the rear of your vehicle (car, SUV, van, truck, trailer, etc.) where the camera can securely attach via its strong magnetic base. Ensure the camera has a clear, unobstructed view of the area behind your vehicle.
3. **Powering the Camera:** The camera can be powered using the included USB charging cable. Connect the USB cable to the camera's charging port and to a suitable USB power source (e.g., a car USB adapter, power bank, or the Y02 monitor's USB port if available). The camera also features a solar panel for supplementary charging.
4. **Antenna Positioning:** Adjust the antenna for optimal signal reception with your Y02 monitor.



An image showing the Yakry Vehicle Backup Camera. It features a main camera lens surrounded by multiple LED lights, a solar panel on top for charging, and an antenna on the left side for wireless connectivity. A power button and battery indicator lights are visible on the side.

Operating Instructions

Once installed and powered, the Yakry Vehicle Backup Camera will wirelessly transmit its video feed to your compatible Yakry Y02 monitor.

- **Power On:** Press the power button on the camera to turn it on. The battery indicator lights will show the current charge level.
- **Automatic Activation:** When paired with the Y02 system, the camera typically activates automatically when the vehicle is put into reverse, or can be manually activated via the monitor. Refer to your Y02 monitor's manual for specific operation details.
- **Wide View:** The camera provides a wide-angle view, offering comprehensive coverage of the area behind your vehicle, aiding in obstacle detection and safe maneuvering.
- **Charging:** The integrated solar panel helps maintain the battery charge during daylight hours. For faster or full charging, use the provided USB cable.

Maintenance

To ensure the longevity and optimal performance of your backup camera, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the camera lens and solar panel with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the surfaces.
- **Battery Care:** While the camera has a solar panel, it's recommended to fully charge the battery via USB periodically, especially if the camera is stored or used in low-light conditions for extended periods.
- **Secure Mounting:** Periodically check that the camera is securely attached to its mounting surface.
- **Storage:** If storing the camera for an extended period, ensure it is fully charged and stored in a cool, dry place.

Troubleshooting

If you encounter issues with your Yakry Vehicle Backup Camera, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No image on monitor	Ensure the camera is powered on and charged. Verify the camera is properly paired with your Yakry Y02 monitor. Refer to the Y02 monitor's manual for pairing instructions. Check for signal interference. Reposition the camera or monitor if necessary. Ensure the camera is within range of the Y02 monitor.
Poor image quality	Clean the camera lens. Check for obstructions in the camera's view. Ensure adequate lighting conditions. Verify the camera is securely mounted and not vibrating.
Camera not charging	Ensure the USB cable is properly connected to both the camera and the power source. Try a different USB power source or cable. Ensure the solar panel is clean and exposed to direct sunlight for effective charging.

If the problem persists after attempting these solutions, please contact Yakry customer support for further assistance.

Specifications

Feature	Detail
Model Compatibility	Yakry Y02 Backup Camera System (ASIN: B0DFCLKKXS)
Mounting Type	Strong Magnetic, No Wiring Required
Power Source	USB Cable (included), Integrated Solar Panel
Vehicle Compatibility	Car, SUV, Van, Truck, Trailer, etc.
Video Capture Resolution	1080p
Color	Black
Item Weight	1.63 pounds

Feature	Detail
Package Dimensions	6.26 x 4.06 x 3.31 inches
Batteries	3 Lithium Ion batteries (included)
Country of Origin	China

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your complete Yakry Y02 system or visit the official Yakry website. You may also contact Yakry customer service directly for assistance with product-related inquiries or issues.

Yakry Official Store: Visit the Yakry Store on Amazon

© 2024 Yakry. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question