## AlfaBot WS24

# AlfaBot WS-24 Cordless Electric Mop User Manual

Model: WS24

Brand: AlfaBot

## Introduction




The AlfaBot WS-24 Cordless Electric Mop is designed to simplify your floor cleaning routine. Featuring powerful dual spinning heads, an integrated water spray function, and an LED headlight, it provides efficient and thorough cleaning for various floor types, including hardwood and tile. Its lightweight and cordless design ensures ease of use and maneuverability, reducing physical strain during cleaning.

## Product Components

Before assembly, ensure all components are present:

- Mop Head Assembly
- Adjustable Handle Sections
- Charging Adapter

- Cleaning Pads (Grey for daily cleaning/waxing, White for deep cleaning/hair)
- Measuring Cup
- User Manual




*Image: Two types of cleaning pads included with the AlfaBot WS-24.*

## Setup Guide

### 1. Assembly

Connect the handle sections by aligning the pins with the holes and pushing them firmly together until they click into place. Attach the assembled handle to the mop head by inserting the lower end of the handle into the designated slot on the mop head until it is securely fastened.

### 2. Charging

Before first use, fully charge the mop for approximately 4 hours. Connect the charging adapter to the charging port located on the

mop head and plug it into a standard electrical outlet. The indicator light will show charging status.




*Image: The AlfaBot WS-24 mop connected to its charging adapter.*

### 3. Filling the Water Tank

Open the water tank cap located on the top of the mop head. Use the provided measuring cup to fill the 180ml water tank with clean water or a suitable floor cleaning solution. Close the cap securely after filling.




*Image: Filling the water tank of the AlfaBot WS-24 mop.*

### 4. Attaching Cleaning Pads

Align the cleaning pads with the hook-and-loop fasteners on the bottom of the mop head. Press firmly to ensure they are securely attached. Ensure both pads are properly centered for optimal performance.

## Operating Instructions

### Power On/Off

Press the power button on the handle to turn the mop on. The dual spinning heads will begin to rotate. Press the power button again to turn the mop off.

### Water Spray Function

While the mop is powered on, press the water spray button on the handle to dispense water or cleaning solution onto the floor. This function is ideal for wet mopping and tackling stubborn stains.

### LED Headlight

The integrated LED headlight automatically illuminates the cleaning path, making it easier to spot dirt and debris in dimly lit areas, under furniture, or in corners.

### Mopping

Guide the mop across the floor. The dual spinning heads, rotating at 150r/min, will automatically propel the mop forward, requiring minimal effort from the user. The mop's adjustable length (37.4" to 48.4") and swivel steering (180° left-to-right, 90° front-to-back) allow for comfortable use and access to hard-to-reach areas.




*Image: The powerful dual spin heads of the AlfaBot WS-24.*




*Image: Adjustable handle length for ergonomic use.*




*Image: Swivel steering and low profile for reaching tight spaces.*




*Image: Suitable for various floor surfaces including wood, marble, and tile.*

*Video: Demonstrating the AlfaBot WS-24 Electric Mop in action, showcasing its cleaning capabilities on various surfaces and ease of use.*

## Maintenance

### Cleaning Pads

The cleaning pads are machine washable. After each use, remove the pads from the mop head and wash them with mild detergent. Air dry completely before reattaching or storing. Regular cleaning of the pads ensures optimal cleaning performance.

### Water Tank Care

After each use, empty any remaining water or solution from the tank. Rinse the tank with clean water to prevent residue buildup. For deep cleaning, periodically flush the tank with a mixture of water and white vinegar to prevent mineral deposits, especially if using hard water.

### General Cleaning and Storage

Wipe down the exterior of the mop with a damp cloth. Do not submerge the mop head in water. Store the mop in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the mop is fully charged before long-term storage to maintain battery health.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Mop does not turn on | Battery is low or depleted | Charge the mop fully (approx. 4 hours). |
| Water spray not working | Water tank is empty or nozzle is clogged | Refill the water tank. Check the spray nozzle for blockages and clean if necessary. |
| Reduced cleaning performance | Cleaning pads are dirty or worn | Clean or replace the cleaning pads. |
| Mop stops unexpectedly | Battery is depleted | Recharge the mop. |

## Specifications

| Feature | Detail |
|---|---|
| Brand | AlfaBot |
| Model Name | WS24 |
| Special Feature | Portable, Adjustable Height, Lightweight, Edge Cleaning, Cordless |
| Surface Recommendation | Floor |
| Included Components | User Manual, Measuring Cup, Cleaning Pad |
| Wattage | 30.0 W |
| Item Weight | 2.25 Kilograms (4.95 pounds) |
| Tank Volume | 180 Milliliters |
| Form Factor | Mop |
| Color | White |
| Power Source | Battery Powered |
| Capacity | 400 Milliliters (overall liquid capacity) |
| Style | Modern |

| Feature | Detail |
| --- | --- |
| UPC | 756329424996 |
| Package Dimensions | 17.04 x 12.83 x 4.53 inches |
| Manufacturer | AlfaBot |
| Country of Origin | China |
| Batteries | 1 Lithium Ion battery required (included) |
| Date First Available | August 29, 2024 |

## Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the warranty card included with your product or visit the official AlfaBot website. Keep your purchase receipt as proof of purchase for any warranty claims.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question