KAWADA KG-039

Kawada Nansupi Number Speed Brain Training Game KG-039 Instruction Manual

Model: KG-039 | Brand: KAWADA

Introduction Package Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The Kawada Nansupi Number Speed (Model KG-039) is an interactive brain training game designed to enhance concentration, attention, and memory. Suitable for ages 6 and above, this compact device offers three distinct game modes to keep players engaged and mentally stimulated. Its intuitive design and satisfying button feedback make it an enjoyable tool for cognitive exercise.



Image: The Kawada Nansupi Number Speed game unit with various game cards.

2. Package Contents

Verify that all items listed below are included in your package:

- Main Unit (x1)
- Instruction Manual (x1)

- Game Cards (Total 40 cards), including:
  - 3x3 Cards
  - 4x4 Cards
  - 5x5 Cards
  - 5x5 Odd/Even Cards
  - 5x5 Random Number Cards
  - 5x5 Challenge Cards



Image: A visual representation of the main unit, instruction manual, and the 40 assorted game cards.

3. Setup

3.1 Battery Installation

The Nansupi game requires batteries for operation. Please refer to the battery compartment on the device for specific battery type and installation instructions. Ensure correct polarity when inserting batteries.

3.2 Inserting Game Cards

To begin a game, select a desired game card and gently slide it into the designated slot on the main unit. The card should fit snugly over the buttons, aligning the numbers or patterns with the corresponding button positions.



Image: Visual instructions demonstrating card selection, card insertion, and pressing buttons for gameplay.

3.3 Initial Power On

Press the power button located on the top of the unit to turn it on. The display will light up, indicating the device is ready for use.

Your browser does not support the video tag.

Video: This video demonstrates the process of inserting a game card and initiating gameplay on the Nansupi device.

4. Operating Instructions

The Nansupi game features three primary modes to challenge your cognitive skills:

4.1 Speed Press Mode

In this mode, your goal is to press the numbered buttons in ascending order as quickly as possible. After inserting a card and pressing the start button, identify the smallest number displayed and press its corresponding button. Continue this sequence until all numbers are pressed. The game records your completion time, allowing you to compete for speed.

4.2 Sequence Memory Mode

This mode tests your short-term memory. After pressing the start button, a sequence of lights will flash on the buttons. Observe and remember the order and position of these flashing lights. Once the sequence finishes, reproduce it by pressing the buttons in the exact same order. You have three attempts; making three mistakes will result in a game over.

4.3 Graphic Memory Mode

In Graphic Memory Mode, the device will light up a pattern of buttons. Your task is to remember all the lit-up button positions and then reproduce the entire pattern by pressing those buttons. Similar to Sequence Memory, you have three chances to correctly reproduce the pattern before failing the game.



Image: This image illustrates the different types of game cards and the two mini-games (Sequence Memory and Graphic Memory) available.

5. Maintenance

To ensure the longevity and optimal performance of your Nansupi game, follow these maintenance guidelines:

- **Cleaning:** Wipe the main unit and cards with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as they may damage the surface.
- **Storage:** Store the game in a cool, dry place away from direct sunlight and extreme temperatures. Keep the cards organized to prevent loss or damage.

- **Battery Care:** Remove batteries if the device will not be used for an extended period to prevent leakage.

6. Troubleshooting

If you encounter any issues with your Nansupi game, please try the following solutions:

- **Device does not power on:**
  - Check if the batteries are correctly installed with the proper polarity.
  - Replace old batteries with new ones.
- **Buttons are unresponsive:**
  - Ensure the game card is properly inserted and aligned.
  - Clean the surface of the buttons and the card to remove any debris.
- **Display is not working:**
  - Turn the device off and on again.
  - Check battery levels.

If the problem persists after trying these steps, please contact customer support.

7. Specifications

Brand	KAWADA
Model Number	KG-039
Material	Plastic
Genre	Memory Game
Product Dimensions (L x W x H)	24 cm x 16 cm x 6 cm
Batteries Required	Yes
Recommended Minimum Age	6 years
Country of Origin	Japan

8. Warranty & Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official KAWADA website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 KAWADA. All rights reserved.