Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NutriChef NC12BGREEN

NutriChef 1.6 QT Portable Electric Rice Cooker & Lunch Maker User Manual

Model: NC12BGREEN

Introduction

Thank you for purchasing the NutriChef 1.6 QT Portable Electric Rice Cooker & Lunch Maker. This multi-functional appliance is designed for convenient and efficient cooking of various dishes, including rice, soup, stew, porridge, noodles, and hot pot. Its compact design and non-stick ceramic coating make it ideal for everyday use and easy cleaning. Please read this manual thoroughly before operation to ensure safe and optimal performance.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance has an automatic power-off feature and anti-burn dry technology for enhanced safety.



Image: The NutriChef rice cooker highlighting its safety features, including automatic power-off, dual security protection, and anti-burn dry technology.

What's Included

Your NutriChef 1.6 QT Portable Electric Rice Cooker & Lunch Maker package includes the following components:

- Electric Cooker (Main Unit)
- Inner Pot (with non-stick ceramic coating)
- Instruction Manual (this document)
- Measuring Cup
- Power Cord



Image: A visual representation of the NutriChef electric cooker, measuring cup, and power cord, along with product dimensions.

Product Features

- **Versatile Cooking Options:** Features 6 cooking programs for rice, soup, stew, porridge, noodles, and hot pot.
- **Efficient Heating:** 600W heating element with a full-circle heating plate ensures rapid and uniform cooking.
- **Enhanced Safety:** Includes automatic power-off, anti-burn dry technology, and double security protection.
- **Non-Stick Ceramic Coating:** Simplifies cleaning and promotes healthier cooking.
- **Intuitive Digital Control Panel:** User-friendly interface with clearly labeled buttons for effortless operation.
- **Keep Warm Function:** Automatically keeps meals warm for up to 2 hours after cooking.
- **Portable Design:** Compact and easy to carry, suitable for home, dorms, and travel.
- **Durable Material:** Constructed from heat and impact-resistant polypropylene (PP).



Image: The NutriChef rice cooker demonstrating its six versatile cooking functions: Rice, Soup, Stew, Porridge, Noodles, and Hot Pot.



Image: A close-up of the NutriChef rice cooker's digital control panel, showing the user-friendly interface and buttons for various functions.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check all parts for any signs of damage. Do not use if any part is damaged.
3. **Clean:** Before first use, wash the inner pot, measuring cup, and lid with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. **Placement:** Place the electric cooker on a stable, flat, heat-resistant surface, away from water sources and direct heat. Ensure adequate ventilation around the unit.
5. **Insert Inner Pot:** Place the cleaned inner pot securely into the main unit.
6. **Connect Power:** Plug the power cord into the cooker's port, then plug the other end into a standard 110V electrical outlet.

Operating Instructions

General Operation:

1. Add ingredients to the inner pot according to your recipe. Do not exceed the maximum fill line.
2. Close the lid securely.
3. Ensure the cooker is plugged into a power outlet.
4. Press the "Function" button on the digital control panel to cycle through the available cooking programs (Rice, Soup, Stew, Porridge, Noodles, Hot Pot).
5. Once the desired function is selected, the cooker will automatically begin the cooking process.
6. The digital display will show the remaining cooking time or a countdown.
7. Upon completion of the cooking cycle, the cooker will automatically switch to "Keep Warm" mode (if applicable for the selected function).
8. To turn off the cooker, press the "OFF" button.

Specific Functions:

- **Rice:** Use the provided measuring cup for accurate rice and water ratios. Typically, 1 cup of rice requires 1.5-2 cups of water.
- **Soup/Stew/Porridge/Noodles/Hot Pot:** Add ingredients and liquid as per your recipe. The cooker will maintain a consistent temperature for simmering.

Timer Delay Function:

The "Timer Delay" function allows you to set a delayed start time for your cooking. Consult the specific recipe and desired meal time to utilize this feature.

1. Add ingredients to the inner pot.
2. Press the "Timer Delay" button.
3. Use the function buttons to adjust the delay time.
4. Confirm your selection. The cooker will start automatically after the set delay time.

Keep Warm Function:

After most cooking cycles, the appliance will automatically switch to "Keep Warm" mode, maintaining the food's temperature for up to 2 hours. To manually activate or deactivate "Keep Warm" mode, press the "Keep Warm" button.



Image: The NutriChef rice cooker demonstrating its automatic keep-warm mode, ensuring meals stay ready to serve.

Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your NutriChef rice cooker. Always unplug the appliance and allow it to cool completely before cleaning.

- **Inner Pot:** The non-stick ceramic coating makes cleaning easy. Wash the inner pot with warm, soapy water using a soft sponge or cloth. Do not use abrasive cleaners, metal scouring pads, or harsh chemicals, as these can damage the non-stick surface. Rinse thoroughly and dry completely.
- **Lid:** Wash the lid with warm, soapy water, rinse, and dry.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit, power cord, or plug in water or any other liquid.
- **Storage:** Ensure all parts are clean and dry before storing. Store the cooker in a cool, dry place.



Image: The non-stick ceramic coating of the inner pot and the superior heat distribution system of the NutriChef rice cooker.

Troubleshooting

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outlet malfunction; damaged cord/plug.	Ensure the power cord is securely plugged into both the cooker and a working electrical outlet. Check the circuit breaker. If cord/plug is damaged, do not use and contact customer support.
Food is undercooked or overcooked.	Incorrect water/ingredient ratio; incorrect function selected; lid not properly sealed.	Refer to recipe for correct ratios. Ensure the correct cooking function is selected. Make sure the lid is securely closed during cooking.
Food sticks to the inner pot.	Insufficient liquid; non-stick coating damaged; food left in "Keep Warm" for too long.	Ensure adequate liquid is used. Avoid using metal utensils that can scratch the coating. Remove food promptly after cooking or "Keep Warm" cycle.

Problem	Possible Cause	Solution
Steam leaking from lid.	Lid not properly seated; lid seal dirty or damaged.	Ensure the lid is correctly positioned and sealed. Clean the lid and its sealing gasket. If the seal is damaged, contact customer support.

Specifications

- **Brand:** NutriChef
- **Model Name:** NC12BGREEN
- **Capacity:** 1.6 Liters
- **Power Source:** Corded Electric
- **Voltage:** 110 Volts
- **Wattage:** 600 watts
- **Product Dimensions (D x W x H):** 9.84" x 7.48" x 6.69"
- **Item Weight:** 2.53 pounds
- **Material:** Polypropylene (PP)
- **Lid Material:** Plastic
- **Special Features:** Automatic Shut Off, Boil Dry Protection, Non-Stick, Portable, Programmable
- **Product Care Instructions:** Hand Wash (Inner Pot)

Warranty and Support

For warranty information, technical support, or service inquiries, please contact NutriChef customer service. Keep your purchase receipt as proof of purchase for any warranty claims.
NutriChef Customer Service: Please refer to the contact information provided on the product packaging or the official NutriChef website for the most up-to-date support details.

© 2024 NutriChef. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG35Q4TL

More documents and user manuals: **https://manuals.plus/**