Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AMOROM B0DG55STNP

AMOROM Smart Air Tag Bluetooth Tracker User Manual

Model: B0DG55STNP

1. Introduction

The AMOROM Smart Air Tag Bluetooth Tracker is designed to help you locate your valuable items quickly and efficiently. Compatible with both iOS and Android devices, this tracker uses Bluetooth technology to keep track of your belongings within a certain range. It features a loud alarm, a phone-finding function, and a replaceable battery for extended use.

2. Package Contents

Please verify that all items are present in your package:

- AMOROM Smart Air Tag Bluetooth Tracker (4 units)
- CR2032 Batteries (4 units, pre-installed)
- Additional CR2032 Battery (1 unit)
- Battery Remover Tool
- Lanyards/Cords (4 units)
- User Manual



Image: Contents of the AMOROM Smart Air Tag package, showing the tracker dimensions, included CR2032 battery, remover tool, and instructions.

3. Setup

3.1 Download the iSearching App

To use your AMOROM Smart Air Tag, you must download the 'iSearching' application on your smartphone or tablet. The app is compatible with both iOS and Android devices.

1. Scan the QR code provided in the included user manual or on the product packaging.
2. Alternatively, search for 'iSearching' in the Apple App Store (for iOS) or Google Play Store (for Android) and install the application.
3. Follow the on-screen instructions to grant necessary permissions (e.g., Bluetooth, location services) for the app to function correctly.

3.2 Pairing the Tracker with Your Device

Once the app is installed and permissions are granted:

1. Ensure Bluetooth is enabled on your smartphone or tablet.
2. Open the 'iSearching' app.
3. Press and hold the button on your AMOROM Smart Air Tag until you hear a beep or see an indicator light (if applicable).
4. In the app, tap the '+' icon or 'Add Device' option to search for nearby trackers.
5. Select your AMOROM Smart Air Tag from the list of discovered devices to complete the pairing process.
6. You can rename your tracker within the app for easier identification (e.g., "Keys," "Wallet," "Bag").

4. Operating Instructions

4.1 Find Nearby Items

When your item is within Bluetooth range (approximately 15-20 meters, depending on obstacles), you can make the tracker ring to locate it.

- Open the 'iSearching' app on your paired device.
- Select the desired AMOROM Smart Air Tag from your device list.
- Tap the 'Alert' or 'Ring' button within the app.
- The tracker will emit a loud sound (up to 100 decibels) to help you pinpoint its location.



Image: A hand holding a smartphone displaying the iSearching app, with an AMOROM tracker on a sofa in the background, illustrating the 'Find Nearby' function with a loud ring.

4.2 Find Your Phone

If you misplace your phone, your AMOROM Smart Air Tag can help you find it, even if your phone is in silent mode.

- Double-click the button on your AMOROM Smart Air Tag.
- Your paired smartphone will ring, allowing you to locate it.



Image: A hand holding an AMOROM tracker, while a smartphone screen displays a notification indicating the tracker is searching for the phone, demonstrating the 'Find Your Phone' feature.

4.3 Disconnection Alert

The tracker provides an alert when it disconnects from your phone, helping you prevent loss.

- If the Bluetooth connection between your phone and the tracker is lost (e.g., you move out of range), both the tracker and your phone will emit an alert sound (approximately 30 seconds).
- You will also receive an instant notification on the 'iSearching' app, indicating the disconnection.



Image: An AMOROM tracker attached to keys on a table, with a smartphone displaying a 'Disconnect' notification, illustrating the disconnection reminder feature as a person walks away.

4.4 Multi-functional Use

The AMOROM Smart Air Tag can be attached to various items to help you keep track of them.

- **Keys:** Attach to your house or car keys.
- **Luggage/Bags:** Secure to suitcases, backpacks, or handbags.
- **Wallets:** Place inside your wallet or purse.
- **Other Valuables:** Use with cameras, pet collars, or other items you wish to track.



Image: A collage of images demonstrating various uses for the AMOROM tracker, including attachment to keys, a wallet, a backpack, luggage, a camera, and a gift, highlighting its versatility.

5. Maintenance

5.1 Battery Replacement

The AMOROM Smart Air Tag uses a replaceable CR2032 coin cell battery, offering up to 6 months of use. When the battery is low, the app may notify you, or the tracker's performance may diminish.

1. Locate the small groove on the side of the tracker.
2. Insert the provided battery remover tool (or a similar thin, flat object) into the groove.
3. Gently pry open the tracker's casing by tilting the tool upwards at a 45-degree angle.
4. Remove the old CR2032 battery.
5. Insert a new CR2032 battery with the positive (+) side facing upwards.
6. Align the two halves of the tracker and press firmly until the cover snaps securely into place.



Image: A three-step diagram illustrating the battery replacement process for the AMOROM tracker: 1. Using a tool to open the cover, 2. Replacing the battery with the positive terminal facing up, 3. Closing the cover.

6. Troubleshooting

If you encounter issues with your AMOROM Smart Air Tag, please refer to the following common solutions:

Problem	Possible Cause / Solution
Tracker does not connect or frequently disconnects.	• Ensure Bluetooth is enabled on your phone. • Check if the tracker is within the 15-20 meter Bluetooth range. Obstacles like walls or furniture can reduce range. • Verify the battery level of the tracker. Replace if low. • Restart the 'iSearching' app and/or your phone. • Unpair and re-pair the tracker in the app.
Cannot hear the tracker's alarm.	• Ensure the tracker is within Bluetooth range. • Check the battery level. A low battery may result in a weaker sound. • Ensure there are no obstructions muffling the sound.
Phone does not ring when double-clicking the tracker.	• Ensure the tracker is paired and connected to your phone via Bluetooth. • Verify that the 'iSearching' app has permission to play sounds/notifications even in silent mode. • Check the tracker's battery level.
App shows inaccurate location or is unresponsive.	• The AMOROM Smart Air Tag is a Bluetooth tracker, not a GPS device. Its location accuracy depends on its proximity to your phone. • Ensure the 'iSearching' app has location permissions enabled. • Close and reopen the app. • Update the app to the latest version.

Problem	Possible Cause / Solution
Tracker beeps unexpectedly.	• This could be a disconnection alert. Check your phone for notifications. • A low battery can sometimes cause erratic behavior. Replace the battery. • If the issue persists, try resetting the tracker (refer to app settings or contact support).

7. Specifications

- **Brand:** AMOROM
- **Model:** B0DG55STNP
- **Connectivity Technology:** Bluetooth
- **Compatible Devices:** Smartphone, Tablet (iOS and Android)
- **Control Method:** Application ('iSearching' app)
- **Battery Type:** CR2032 (replaceable)
- **Battery Life:** Approximately 6 months
- **Number of Items:** 4 trackers
- **Material:** Plastic or composite materials
- **Bluetooth Range:** 15-20 meters (unobstructed)
- **Alarm Sound Level:** Up to 100 dB

8. Safety Information

- Keep the device and batteries out of reach of children and pets. Swallowing a coin cell battery can be dangerous.
- Do not expose the device to extreme temperatures, direct sunlight, or moisture.
- Do not attempt to disassemble or modify the device beyond battery replacement.
- Dispose of batteries and the device according to local regulations.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official AMOROM website. Please have your product model number (B0DG55STNP) and purchase date available when contacting support.

© 2024 AMOROM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG55STNP

More documents and user manuals: **https://manuals.plus/**