Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lenmen HP006

Lenmen Graphene-Infused Heating Pad User Manual

Model: HP006

Important Safety Information

It is crucial to read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Always unplug the heating pad when not in use.** This prevents accidental activation and conserves energy.
- **Do not use while sleeping.** Prolonged direct contact with heat can cause burns.
- **Keep the heating pad away from flammable materials.** Ensure no curtains, bedding, or other combustible items are in direct contact with the pad during operation.
- **Do not use if you have a medical condition that makes you sensitive to heat.** Consult a healthcare professional if you have conditions such as diabetes, circulatory problems, or nerve damage.
- **Keep out of reach of children and pets.** This product is not a toy and should not be used by individuals who cannot operate it safely.
- **Do not use if the cord is damaged.** Inspect the power cord regularly for any signs of wear, cuts, or fraying. If damaged, discontinue use immediately and contact customer support.
- **Consult a doctor before use if you are pregnant or have a medical condition.**
- Do not use pins or other metallic objects to fasten the heating pad. This can damage the internal wiring and create a shock hazard.
- Do not fold or crease the heating pad tightly during use. This can damage the heating elements.
- Do not dry clean. Follow cleaning instructions carefully.

Product Overview

The Lenmen Graphene-Infused Heating Pad (Model HP006) is designed to provide targeted heat therapy for various body areas, including the neck, shoulders, and back. Its graphene infusion technology allows for deeper heat penetration, while the weighted design ensures optimal contact and comfort. The pad features multiple heat settings and an auto-off timer for

personalized and safe use.



Image: The Lenmen Graphene-Infused Heating Pad, showing its ergonomic shape, integrated controller, and product packaging. The pad is gray and designed to drape over the neck and shoulders.

Key Features:

- **Graphene-Infused Fabric:** For deeper heat penetration and more effective muscle relaxation.
- **Extended Heating Coil (354"):** Ensures faster heating and wider, denser heat distribution.
- **Ergonomic Weighted Design:** Conforms to body contours for optimal comfort and stability, especially around the neck and shoulders.
- **6 Temperature Settings:** Ranging from 108°F to 144°F (42°C to 62°C) for customized warmth.
- **4 Auto-Off Timer Options:** 0.5h, 1h, 1.5h, 2h for safety and convenience.
- **Soft Micro Plush Flannel:** Provides a luxurious and comfortable feel.
- **Machine-Washable:** Easy to clean after removing the controller.

Setup and Initial Use

1. **Unpack the Heating Pad:** Carefully remove the heating pad and its controller from the packaging. Inspect for any visible damage.
2. **Connect the Controller:** Ensure the controller cable is securely plugged into the heating pad's connector. The connection should be firm.
3. **Plug into Power Outlet:** Insert the power plug into a standard 120V AC electrical outlet.
4. **Position the Pad:** Place the heating pad on the desired body area (neck, shoulders, back, abdomen, legs, or arms). The weighted edges will help it drape naturally.



Image: A woman comfortably seated, wearing the Lenmen heating pad draped over her neck and shoulders, illustrating its ergonomic fit and intended use.

Operating Instructions

Using the LED Controller:



Image: A close-up view of the Lenmen heating pad's LED controller, showing the power button, temperature adjustment buttons, and timer button, with the display showing "6" for the highest heat setting.

1. **Power On/Off:** Press the power button (●) to turn the heating pad on or off. The LED display will illuminate when powered on.
2. **Adjust Temperature:** Use the temperature adjustment buttons (+ / -) to cycle through the 6 heat settings. The current setting will be displayed on the LED screen. The temperature range is 108°F (42°C) to 144°F (62°C).
3. **Set Timer:** Press the timer button () to select an auto-off duration. Options include 0.5 hours, 1 hour, 1.5 hours, and 2 hours. The selected timer setting will be indicated on the display or by a specific light.

4. **Automatic Shut-off:** The heating pad will automatically turn off after the selected timer duration has elapsed, or after 2 hours if no timer is set, as a safety feature.

Recommended Usage:

For optimal pain relief and comfort, apply the heating pad directly to the affected area. Start with a lower heat setting and gradually increase if needed. Do not use for more than 20-30 minutes at a time, especially on higher settings, to prevent skin irritation or burns. Allow the skin to cool completely between sessions.



Image: A collage showing the versatility of the Lenmen heating pad, demonstrating its use on the back, thighs, neck & shoulder, and abdomen, highlighting its adaptability for various body parts.

Maintenance and Care

Cleaning Instructions:

The Lenmen heating pad is machine-washable for easy cleaning. Follow these steps:

1. **Disconnect Power:** Always unplug the heating pad from the electrical outlet and disconnect the controller from the pad before cleaning.
2. **Machine Wash:** Place the heating pad in a washing machine. Use cold water on a gentle cycle. Do not use bleach or harsh detergents.
3. **Tumble Dry:** Tumble dry on low heat or air dry. Ensure the heating pad is completely dry before reconnecting the controller and using it again. Do not iron.



Image: A woman placing the Lenmen heating pad into a washing machine, demonstrating the ease of cleaning after disconnecting the controller.

Storage:

When not in use, store the heating pad in a cool, dry place. Do not wrap the cord tightly around the controller or the pad, as this can damage the wiring. Store it loosely folded or laid flat.

Troubleshooting

Problem	Possible Cause	Solution
Heating pad does not turn on.	Not plugged in; controller not connected; power outage; damaged cord.	Ensure plug is fully inserted into outlet. Check controller connection. Verify power to outlet. Inspect cord for damage; if damaged, discontinue use.
Heating pad is not heating sufficiently.	Incorrect heat setting; auto-off timer activated; internal issue.	Increase heat setting using the controller. Check if timer has expired. If problem persists, contact customer support.
Controller display is not working.	Power issue; controller malfunction.	Ensure power is connected. Try unplugging and replugging. If still not working, contact customer support.
Pad feels too hot.	Heat setting is too high; prolonged use.	Reduce heat setting. Discontinue use immediately if discomfort occurs. Do not use for extended periods.

Specifications

- **Model:** HP006
- **Brand:** Lenmen
- **Material:** Cotton, Polyester
- **Color:** Gray
- **Item Weight:** 2.09 Pounds (0.95 Kilograms)
- **Package Dimensions:** 8.7 x 7.91 x 4.06 inches
- **Number of Heat Settings:** 6 (108°F ~ 144°F / 42°C ~ 62°C)
- **Auto-Off Timer Options:** 0.5h, 1h, 1.5h, 2h
- **Power Source:** AC 120V (Standard US Outlet)

Warranty and Support

Lenmen products are manufactured with quality and durability in mind. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Lenmen website.

If you encounter any issues or have questions about your Lenmen Graphene-Infused Heating Pad, please contact our customer support team:

- **Customer Support:** Refer to contact information provided on the product packaging or the official Lenmen website.
- **Online Resources:** Visit the Lenmen Store on Amazon for FAQs and additional product information.

© 2025 Lenmen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG5DRZWD

More documents and user manuals: **https://manuals.plus/**