Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MR5125303

8 Ft. Giant Animated Gargoyle Pillar Instruction Manual

Model: MR5125303

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your 8 Ft. Giant Animated Gargoyle Pillar. This oversized Halloween decoration is designed to enhance your haunted house setting with its imposing presence, dynamic lighting, and eerie sound effects. Please read this manual thoroughly before setup and operation to ensure safe and proper use.

Important Safety Information

For your safety and to prevent damage to the product, please observe the following warnings:

- **Indoor use only:** This product is designed for indoor use. Do not expose to moisture, rain, or extreme temperatures.
- **Age Restriction:** Not suitable for children under 14 years of age.
- **Supervision:** Always supervise children when around the display.
- **Placement:** Ensure the prop is placed on a stable, level surface to prevent tipping.
- **Battery Safety:** Use only the specified battery type (3 AA batteries, not included). Do not mix old and new batteries, or different types of batteries. Remove batteries if the product is not used for an extended period.

Package Contents

Please verify that all components are present before beginning assembly:

- 1 x Gargoyle Figure
- 1 x Pillar Base (multi-part assembly)
- Assembly Hardware (screws, connectors, etc.)
- Instruction Manual



Image: The complete 8 Ft. Giant Animated Gargoyle Pillar, showcasing its full height and detailed design.

Setup and Assembly

The 8 Ft. Giant Animated Gargoyle Pillar requires simple assembly. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Assemble Pillar Sections:** Connect the individual sections of the granite-look pillar according to the included assembly diagram. Ensure all connections are secure.
3. **Attach Gargoyle Figure:** Securely attach the gargoyle figure to the top of the assembled pillar. Ensure it is firmly seated and stable.
4. **Install Batteries:** Locate the battery compartment, typically at the base or rear of the gargoyle figure. Insert 3 AA batteries (not included), observing correct polarity (+/-). Close the battery compartment securely.
5. **Positioning:** Place the assembled Gargoyle Pillar on a stable, level surface in your desired indoor location. Ensure there is enough space around the prop for its effects to be appreciated and for safe passage.



Image: Side view of the Gargoyle Pillar, illustrating its profile and the texture of the pillar.

Operating Instructions

The Gargoyle Pillar features dynamic lighting and sound effects with multiple operating modes:

1. **Locate Control Switch:** Find the control switch, usually located on the back or base of the gargoyle figure.
2. **Select Operating Mode:**
    - **ON:** In this mode, the LED light-up eyes and mouth will glow red, and the blue uplights on the pedestal will illuminate continuously. The sound effects (bell tolls, crows cawing, eerie insect noises) will play in a continuous loop.
    - **SENSOR:** This is the recommended mode for interactive display. The prop will remain dormant until its motion sensor is activated. Upon activation, the red LED eyes and mouth will glow, blue uplights will illuminate, and the spine-tingling sound effects will play. After a short duration, the effects will cease until the sensor is triggered again.
    - **OFF (Try-Me Function):** This mode turns off all functions. It can also be used for a "Try-Me" demonstration if the product has a dedicated button for this feature.
3. **Activation:** For "SENSOR" mode, ensure the sensor is unobstructed and facing the area where movement is expected.



Image: The Gargoyle Pillar illuminated with blue uplighting and red glowing eyes, set within a spooky, fog-filled environment, demonstrating its activated state.



Image: A detailed close-up of the gargoyle's face, highlighting its menacing expression, sharp teeth, and the texture of its stone-like skin.

Maintenance

Proper maintenance will ensure the longevity of your Animated Gargoyle Pillar:

- **Cleaning:** Dust the prop regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Storage:** When not in use, store the prop in its original packaging or a protective container in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the lights dim or sounds become distorted. Always replace all batteries at the same time.

Troubleshooting

Problem	Possible Cause	Solution
Prop does not turn on or activate.	Batteries are dead or incorrectly installed. Control switch is in "OFF" position. Sensor is obstructed or not triggered (in SENSOR mode).	Replace batteries, ensuring correct polarity. Set control switch to "ON" or "SENSOR". Ensure sensor is clear and test by moving in front of it.
Lights are dim or sounds are distorted.	Low battery power.	Replace all batteries with fresh ones.
Prop activates unexpectedly or not at all in SENSOR mode.	Sensor sensitivity. Environmental factors (e.g., drafts, light changes).	Adjust placement to optimize sensor range. Ensure sensor is not exposed to direct light sources or strong air currents.

Specifications

Model Number	MR5125303
Dimensions (L x W x H)	0.1 x 0.1 x 96 inches (approx. 8 ft tall)
Item Weight	37 pounds
Power Source	3 x AA Batteries (not included)
Materials	Metal frame, Plastic shell, Fabric elements
Light Color	Red (eyes/mouth), Blue (uplights)
Recommended Use	Indoor Halloween Displays, Haunted Houses, Themed Events

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the manufacturer's official website. Keep your purchase receipt as proof of purchase.

© 2024 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG62QGNG

More documents and user manuals: **https://manuals.plus/**