Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LawnMaster CLMF4819A

LawnMaster CLMF4819A 48V MAX* 19-inch Brushless Cordless Mower User Manual

Model: CLMF4819A
Brand: LawnMaster

Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your LawnMaster CLMF4819A 48V MAX* 19-inch Brushless Cordless Mower. Please read this manual thoroughly before operating the machine to ensure proper use and to prevent injury or damage.

Safety Instructions

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the appliance.
- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and sturdy footwear.
- Keep children and bystanders away from the operating area.
- Do not operate the mower in wet conditions or rain.
- Inspect the area to be mowed and remove any objects that could be thrown by the blade.
- Ensure the battery is fully charged before use and remove it when not in use or during maintenance.

Package Contents

Verify that all items are present in the package:

- LawnMaster CLMF4819A 19-inch Brushless Cordless Mower
- 2 x 24V MAX* 4.0Ah Lithium-ion Batteries
- Dual Charger
- Grass Collection Bag
- Side Discharge Chute
- Mulching Plug
- User Manual

Setup

Assembling the Mower

1. **Handle Assembly:** Unfold the handle and secure it in place using the quick-release levers or knobs provided. Ensure the handle is firmly locked.
2. **Grass Collection Bag:** Assemble the grass collection bag according to the instructions and attach it to the rear discharge opening of the mower.
3. **Battery Installation:** Insert the two 24V MAX* 4.0Ah batteries into the battery compartments. Ensure they click into place securely.

Charging the Batteries

The batteries may not be fully charged upon purchase. It is recommended to fully charge them before first use.

1. Connect the dual charger to a standard power outlet.
2. Insert the 24V MAX* 4.0Ah batteries into the charging slots.
3. The charging indicator lights on the charger will show the charging status. A full charge typically takes 2-4 hours.
4. Once fully charged, remove the batteries from the charger.



Image: The LawnMaster CLMF4819A 19-inch cordless mower shown with its two 24V batteries and the dual charger. The mower is orange and black, with a foldable handle. The batteries and charger are black.

Operating Instructions

Starting the Mower

1. Ensure batteries are fully charged and properly inserted.
2. Press and hold the safety button, then pull the bail switch lever towards the handle. The motor will start.
3. Release the safety button once the motor is running.

Adjusting Cutting Height

The mower offers 6 cutting positions, ranging from 1.4 inches to 3.4 inches.

- Locate the single-point height adjustment lever on the side of the mower.
- Pull the lever outwards and move it to the desired height setting.
- Ensure all wheels are at the same height setting before operation.

Mowing Techniques

- For best results, mow dry grass.
- Overlap cutting swaths slightly to ensure even coverage.
- The iPOWER TECHNOLOGY DISPLAY indicates the cutting mode and battery level, helping optimize energy use.
- Utilize the 3-in-1 function: bagging, side discharge, or mulching, based on your lawn care needs.

Maintenance

General Cleaning

- After each use, disconnect the batteries and clean the mower deck and exterior with a damp cloth.
- Remove any grass clippings or debris from the blade area.
- Do not use water hoses or high-pressure washers directly on the mower.

Blade Care

- Regularly inspect the blade for sharpness and damage. A dull blade can tear grass, leading to an unhealthy lawn.
- If the blade is dull or damaged, have it sharpened or replaced by a qualified service technician.
- Always wear heavy-duty gloves when handling the blade.

Battery Storage

- Store batteries in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, charge batteries to approximately 50% capacity.

Troubleshooting

Problem	Possible Cause	Solution
Mower does not start	Batteries not inserted correctly Batteries not charged Safety button or bail switch not engaged	Ensure batteries are fully seated. Charge batteries fully. Engage safety button and pull bail switch.
Reduced cutting performance	Dull or damaged blade Grass too wet or too tall Grass collection bag full	Sharpen or replace blade. Mow dry grass; raise cutting height. Empty grass collection bag.
Mower stops during operation	Batteries depleted Overload protection activated	Recharge batteries. Reduce load (e.g., raise cutting height, mow smaller sections).

Specifications

Feature	Detail
Model Number	CLMF4819A
Power Source	2 x 24V MAX* (48V MAX*) Lithium-ion Batteries
Battery Capacity	4.0Ah per battery
Cutting Width	19 inches
Cutting Height Positions	6 positions (1.4 - 3.4 inches)
Motor Type	Brushless
No-Load Speed	3,400 RPM
Runtime	Up to 40 minutes (with 2 x 4.0Ah batteries)
Grass Bag Capacity	15 gallons
Rear Wheel Size	9.3 inches
Functions	Bagging, Side Discharge, Mulching

Warranty and Support

LawnMaster products are designed for durability and performance. For warranty information, technical support, or to purchase replacement parts, please visit the official LawnMaster website or contact their customer service.
Note: Specific warranty terms and conditions may vary. Please refer to the warranty card included with your product or the manufacturer's website for the most current information.
Manufacturer: LawnMaster
Model: CLMF4819A
ASIN: B0DG8PZSQD
For further assistance, you may visit the LawnMaster Store on Amazon.

© 2024 LawnMaster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DG8PZSQD

More documents and user manuals: **https://manuals.plus/**