iScooter iX5S

iScooter iX5S Electric Scooter User Manual

Model: iX5S | Brand: iScooter

1. Important Safety Information

Before operating your iScooter iX5S Electric Scooter, please read this manual thoroughly and understand all safety warnings and instructions. Failure to follow these instructions may result in serious injury or property damage.

- Always wear a helmet and appropriate safety gear (knee pads, elbow pads, wrist guards) when riding.
- Check local laws and regulations regarding electric scooter use.
- Do not ride in wet conditions, heavy rain, or through puddles.
- Ensure all components are securely fastened and brakes are functioning correctly before each ride.
- Maintain a safe speed and distance from other vehicles and pedestrians.
- Avoid riding on uneven terrain, steep inclines, or slippery surfaces unless specifically designed for it and you are experienced.
- Do not perform stunts or dangerous maneuvers.
- The maximum weight capacity is 330 lbs. Do not exceed this limit.
- Keep hands and feet on the handlebars and footboard at all times during operation.

2. Package Contents

Upon opening your iScooter iX5S Electric Scooter package, please verify that all the following items are

included:

- iX5S Electric Scooter (1 unit)
- User Manual (1 unit)
- Screw and screwdriver set (for assembly)
- Power Adapter/Charger
- Storage Bag



Image: The iScooter iX5S Electric Scooter with its main components and accessories.

3. Setup and Assembly

Your iScooter iX5S Electric Scooter comes partially assembled. Follow these steps to complete the setup:

1. **Unboxing:** Carefully remove the scooter and all accessories from the packaging.
2. **Front Wheel Installation:** Attach the front wheel to the fork using the provided screws and tools. Ensure it is securely fastened and the brake disc aligns correctly with the caliper.
3. **Unfolding the Scooter:** Locate the folding mechanism on the stem. Release the latch and carefully lift the handlebar stem until it locks into the upright position. Secure the safety latch.
4. **Handlebar Adjustment:** Adjust the handlebar height to a comfortable riding position and secure it using the quick-release clamp.
5. **Brake Lever Adjustment:** Adjust the angle of the brake levers for comfortable reach. Use the provided Allen wrench to tighten them securely.
6. **Initial Charge:** Before your first ride, fully charge the scooter's battery. Refer to the 'Charging Operation' section for detailed instructions.

Video: Detailed unboxing and assembly guide for the iX5S Electric Scooter. This video demonstrates the steps for installing the front wheel, unfolding the scooter, and adjusting the handlebars.



Image: The iX5S Electric Scooter in its folded state, highlighting its portability and easy folding mechanism.

4. Operating Instructions

Familiarize yourself with the controls and features of your iX5S Electric Scooter for a safe and enjoyable ride.

4.1 Power On/Off

To power on the scooter, insert the key into the ignition and turn it to the 'ON' position. The LCD display will illuminate. To power off, turn the key to the 'OFF' position.

Video: Demonstration of powering on the iX5S Electric Scooter and initial display functions.

4.2 Speed Modes

The iX5S offers four distinct speed settings to suit various riding conditions and preferences:

- **Mode 1:** Approximately 9 MPH (for beginners or crowded areas)
- **ECO Mode:** Approximately 15 MPH (for extended range and moderate speed)
- **NORMAL Mode:** Approximately 21 MPH (for balanced performance)
- **SPORT Mode:** Approximately 28 MPH (for maximum speed and performance)

Switch between modes using the mode button on the handlebar display. The current speed mode will be indicated on the LCD display.

Video: How to switch between different speed modes on the iX5S Electric Scooter.



Image: Visual representation of the four speed modes available on the iX5S Electric Scooter.

4.3 Lighting System

The iX5S is equipped with a comprehensive lighting system for enhanced visibility and safety:

- **Headlight:** Bright front headlight with reflectors for illuminating your path.
- **Taillight:** Rear taillight for visibility from behind.
- **Turn Signals:** Integrated turn signals at the four corners of the deck for indicating turns.
- **Ambient Lights:** Blue ambient side lights for added visibility and style.
- **Brake Light:** The taillight flashes when braking to alert others.

Activate the lights using the dedicated light button on the handlebar.

Video: Demonstration of the iX5S Electric Scooter's lighting system, including headlights, taillights, and turn signals.



Image: The iX5S Electric Scooter's integrated lighting system, showing the headlight, taillight, and ambient lights.

4.4 Braking System

The iX5S features a robust triple braking system for reliable stopping power:

- **Dual Disc Brakes:** Front and rear mechanical disc brakes provide strong stopping force.
- **Electronic Braking System (EABS):** An electronic brake system assists in stopping and can recover energy.

Always use both brake levers simultaneously for optimal and safe braking. Practice braking in a safe, open area before riding in traffic.



Image: Close-up view of the iX5S Electric Scooter's triple braking system, including front and rear disc brakes.

4.5 App Connectivity

Connect your iX5S Electric Scooter to the dedicated smartphone app for additional features and controls. Refer to the app's instructions for pairing and usage.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your iX5S Electric Scooter.

5.1 Battery Charging

To charge the 48V 15Ah battery:

1. Ensure the scooter is powered off.
2. Locate the charging port, usually covered by a rubber flap, on the scooter's deck.
3. Plug the charger into a standard wall outlet, then connect the charging cable to the scooter's charging port.
4. The indicator light on the charger will typically turn red during charging and green when fully charged.
5. Charging time is approximately 8 hours for a full charge.
6. Always disconnect the charger once charging is complete and replace the rubber flap to protect the port.

Video: Instructions on how to properly charge the iX5S Electric Scooter's battery.

5.2 Tire Pressure

Check the tire pressure of the 11-inch pneumatic tires regularly. Maintain the recommended PSI (usually found on the tire sidewall or in the specifications section) for optimal performance and safety.

5.3 Cleaning and Storage

- Clean the scooter with a damp cloth. Do not use high-pressure water or corrosive cleaners.
- Store the scooter in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to about 50-70% and recharge every 30-60 days to prevent deep discharge.

6. Troubleshooting

If you encounter issues with your iX5S Electric Scooter, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Scooter does not power on	Low battery; Loose connections; Faulty power button/key switch	Charge battery; Check all cable connections; Contact customer support if issue persists.
Reduced range/power	Under-inflated tires; Overloaded scooter; Battery degradation	Inflate tires to recommended PSI; Reduce load; Consider battery replacement if old.
Brakes not effective	Worn brake pads; Loose brake cables; Air in hydraulic system (if applicable)	Inspect and replace brake pads; Adjust brake cable tension; Seek professional service.
Unusual noises	Loose components; Debris in wheels/brakes; Motor issue	Check and tighten all screws; Clean wheels/brakes; Contact customer support.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact iScooter customer support.

7. Specifications

Feature	Specification
Brand	iScooter
Model Name	iX5S
Motor Power	1000W
Top Speed	28 MPH
Maximum Distance Range	37-40 Miles
Battery	48V 15Ah Lithium Ion
Charging Time	8 Hours
Weight Limit	330 Pounds

Feature	Specification
Tire Size	11 Inches
Tire Type	Offroad Pneumatic
Brake Style	Double disc brakes and EABS braking systems
Suspension Type	Dual Suspension (Front & Rear Shock Absorber)
Frame Material	Aluminum
Item Weight	60 Pounds
Product Dimensions (LxWxH)	46" x 9.8" x 17.7"
Special Features	Mood Lights, Turn Signals, APP Control

8. Warranty and Support

8.1 Warranty Information

The iScooter iX5S Electric Scooter comes with a limited warranty. The warranty period is typically 1 year for the main components and 6 months for certain parts (e.g., battery, motors, controller, screen, control module). Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact iScooter customer support:

- **Phone:** +1 (855) 916-2366
- **Email:** support@iscooterglobal.com

iScooter prioritizes quality and technical excellence, offering fast and professional service to ensure customer satisfaction.

© 2025 iScooter. All rights reserved.