Effireli YK-AH81-15439A

Effireli Replacement Remote Control User Manual

For Samsung Soundbar Models (YK-AH81-15439A)

1. Introduction

This manual provides instructions for the Effireli replacement remote control, model YK-AH81-15439A, designed for use with various Samsung Soundbar models. This remote offers direct functionality without the need for complex programming or setup.

2. Compatibility

This remote control is compatible with the following Samsung Soundbar models:

- HW-B650/XD, HW-B650/XL, HW-B650/XM, HW-B650/XN, HW-B650/XS, HW-B650/XT, HW-B650/XU, HW-B650/XV, HW-B650/XY, HW-B650/ZA, HW-B650/ZC, HW-B650/ZF, HW-B650/ZL, HW-B650/ZN, HW-B650/ZP, HW-B650/ZS, HW-B650/ZX, HW-B650/EN, HW-B650/RU, HW-B650/SA, HW-B650/TK, HW-B650/XA
- HW-B660/XE, HW-B660/ZG
- HW-B670/XL, HW-B67C/ZC, HW-B67E/XL
- HW-C400/EN, HW-C400/XU, HW-C400/ZA
- HW-S50B/EN, HW-S50B/PE, HW-S50B/RU, HW-S50B/XA, HW-S50B/XN, HW-S50B/XU, HW-S50B/ZC, HW-S50B/ZF, HW-S50B/ZL, HW-S50B/ZN, HW-S50B/ZX
- HW-S56B/XE, HW-S56B/ZG
- HW-B530/EN, HW-B530/XN, HW-B530/XU, HW-B530/ZF, HW-B53C/ZC
- HW-B540/XE, HW-B540/ZG
- HW-B550/EN, HW-B550/PE, HW-B550/RU, HW-B550/SA, HW-B550/XA, HW-B550/XD, HW-B550/XL, HW-B550/XM, HW-B550/XN, HW-B550/XP, HW-B550/XS, HW-B550/XT, HW-B550/XU, HW-B550/XV, HW-B550/XY, HW-B550/ZA, HW-B550/ZB, HW-B550/ZC, HW-B550/ZF, HW-B550/ZK, HW-B550/ZL, HW-B550/ZP, HW-B550/ZS, HW-B550/ZW, HW-B550/ZX
- HW-B560/XE, HW-B560/ZG
- HW-B57C/ZA

Note: If your specific soundbar model is not listed or your original remote appears significantly different,

please contact customer support to confirm compatibility.

3. Setup

3.1 Inserting Batteries

This remote control requires two AAA batteries (not included). To insert batteries:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

3.2 Initial Use

No programming or setup is required for this replacement remote control. Once batteries are inserted, simply point the remote towards your compatible Samsung Soundbar and begin operation.

4. Operating Instructions

Familiarize yourself with the buttons on your Effireli replacement remote control:



Image: Effireli Replacement Remote Control for Samsung Soundbar. This image displays the full layout of the black remote control, highlighting its various function buttons.

Button	Function
Power ( )	Turns the soundbar on or off.
Source/Input (→)	Selects the input source for the soundbar (e.g., HDMI, Optical, Bluetooth).
Bluetooth Pair (ᛒ PAIR)	Initiates Bluetooth pairing mode for connecting devices.
Play/Pause ( )	Plays or pauses media playback.
Mute ( )	Mutes or unmutes the sound.
Sound Mode	Cycles through available sound modes (e.g., Standard, Surround, Game).
Info (i)	Displays information about the current soundbar status or input.
Volume Up (+)	Increases the soundbar volume.
Volume Down (-)	Decreases the soundbar volume.
Woofer (+/-)	Adjusts the woofer level.
CH LEVEL	Adjusts individual channel levels (e.g., front, center, surround).
Settings (⚙)	Accesses soundbar settings menu.
TONE CONTROL	Adjusts bass and treble settings.

5. Maintenance

To ensure optimal performance and longevity of your remote control:

- Keep the remote control clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote to extreme temperatures, humidity, or direct sunlight.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- Replace batteries when the remote's response becomes sluggish or inconsistent.

6. Troubleshooting

If you experience issues with your remote control, consider the following:

- **Remote not responding:** Ensure batteries are inserted correctly and are not depleted. Replace batteries if necessary.
- **Remote range is limited:** Check for any obstructions between the remote and the soundbar. Ensure you are within the effective operating range.
- **Specific buttons not working:** Clean the remote's surface and ensure no debris is obstructing the buttons. If the issue persists, the remote may be faulty.
- **Soundbar not responding to any remote:** Check the soundbar's power and input settings. Ensure the soundbar itself is functioning correctly.

If troubleshooting steps do not resolve the issue, please refer to the Warranty and Support section.

7. Specifications

Model Number	YK-AH81-15439A
Brand	Effireli
Color	Black
Product Dimensions	7.09 x 1.97 x 0.59 inches
Item Weight	1.41 ounces
Special Feature	No Programming Required
Max Number of Supported Devices	1
Compatible Devices	Samsung Soundbars (as listed in Section 2)

8. Warranty and Support

8.1 Warranty Information

This product comes with a 12-month warranty covering manufacturing defects from the date of purchase. Additionally, a 30-day money-back guarantee is offered. Returns and exchanges are accepted within the warranty period for eligible defects.

8.2 Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact the seller directly. Ensure you have your purchase details and product model number (YK-AH81-15439A) available for faster service.

© 2024 Effireli. All rights reserved.