Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MANSCAPED 30-00184

MANSCAPED® The Chairman™ PRO Replacement SkinSafe® Foil Blade Instruction Manual

Model: 30-00184

1. Introduction

Thank you for choosing the MANSCAPED® The Chairman™ PRO Replacement SkinSafe® Foil Blade. This high-quality stainless steel four-blade foil is engineered for precise and effortless grooming, ensuring a smooth, close shave with every use. It is designed for seamless compatibility with The Chairman™ PRO shaver, featuring FlexAdjust Technology to adapt to facial contours and minimize irritation. This manual provides essential information for proper installation, operation, and maintenance of your replacement foil blade.



Figure 1: MANSCAPED® The Chairman™ PRO Replacement SkinSafe® Foil Blade.

2. Safety Information

- Always ensure the shaver is turned off before replacing or cleaning the blade head.
- Handle the foil blade with care to avoid injury. The blades are sharp.
- Keep out of reach of children.
- Do not use the shaver or blade if any part is damaged.
- SkinSafe® technology does not guarantee cut protection. Always use with caution.

3. Package Contents

Your replacement foil blade package typically includes:

- 1 x MANSCAPED® The Chairman™ PRO Replacement SkinSafe® Foil Blade

If you purchased a full shaver kit, it would also include:

- The Chairman™ PRO Shaver Unit
- Stubble Trimmer Blade Head (interchangeable)
- Charging Cable
- Travel Case



Figure 2: The Chairman™ PRO shaver with its interchangeable dual-head system.

4. Blade Replacement

Replacing the foil blade on your The Chairman™ PRO shaver is a simple process thanks to its magnetic attachment system.

1. **To Remove the Current Blade:** Gently pull the magnetic-attached blade head straight up and away from the shaver unit. It should detach with minimal effort.
2. **To Attach the New Blade:** Align the new replacement foil blade head with the shaver unit. The magnetic connection will guide it into place and securely attach it. Ensure it clicks firmly into position.



Figure 3: Demonstrating the removal of a magnetic blade head.

5. Operating Instructions

Once the foil blade is securely attached, you can operate your The Chairman™ PRO shaver.

- **Power On/Off:** Press the main power button to turn the shaver on or off.
- **Battery Indicator:** The shaver features a display that shows the remaining battery percentage.
- **LED Spotlight:** Press the dedicated light button to activate the LED spotlight, which illuminates hard-to-see areas for a more precise shave.
- **FlexAdjust Technology:** The shaver head is designed to adapt to the contours of your face and neck, maintaining close contact for an efficient shave.
- **Precision Lock:** Use the precision lock feature to hold the blade head in a fixed position for detailed grooming.
- **Travel Lock:** For secure portability, press and hold the lock button for 3 seconds to engage or disengage the travel lock. This prevents accidental activation during travel.



Figure 4: Detailed view of the four-blade foil head.

6. Maintenance

Regular cleaning and maintenance will ensure optimal performance and longevity of your foil blade.

- **Daily Cleaning:** After each use, remove the foil blade head and rinse it under running water to remove hair clippings and debris.
- **Deep Cleaning:** Periodically, use a small brush (often included with the shaver) to gently clean the inner workings of the blade head and the shaver unit.
- **Drying:** Allow the blade head and shaver unit to air dry completely before reattaching and storing.
- **Storage:** Store the shaver and blade in a dry, cool place, preferably in its travel case, to protect it from damage.
- **Replacement:** For best performance, it is recommended to replace the foil blade every few months, or when you notice a decrease in shaving efficiency or increased irritation.

7. Troubleshooting

If you encounter any issues with your replacement foil blade or shaver, consider the following:

- **Poor Shaving Performance:** Ensure the blade head is clean and free of debris. If performance is still poor, it may be time to replace the foil blade.
- **Irritation:** Ensure the blade is clean. If irritation persists, consider replacing the blade. Always shave on clean, dry skin for best results.
- **Blade Not Attaching Securely:** Check for any obstructions on the magnetic connection points on both the blade head and the shaver unit. Ensure they are clean.

8. Specifications

Model Name	The Chairman™ PRO Replacement Foil Blade
Model Number	30-00184
Brand	MANSCAPED
Blade Material	Stainless Steel
Number of Blades	4
Head Type	Foil
Color	Black
Unit Count	1.0 Count
Package Dimensions	4.57 x 3.11 x 1.69 inches
Item Weight	1.76 ounces

9. Warranty and Support

For warranty information, product support, or to purchase additional replacement parts, please visit the official MANSCAPED website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Official MANSCAPED Store: Visit the MANSCAPED Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGB9X8RY

More documents and user manuals: **https://manuals.plus/**