Generic T3

T3 Wireless Charging Keyboard and Mouse Set User Manual

Model: T3 | Brand: Generic

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your T3 Wireless Charging Keyboard and Mouse Set. This high-quality unit offers a seamless wireless experience for various computing needs, featuring an ergonomic design and backlighting system.

This image displays the T3 Wireless Charging Keyboard and Mouse Set. The keyboard features orange backlighting on its keys, and the mouse has a distinctive black and orange pattern. Below the keyboard, icons indicate wireless connectivity via a USB receiver and a rechargeable battery.

SETUP

1. Unboxing and Components

Carefully remove all components from the packaging. Ensure you have the following items:

- T3 Wireless Keyboard
- T3 Wireless Mouse
- USB Wireless Receiver
- USB Charging Cable (for keyboard and mouse)

- User Manual (this document)

2. Initial Charging

Before first use, it is recommended to fully charge both the keyboard and the mouse.

1. Locate the charging port on the keyboard and mouse.
2. Connect the provided USB charging cable to the charging port on each device.
3. Plug the other end of the USB cable into a powered USB port (e.g., computer, USB wall adapter).
4. The charging indicator light will illuminate during charging and typically turn off or change color when fully charged.

Allow approximately 2-3 hours for a full charge.

3. Connecting the Wireless Receiver

The T3 set uses a single USB receiver for both the keyboard and mouse.

1. Turn on the keyboard and mouse using their respective power switches (usually located on the underside of the devices).
2. Insert the USB wireless receiver into an available USB port on your computer.
3. Your operating system should automatically detect and install the necessary drivers. This is a plug-and-play device, requiring no manual driver installation.
4. Once drivers are installed, the keyboard and mouse should be ready for use.

OPERATING INSTRUCTIONS

Keyboard Functions

- **Backlighting:** The keyboard features a backlighting system. Use the dedicated backlight key (often indicated by a sun or light bulb icon) to cycle through different lighting modes or to turn the backlighting on/off.
- **Multimedia Function Keys:** The keyboard includes multimedia function keys (F1-F12, often combined with the 'Fn' key). These keys allow quick access to functions like volume control, media playback, and web browsing. Refer to the keycap legends for specific functions.
- **Ergonomic Design:** The keyboard is designed for ergonomic comfort during extended use.

Mouse Functions

- **Optical Resolution:** The mouse operates with an optical resolution of 1600dpi, providing precise tracking.
- **Buttons:** Standard left-click, right-click, and scroll wheel functions are available. Additional side buttons may be present for forward/back navigation or other customizable functions depending on your operating system settings.
- **Power Saving:** The mouse may enter a sleep mode after a period of inactivity to conserve battery. Move the mouse or click a button to wake it up.

MAINTENANCE

Cleaning

- Turn off both the keyboard and mouse before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution.
- Avoid spraying liquids directly onto the devices.
- For keyboard keys, use compressed air to remove dust and debris from between the keys.

Battery Care

- Recharge the devices when the battery indicator is low or when performance degrades.
- Avoid fully depleting the battery frequently, as this can reduce its lifespan.
- If storing the devices for an extended period, charge them to about 50% before storage and recharge every few months.
- Do not expose the devices to extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low battery; Receiver not connected; Device turned off; Interference.	Charge devices; Ensure USB receiver is firmly plugged in; Turn on devices; Move receiver closer or away from other wireless devices.
Lag or intermittent connection	Distance from receiver; Interference; Low battery.	Reduce distance to receiver; Remove sources of interference (e.g., other wireless devices, large metal objects); Recharge devices.
Backlight not working	Backlight turned off; Low battery.	Press the backlight key to cycle modes; Recharge keyboard.
Mouse cursor erratic	Dirty optical sensor; Uneven surface.	Clean the optical sensor on the mouse's underside; Use on a clean, flat, opaque surface.

SPECIFICATIONS

Model: T3

Connectivity: Wireless (USB Receiver)

Mouse Optical Resolution: 1600dpi

Special Features: Wireless charging, Ergonomic design, Backlit keyboard, Multimedia function keys

Compatible Devices: Laptop, Office PC, Gaming PC, Home PC

Item Weight: Approximately 1.7 pounds (for the set)

Color: Black Orange (as per this variant)

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms, conditions, and duration, please refer to the documentation provided at the time of purchase or contact your retailer.
For technical support or inquiries, please contact the product manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase for warranty claims.