X Rocker Aries (Youth) / 7028801

X Rocker Gaming Chair User Manual

Model: Aries (Youth) / 7028801
Brand: X Rocker

1. Introduction

Welcome to the X Rocker Gaming Chair user manual. This guide provides essential information for the setup, operation, maintenance, and troubleshooting of your new X Rocker PC Computer Video Gaming Office Pedestal Chair. Designed for adults, teens, men, boys, and girls, this ergonomic chair features built-in audio speakers for an immersive gaming and entertainment experience. Please read this manual thoroughly before use to ensure proper functionality and safety.

2. Safety Information

To ensure safe operation and prolong the life of your X Rocker Gaming Chair, please adhere to the following safety guidelines:

- **Weight Limit:** Do not exceed the recommended weight capacity of the chair. Refer to the 'Specifications' section for details.
- **Assembly:** Ensure all components are securely fastened before use. Do not use the chair if any parts are damaged or missing.
- **Stability:** Always sit properly in the chair. Avoid standing on the chair or using it as a step stool.
- **Electrical Connections:** When connecting the audio system, ensure all cables are properly inserted and not pinched. Disconnect power before cleaning or moving the chair.
- **Placement:** Place the chair on a stable, level surface. Keep away from direct sunlight, heat sources, and moisture.
- **Children:** Supervise children when they are using the chair to prevent accidents.
- **Cleaning:** Use only a damp cloth for spot cleaning. Avoid harsh chemicals or abrasive cleaners.

3. Package Contents

Please check the package contents to ensure all parts are present:

- X Rocker Gaming Chair (Backrest and Seat Base)
- Pedestal Base
- Armrests (2)
- Power Adapter

- Audio Cables (RCA, AUX)
- Assembly Hardware (Screws, Allen Wrench)
- User Manual (This Document)

4. Setup and Assembly

Follow these steps to assemble your X Rocker Gaming Chair:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Pedestal Base:** Secure the pedestal base to the bottom of the seat base using the provided screws and Allen wrench. Ensure it is firmly attached.
3. **Attach Armrests:** Fasten the armrests to the sides of the seat base using the designated screws.
4. **Connect Backrest:** Align the backrest with the seat base and secure it using the remaining screws. Ensure all connections are tight.
5. **Power Connection:** Connect the power adapter to the chair's power input and then to a wall outlet.
6. **Audio Connection:** Use the provided audio cables (RCA or AUX) to connect the chair's audio input to your gaming console, PC, TV, or other audio source. The chair features 2 headrest mounted speakers and a backrest subwoofer.



Figure 4.1: Fully assembled X Rocker Gaming Chair, showcasing its black and gold design with integrated armrests and pedestal base.

5. Operating Instructions

5.1 Audio System Operation

Your X Rocker Gaming Chair is equipped with a built-in sound system for an immersive audio experience.

- **Power On/Off:** Locate the control panel on the side of the chair. Use the power button to turn the audio system on or off.
- **Volume Control:** Adjust the master volume using the dedicated knob on the control panel.
- **Bass Control:** A separate knob allows you to adjust the intensity of the subwoofer's bass output.
- **Input Selection:** If multiple audio sources are connected, use the input selector (if available on your model) to switch between them.

5.2 Ergonomic Features

The chair's design prioritizes comfort and support during long sessions.

- **Swivel Function:** The elevated pedestal base allows for 360-degree swivel movement, providing flexibility and dynamic positioning.
- **Rocking Function:** The chair is designed for naturally smooth rocking, enhancing comfort during active play or relaxation.
- **Fixed Armrests:** The integrated armrests provide stable support for your arms and shoulders.
- **Ergonomic Backrest:** The naturally curving backrest and deeply padded foam interior offer sustained comfort and support.

5.3 Storage

For convenient storage, the X Rocker Gaming Chair can be folded down.

- **Folding Mechanism:** Gently push the backrest forward towards the seat. The chair is designed to fold compactly for easy storage when not in use.

6. Maintenance

Proper maintenance will ensure the longevity of your gaming chair.

- **Cleaning:** The chair is finished in a soft and durable faux leather material. For cleaning, use a damp cloth to spot clean any spills or dirt. Do not use abrasive cleaners, solvents, or harsh chemicals as these may damage the material.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Punctures:** Keep sharp objects away from the chair's surface to prevent tears or punctures in the faux leather.

7. Troubleshooting

If you encounter any issues with your X Rocker Gaming Chair, refer to the following common problems and solutions:

- **No Sound from Speakers:**
  - Ensure the power adapter is securely connected to both the chair and a working wall outlet.
  - Verify the audio system is powered on via the control panel.
  - Check that the volume knob is turned up.
  - Confirm that the audio cables are correctly connected to both the chair and your audio source (console, PC, TV).
  - Test with a different audio source or cable to rule out external device issues.
- **Chair Feels Unstable/Wobbly:**
  - Ensure all assembly screws are tightened securely. Refer back to Section 4: Setup and Assembly.
  - Verify the chair is placed on a flat, level surface.
- **Difficulty Folding the Chair:**
  - Ensure there are no obstructions preventing the backrest from folding forward.

- Apply gentle, even pressure to fold the chair. Do not force it.

8. Specifications

Attribute	Detail
Brand	X Rocker
Model Name	Audio Junior Pedestal Gaming Chair
Model Number	7028801
Style	Aries (Youth)
Color	Black/Gold
Product Dimensions (LxWxH)	26.77"D x 19.69"W x 36.61"H
Back Style	Solid Back
Recommended Uses	Gaming
Room Type	Office, Kids Room, Game Recreation Room, Bedroom, Home Theater
Age Range	Child
UPC	094338702880
Manufacturer	X Rocker
Special Features	Built-in Audio Speakers, Ergonomic Design, Swivels, Rocks, Folds

9. Warranty and Support

For warranty information and customer support, please refer to the official X Rocker website or contact their customer service department. Keep your purchase receipt for any warranty claims.

© 2025 X Rocker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question