Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC/DC Adapter

onerbl AC/DC Adapter for SKP Audio SMX-2200 Digital Midi Controller User Manual

Model: AC/DC Adapter

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC/DC Adapter. Please read these instructions carefully before using the product and retain them for future reference. This adapter is designed to provide power to compatible devices, specifically the SKP Audio SMX-2200 Digital Midi Controller.

2. Product Overview

The onerbl AC/DC Adapter is a high-quality replacement power charger designed to meet the power requirements of your compatible device. It converts standard AC wall power into the DC power needed by your equipment, allowing for operation or battery charging.

Key Features:

- High-quality replacement power charger adapter.
- Universal input: AC 100-240V 50/60Hz (suitable for worldwide use).
- Extended cable length for convenience.
- Built-in Over Voltage Protection and Over Heat Protection for device safety.
- Tested units ensuring reliable performance.



Image: Front view of the onerbl AC/DC Adapter, displaying its input specifications (100-240V AC, 50/60Hz) and a "CAUTION INDOOR USE ONLY" label. The cable is coiled neatly below the adapter.

3. Setup Instructions

1. **Verify Compatibility:** Ensure your device is the SKP Audio SMX-2200 Digital Midi Controller or another device requiring the same power specifications. Refer to your device's manual for power requirements.
2. **Connect to Device:** Carefully insert the adapter's DC output plug into the power input port of your SKP Audio SMX-2200 Digital Midi Controller. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the adapter's AC input prongs into a standard wall power outlet (AC 100-240V, 50/60Hz).
4. **Power On:** Once connected, your device should receive power. Follow your device's instructions to power it on.



Image: The onerbl AC/DC Adapter is shown plugged into a white wall outlet, demonstrating a typical setup. A small green potted plant is positioned nearby.

4. Operating Instructions

The onerbl AC/DC Adapter operates automatically once connected correctly. It provides continuous power to your compatible device. There are no user-adjustable settings on the adapter itself.

- Ensure the adapter is always plugged into a functional power outlet.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- Always handle the adapter and its cables with care to prevent damage.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires, cracks, or bent prongs. If damage is found, discontinue use immediately and replace the adapter.

6. Troubleshooting

If you encounter issues with your onerbl AC/DC Adapter, refer to the following common troubleshooting steps:

1. **No Power to Device:**
    - Ensure the adapter is securely plugged into both the wall outlet and your device.
    - Test the wall outlet with another known working appliance to confirm it has power.
    - Verify that your device's power switch is in the "ON" position.
    - Confirm the adapter is the correct model and voltage for your device.
2. **Adapter Feels Hot:**
    - It is normal for adapters to feel warm during operation. However, if it becomes excessively hot to the touch or emits a burning smell, disconnect it immediately from the power source and discontinue use.
    - Ensure the adapter is in a well-ventilated area and not covered.
3. **Device Not Charging (if applicable):**
    - Check the device's charging indicator.
    - Ensure the device's battery is properly seated (if removable).

If these steps do not resolve the issue, contact customer support for further assistance.

7. Specifications

Brand	onerbl
Model	AC/DC Adapter
Input Voltage	AC 100-240V, 50/60Hz
Compatible Devices	SKP Audio SMX-2200, SMX2200 Digital Midi Controller
Cable Length	Approx. 76 inches (6.5 feet)
Dimensions (Adapter Body)	Approx. 3.1 inches (Height) x 2.1 inches (Width) x 1.2 inches (Depth)
Safety Features	Over Voltage Protection, Over Heat Protection



Image: A detailed diagram illustrating the physical dimensions of the onerbl AC/DC Adapter. The main body measures approximately 3.1 inches in height, 2.1 inches in width, and 1.2 inches in depth. The cable length is also indicated as 76 inches.

8. Safety Information

- **Indoor Use Only:** This adapter is designed for indoor use only. Do not expose it to rain, moisture, or extreme temperatures.
- **Avoid Overloading:** Do not overload power outlets or extension cords, as this can lead to fire or electric shock.
- **Proper Ventilation:** Ensure the adapter is placed in a well-ventilated area to prevent overheating. Do not cover it with cloths or other materials.
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter yourself. Refer all servicing to qualified personnel.
- **Keep Away from Children:** Store the adapter and its cables out of reach of children.
- **Disconnect Safely:** Always grasp the plug, not the cable, when disconnecting the adapter from a power outlet.

9. Warranty and Support

Warranty information for this product is typically provided with your purchase or can be obtained directly from the manufacturer or seller. Please refer to your purchase documentation for specific warranty terms and conditions.
For technical support or inquiries, please contact the seller or manufacturer directly. Contact details are usually available on the product packaging or the point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question