Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

L LAVAREDO T15E

L LAVAREDO Kids Digital Watch T15E User Manual

1. Introduction

Welcome to the user manual for your L LAVAREDO Kids Digital Watch T15E. This guide provides detailed instructions on how to set up, operate, and maintain your watch, ensuring optimal performance and longevity. Please read this manual thoroughly before using the watch.

2. Product Overview

2.1 Key Features

- **Fitness Tracker:** Pedometer, calorie counter, and mileage tracker without requiring a smartphone app.
- **Multi-function Display:** Time, date, alarm, stopwatch, and EL-backlight.
- **Silent Vibration Alarm:** Two customizable vibration alarms to avoid disturbing others.
- **Rechargeable Battery:** Improved charging port for enhanced water resistance, offering 10-15 days of normal use on a 2-hour charge.
- **50M Water Resistance:** Suitable for daily activities like hand washing, water splashing, and rain.
- **Durable Design:** Sturdy zinc alloy case, high-resolution resin dial, metal back cover, and soft silicone strap.

2.2 Watch Components

The L LAVAREDO Kids Digital Watch T15E features a clear digital display and two control buttons, typically labeled 'A' and 'B', located on the side of the watch case. The back of the watch includes charging contacts.



Front view of the L LAVAREDO Kids Digital Watch T15E, showing the digital display and side buttons.



Rear view of the watch, highlighting the charging contacts and regulatory markings.



Detail of the soft silicone strap, designed for comfort.



Visual representation of the watch's various functions.

3. Setup

3.1 Initial Charging

Before first use, fully charge your watch. Connect the provided charging cable to the watch's charging port and a standard USB power adapter (not included). A full charge typically takes about 2 hours and provides 10-15 days of normal use.



The watch connected to its charging cable.

3.2 Setting Time and Date

1. From the time display, press button **A** repeatedly to cycle through modes until you reach the time setting mode (usually indicated by flashing digits).
2. Use button **B** to adjust the flashing digit (hours, minutes, year, month, day).
3. Press button **A** again to move to the next setting item.
4. Once all settings are adjusted, press button **A** to exit the setting mode.

3.3 Pedometer Setup

To ensure accurate step, calorie, and mileage tracking, you may need to input your height and weight. Refer to the watch's display during pedometer setup mode (accessed by cycling through modes with button **A**) and use button **B** to adjust values as prompted.

4. Operating Instructions

4.1 Time Display Mode

In the default time display mode, the watch shows the current time. Press button **A** once to briefly display the date, then it will return to the time display.

4.2 Pedometer Mode

Press button **A** repeatedly until the pedometer icon appears. The display will show your current step count. Continue pressing **A** to view calories burned and distance traveled.



The watch tracking activity during play.

4.3 Stopwatch Mode

To use the stopwatch:

1. Press button **A** until the stopwatch mode is displayed (usually showing '00:00:00').
2. Press button **B** to start the stopwatch.
3. Press button **B** again to pause/resume.
4. To reset, press button **A** while the stopwatch is paused.



Stopwatch function icon.

4.4 Vibration Alarm

The watch supports two silent vibration alarms:

1. Press button **A** repeatedly until you reach the alarm setting mode (e.g., 'A1 OF' or 'A1 00:00').
2. To enable or disable the alarm, press and hold button**A**. The display will toggle between 'A1 OF' (off) and the alarm time (on).
3. When the alarm is enabled, use button **B** to set the desired alarm time.
4. Repeat for Alarm 2 if needed.



The watch's silent vibration alarm in use.

4.5 EL-Backlight

To illuminate the display in low-light conditions, press button**B**. The backlight will activate for a few seconds.

5. Maintenance

5.1 Charging Guidelines

Always use the provided charging cable. Ensure the charging contacts on the watch and cable are clean and dry before connecting. Avoid overcharging the watch for extended periods.

5.2 Water Resistance

The L LAVAREDO Kids Digital Watch T15E is rated 50M water-resistant. This means it is suitable for daily activities such as hand washing, water splashing, and use in rainy conditions. **Important Note:** Do not wear the watch when it is completely submerged in water, such as during swimming or bathing, as this can compromise its water resistance.



Water resistance guidelines for the watch.

5.3 Cleaning

Clean the watch regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the watch's finish or components.

6. Troubleshooting

Issue	Possible Solution
Watch not turning on	Ensure the watch is fully charged. Connect to the charger for at least 30 minutes.
Display is dim or unresponsive	Charge the watch. If the issue persists, perform a soft reset (refer to manufacturer support if available).
Pedometer inaccurate	Verify that height and weight settings are correctly entered. Ensure the watch is worn snugly on the wrist.
Alarm not vibrating	Check if the alarm is enabled in the settings. Ensure the volume/vibration setting is not set to 'off' if applicable.
Water damage after exposure	Confirm that the watch was not submerged beyond its 50M water resistance rating (e.g., swimming or bathing). Contact support if damage occurred within specified limits.

7. Specifications

- **Model Number:** T15E
- **Brand:** L LAVAREDO
- **Water Resistance:** 50M (Daily life waterproof, not for swimming/bathing)
- **Battery Life:** Approximately 10-15 days (normal use)
- **Charging Time:** Approximately 2 hours
- **Strap Material:** Soft Silicone
- **Case Material:** Zinc Alloy
- **Display Type:** Digital
- **Strap Length (Min-Max):** 5.1 inches - 7.6 inches
- **Recommended Age:** 5-13 years

8. Warranty and Support

L LAVAREDO is committed to providing reliable products and customer satisfaction. If you encounter any issues or have questions regarding your T15E Kids Digital Watch, please contact our customer support. We aim to provide a satisfactory resolution to your inquiries.

For support, please refer to the contact information provided with your purchase or visit the official L LAVAREDO brand store online.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGQF8ZQS

More documents and user manuals: **https://manuals.plus/**