De'Longhi EC900M

De’Longhi Dedica Maestro Espresso Machine

Model: EC900M | Brand: De'Longhi

Introduction

The De’Longhi Dedica Maestro is designed for an authentic brewing experience, offering preset recipes for single and double espresso and coffee. It features a 15-bar pump for consistent results, Active Temperature Control with three brewing temperatures for optimal extraction, and a MyLatte Art steam wand for perfect milk froth. This manual provides comprehensive instructions for setup, operation, and maintenance.

Setup

Unboxing and Initial Placement

Carefully remove all components from the packaging. Place the espresso machine on a stable, flat surface near a power outlet. Ensure adequate clearance around the machine for ventilation and access to the water tank.



Figure 1: De'Longhi Dedica Maestro Espresso Machine setup on a countertop.

Water Tank Preparation

Fill the 54 oz water tank with fresh, cold water. Ensure the tank is properly seated in its compartment at the back of the machine.



Figure 2: Compact design of the espresso machine, highlighting the water tank location.

Power Connection

Plug the machine into a grounded electrical outlet. The indicator lights on the control panel will illuminate, signaling that the machine is powered on and beginning its heating cycle.

Your browser does not support the video tag.

Video 1: Official De'Longhi introduction to the Dedica Maestro, showcasing its features and compact design.

Operating Instructions

Making Espresso

The Dedica Maestro features a 15-bar professional pump for optimal extraction. It heats up quickly thanks to Advanced Thermoblock technology.

1. Select your desired filter basket (single or double shot) and insert it into the portafilter.
2. Add ground coffee to the filter basket. Use the professional tamper to evenly press the coffee grounds.
3. Attach the portafilter to the machine's brewing head.
4. Place your cup(s) on the drip tray. For smaller cups, use the espresso shelf to reduce splash.
5. Select your desired espresso shot (single or double) using the intuitive control panel. The machine will begin brewing.



Figure 3: Expertly extracted espresso with consistent 9-bar extraction.

Temperature Control

Active Temperature Control provides stability and allows you to customize brewing temperatures to match your coffee beans for optimal extraction. Refer to the control panel for temperature settings.

Milk Frothing (Manual Frother)

The MyLatte Art steam wand allows you to create rich, creamy foam for latte art or thick foam for cappuccinos.

1. Fill a milk pitcher with cold milk (dairy or alternative).
2. Position the steam wand into the milk, ensuring the tip is just below the surface.
3. Activate the steam function on the control panel.
4. Move the pitcher up and down to incorporate air and create foam. Once desired texture is achieved, turn off the steam.
5. Wipe the steam wand immediately after use with a damp cloth to prevent milk residue buildup.



Figure 4: Powerful steam wand froths milk and alternatives to silky smooth microfoam.

Maintenance

Cleaning the Drip Tray

Regularly empty and clean the drip tray to prevent overflow and maintain hygiene. The fully stainless steel finish makes clean up simple.

Cleaning the Steam Wand

After each use, wipe the steam wand with a damp cloth. Periodically, remove the steam wand nozzle and rinse it thoroughly to clear any milk blockages.

Descaling

The machine will indicate when descaling is required. Follow the instructions in the quick start guide for the descaling process to ensure optimal performance and longevity of your machine.

Troubleshooting

If you encounter issues with your De'Longhi Dedica Maestro, refer to the following common troubleshooting steps:

- **No water flow:** Check if the water tank is filled and correctly inserted. Ensure the machine is heated up.
- **Weak espresso extraction:** Verify that the coffee grounds are not too coarse or too fine. Ensure the coffee is properly tamped.
- **No steam from wand:** Check if the steam function is activated and the machine has reached steaming temperature. Ensure the wand is not clogged with dried milk.
- **Machine not heating:** Confirm the machine is plugged in and powered on. Allow sufficient time for the Advanced Thermoblock technology to heat up (ready in seconds).

For persistent issues, contact De'Longhi customer support.

Specifications

- **Model Name:** Dedica Maestro
- **Model Number:** EC900M
- **Brand:** De'Longhi
- **Color:** Stainless Steel
- **Product Dimensions:** 13.62"D x 8.15"W x 12.9"H
- **Item Weight:** 12.12 pounds
- **Special Features:** 15 Bar Professional Pump, Advanced Thermoblock Technology, Commercial-Style Steam Wand, Compact Footprint
- **Coffee Maker Type:** Espresso Machine
- **Filter Type:** Reusable (includes single and double wall filters)
- **Style:** Manual Frother
- **Operation Mode:** Semi-Automatic
- **Voltage:** 120 Volts
- **Included Components:** Professional tamper, small cup tray, cleaning brush, cleaning needle, Double coffee Filter (pressurized), Single coffee filter (Unpressurized), Double coffee Filter (unpressurized), Measuring Scoop, Total Hardness Test, Single coffee filter (pressurized).



Figure 5: Included accessories for the Dedica Maestro.

Warranty and Support

The De'Longhi Dedica Maestro Espresso Machine comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please visit the official De'Longhi website or contact their customer service line.

Online Resources: Visit the De'Longhi Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question