Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

kerry yoo C11

KerryYoo C11 Electric Dirt Bike User Manual

Model: C11 | Brand: KerryYoo

1. Introduction

Welcome to the KerryYoo C11 Electric Dirt Bike user manual. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new electric dirt bike. Please read this manual thoroughly before operating the bike to ensure a safe and enjoyable experience for the rider.

The KerryYoo C11 is designed for young riders aged 8-14, offering an exciting off-road experience with its powerful motor and durable construction.



Figure 1.1: KerryYoo C11 Electric Dirt Bike

2. Safety Information

Your safety and the safety of others are paramount. Always adhere to the following safety guidelines:

- **Protective Gear:** Always wear a helmet, knee pads, elbow pads, and appropriate footwear when riding the dirt bike.
- **Adult Supervision:** This product requires direct adult supervision at all times during operation.
- **Riding Environment:** Ride only in safe, open areas away from traffic, pedestrians, and obstacles. Avoid riding on public roads or sidewalks.
- **Weight and Age Limits:** The bike is designed for riders aged 8-14 years and supports a maximum load of 200 lbs. Do not exceed these limits.
- **Braking:** Familiarize yourself with the hydraulic disc brakes and practice stopping safely before riding at higher speeds.
- **Battery Safety:** Do not tamper with the battery or charging system. Use only the provided charger.
- **Pre-Ride Check:** Before each ride, check the tires, brakes, and overall condition of the bike.

3. Product Features

The KerryYoo C11 Electric Dirt Bike is equipped with advanced features for performance and safety:

- **Powerful 36V 350W Motor & Long-Lasting Battery:**

  Equipped with a 36V 350W motor, this electric dirt bike delivers a top speed of 16MPH. The 36V 9AH battery provides approximately 1.5 hours of ride time after 6-9 hours of charging.



Figure 3.1: Motor and Battery Housing

- **Explosion-Proof Tires & Spring Suspension:**

  Features durable, explosion-proof rubber tires for reliability on various terrains. The spring suspension system ensures a smooth and stable ride, absorbing shocks from uneven surfaces.



Figure 3.2: Tires and Suspension System

- **Twist Grip Throttle & Infinitely Variable Speed:**

  Designed with a twist grip throttle for intuitive speed control, offering an infinitely variable speed range up to 16 mph for a customizable riding experience.



Figure 3.3: Twist Grip Throttle

- **Hydraulic Disc Brakes & Full Metal Frame:**

  Equipped with advanced hydraulic disc brakes for reliable stopping power. The full metal frame ensures durability and can support riders up to 200 lbs.



Figure 3.4: Hydraulic Disc Brakes and Key Ignition

- **Compact Design & Load Capacity:**

  The bike features a compact design suitable for young riders, with dimensions of 45 x 9 x 25 inches and a maximum load capacity of 200 lbs.



Figure 3.5: Product Dimensions and Load Capacity

4. Setup

4.1 Initial Charging

Before the first use, fully charge the battery. The initial charging time is typically 6-9 hours. Locate the charging port on the side of the bike (refer to Figure 3.4 for general location) and connect the provided charger. The indicator light on the charger will change when charging is complete.

4.2 Assembly

The KerryYoo C11 Electric Dirt Bike comes mostly pre-assembled. Minor assembly may be required, such as attaching the handlebars or front fender. Please refer to the separate assembly guide included in the packaging for detailed instructions. Ensure all bolts and fasteners are securely tightened before operation.

5. Operating Instructions

5.1 Power On/Off

To power on the bike, insert the key into the ignition (refer to Figure 3.4) and turn it to the 'ON' position. The power indicator on the handlebar will illuminate. To turn off, turn the key to the 'OFF' position and remove it.

5.2 Battery Indicator

The handlebar features a power indicator (refer to Figure 3.3) that displays the current battery level. Ensure the battery is sufficiently charged before each ride.

5.3 Riding the Bike

1. Ensure the bike is on a flat, stable surface and the kickstand is up.
2. Mount the bike, placing your feet on the footrests.
3. Slowly twist the right-hand grip (throttle) towards you to accelerate. The speed is infinitely variable, allowing for smooth acceleration.
4. To slow down or stop, release the throttle and gently apply the brake levers located on the handlebars.

5.4 Kickstand Operation

The bike is equipped with a sturdy kickstand for convenient parking. To deploy, push the kickstand down with your foot until it locks into place. To retract, lift the bike slightly and push the kickstand back up.

5.5 Official Product Video

Watch the official product video for a visual guide on the features and operation of the KerryYoo 36V Electric Dirt Bike:

Your browser does not support the video tag.

Video 5.1: Official KerryYoo 36V Electric Dirt Bike Overview. This video demonstrates key features and shows the bike in action on various terrains.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your electric dirt bike:

- **Battery Care:**
  - Always fully charge the battery after each use.
  - If storing the bike for an extended period, charge the battery every 30 days to maintain its health.
  - Do not overcharge or completely drain the battery.
- **Tire Pressure:** Regularly check tire pressure and inflate to the recommended PSI (usually found on the tire sidewall) to ensure optimal performance and safety.
- **Cleaning:** Clean the bike with a damp cloth. Avoid using high-pressure water jets or harsh chemicals, which can damage electrical components.
- **General Inspection:** Periodically check all nuts, bolts, and moving parts for tightness and wear. Lubricate moving parts as necessary.

7. Troubleshooting

If you encounter issues with your KerryYoo C11 Electric Dirt Bike, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bike does not power on.	Battery is not charged; Power switch is off; Key not fully inserted/turned.	Charge the battery; Ensure power switch is ON; Fully insert and turn the key.
Low power or slow speed.	Low battery charge; Rider weight exceeds limit; Riding on steep inclines.	Recharge battery; Ensure rider is within weight limit; Ride on flatter terrain.
Brakes are not effective.	Brake pads worn; Brake cable loose.	Inspect brake pads and replace if necessary; Adjust brake cable tension. Consult professional if unsure.

If the problem persists after attempting these solutions, please contact KerryYoo customer support for assistance.

8. Specifications

Feature	Detail
Model	C11
Motor Power	36V 350W
Top Speed	Up to 16 MPH
Battery	36V 9AH
Ride Time	Approx. 1.5 hours (after 6-9 hours charge)
Tires	Explosion-Proof Rubber
Brakes	Hydraulic Disc Brakes
Frame Material	Full Metal Frame
Product Dimensions	45 x 9 x 25 inches
Item Weight	61 pounds
Recommended Age	8-14 years
Max Load Capacity	200 lbs

9. Warranty and Support

KerryYoo stands behind the quality of its products. For warranty information, technical support, or any inquiries regarding your C11 Electric Dirt Bike, please contact KerryYoo customer service. Details can typically be found on the product packaging or the official KerryYoo website.
We are committed to providing excellent service and ensuring your satisfaction.

© 2024 KerryYoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGTRMRM8

More documents and user manuals: **https://manuals.plus/**